KNX[®] Power Supply System KNX PS640-IP

with Ethernet Interface



Installation and Adjustment



Elsner Elektronik GmbH Steuerungs- und Automatisierungstechnik Herdweg 7 • D-75391 Gechingen • Germany Phone: +49 (0) 70 56/93 97-0 • Fax: +49 (0) 70 56/93 97-20 info@elsner-elektronik.de • www.elsner-elektronik.de

Contents

Product description	3
Application	4
Technical data	6
Installation and commissioning	7
Installation	7
Operation (Settings at the Device)	9
Starting position	9
Line reset	9
Data memory1	0
Operating data	1
Language1	1
Setting of parameters (Software ETS)1	3
General	3
IP configuration1	4
Routing (KNX -> IP) 1	6
Routing (IP -> KNX)1	7
ETS Connection Manager1	9

KNX PS640-IP from software version display 1.0, IP chip 1.1, ETS programme version 1.0 Version: 01/09/2009. Errors excepted. Subject to technical changes.

Product description

The Power Supply System KNX PS640-IP combines the central functions of a KNX bus line: Power supply with throttle, IP router and IP interface:

The **power supply unit** of the KNX PS640-IP delivers a 29 V bus voltage for the KNX system and 24 V DC supply voltage for 24 V devices. Special operating conditions such as short circuit, electrical surge, overcharge or excess temperature are recorded and may be read off on the display. The present power discharge is displayed as well. It is possible to reset the connected bus devices directly by means of the key pad.

The *IP router* of the KNX PS640-IP allows for forwarding of telegrams between different lines via a rapid LAN (IP) backbone. The KNX PS640-IP therfore also takes on the function of a line coupler.

In parallel, the KNX PS640-IP can be used as *interface for accessing the bus* via IP. Like this, the KNX system can be configuered and supervised from any PC in the LAN (Tunnelling).

This device works according to the KNXnet/IP specification using the core, the device management, the tunnelling and the routing part. The router of KNX PS640-IP has a filter table and is able to buffer up to 150 telegrams.

Functions:

- Delivers a **29 V KNX bus voltage** (reduced), output current max. 640 mA, shortcircuit proof
- Delivers 24 V DC (not reduced), output current max. 150 mA
- **Reset** of a line directly on the device
- Record of operating hours, overload, external overvoltage, internal overvoltage, short circuit and excess temperature
- Display of operating data bus voltage, bus current and temperature of the device
- The display may be shown in German, English, Spanish or Dutch
- **Routing:** Transfer of KNX data via LAN (rapid backbone)
- Line coupler function via LAN
- **Tunnelling:** Configuration and supervising of the KNX system from any PC in the LAN

Application

Coupler function (KNXnet/IP Routing)

The Power Supply System KNX PS640-IP can operate as a line and/or backbone coupler. In both cases, the LAN (IP) acts as a backbone.



KNX PS640-IP as a line coupler



The physical address assigned to the KNX PS640-IP determines whether the device operates as a line or backbone coupler. If the physical address is in the form of x.y.0 (x, y: 1..15), the router operates as a line coupler. If it is in the form of x.0.0 (x: 1..15), the router acts as a backbone coupler.

Attention: If the KNX PS640-IP is used as a backbone coupler (x.0.0), there must be no KNX IP Router in the topology beneath it. For example, if a KNX PS640-IP has the physical address of 1.0.0, there must be no KNX IP Router with the address 1.1.0.

If the KNX PS640-IP is used as a line coupler (x.y.0), there must be no KNX IP Router in the topology above it. For example, if a KNX PS640-IP has the physical address of 1.1.0, there must be no KNX IP Router with the address 1.0.0.

The KNX PS640-IP has a filter table and thus contributes to reducing bus load. The filter table is automatically generated by the ETS.

Because of the speed difference between the Ethernet (10 Mbit/s) and KNX (9.6 kbit/s), a far greater number of telegrams can be transmitted on IP. If several consecutive telegrams are transmitted on the same line, they must be buffered in the router to avoid telegram loss. The KNX PS640-IP 750 has a memory for 150 telegrams (from IP to KNX/EIB).

Bus access (KNXnet/IP Tunnelling)

The Power Supply System KNX PS640-IP can be used as an interface to KNX. KNX can be accessed from any point in the LAN. For this purpose, a second physical address must be assigned in the ETS. Please refer to chapter "ETS Connection Manager".

Technical data

	۸		
Housing:	Plastic material		
Colour:	White		
Mounting:	Snap-on fitting on mounting rails		
Protection category:	IP 20		
Dimensions:	approx. 123 x 89 x 61 (W x H x D, mm), 7 width units		
Weight:	approx. 395 g		
Ambient temperature:	Operation -5+45 °C, Storage -25+70°C		
Ambient air humidity:	max. 95% R. H., avoid bedewing		
Operating voltage:	230 V AC , 50 Hz		
Power consumption:	approx. 28 W (full load)		
Outputs:	 KNX bus voltage 29 V (reduced), Output current max. 640 mA, short-circuit proof 24 V DC (not reduced), Output current max. 150 mA LAN connector RJ45; 10BaseT (10Mbit/s), Supported internet protocols: ARP, ICMP, IGMP, UDP/IP and DHCP 		

The following standards have been considered for the evaluation of the product in terms of electro magnetic compatibility:

Transient emissions:

- EN 60730-1:2000 Section EMV (23, 26, H23, H26) (threshold category: B)
- EN 50090-2-2:1996-11 + A1:2002-01 (threshold category: B)
- EN 61000-6-3:2001 (threshold category: B)

Interference resistance:

- EN 60730-1:2000 Section EMV (23, 26, H23, H26)
- EN 50090-2-2:1996-11 + A1:2002-01
- EN 61000-6-1:2004

The product has been tested for the above mentioned standards by an accredited EMV laboratory.

Installation and commissioning

Attention! Mains voltage! The legal national regulations must be complied with.

Installation, inspection, commissioning and troubleshooting of the power supply system must only be carried out by a competent electrician. Disconnect all lines to be assembled, and take safety precautions against accidental switch-on.

The power supply is exclusively intended for appropriate use. With each inappropriate change or non-observance of the instructions for use, any warranty or guarantee claim will be void.

After unpacking the device, check immediately for any mechanical damages. In case of transport damage, this must immediately notified to the supplier.

If damaged, the power supply system must not be put into operation.

If an operation without risk may supposedly not be guaranteed, the plant must be put out of operation and be secured against accidental operation.

The power supply system must only be operated as stationary system, i.e. only in a fitted state and after completion of all installation and start-up works, and only in the environment intended for this purpose.

Elsner Elektronik does not assume any liability for changes in standards after publication of this instruction manual.

Installation

Observe the correct installation. Incorrect installation may destroy the power supply system or connected electronic devices.





Housing



- 1 LAN connection (RJ45, for Ethernet patch cabel)
- 2 Programming LED and programming button
- 3 Bus connection (KNX terminal + / -)
- 4 Input operating voltage 230 V AC, L / N / PE
- 5 Output direct current voltage 24 V DC, + / -

Connections 4 and 5 are suitable for solid conductors up to 1.5 mm² or conductors with fine wires.

Scheme



Operation (Settings at the Device)

Starting position

```
elsner elektronik
KNX PS640-IP
Normal Operation
Diagnostics >
```

The following may be read off and set on the display of the Power Supply System KNX PS640-IP:

- Reset of a line
- Recall of the data memory with operating hours, overcharge, external electrical surge, internal electrical surge, short circuit and excess temperature
- Recall of the operating data bus voltage, bus current and temperature
- Language of display

The backlight of the display will be switched off automatically if the temperature inside the housing exceeds 50°C. Thus a high thermal load is avoided.

Line reset

elsner elektronik KNX PS640-IP Normal Operation Diagnostics > In starting position, press key \triangleright once.

Line Reset > I Data Memory > Operating Data > Language Press key \triangleright once more in order to get into the sector "Line reset".

Reset: Yes No 30 seconds Reset not active! Mov the o with

Move the cursor (flashing rectangle at right edge) to the desired setting with the keys ∇ or \triangle and confirm with key **Ok**.

Yes: Reset is activated. The line is switched to neutral and shorted. The basic setting displays: "Reset is active!"

No: Reset not activated. The power supply system works in normal operation.

30 seconds: A reset of 30 seconds is started. Afterwards, the line is supplied with voltage as usual. During the reset state, which lasts 30 seconds, the basic setting displays: "Reset active: XX sec" (countdown).

With key \triangleleft , you return to the previous menu level.

Data memory

elsner elektronik KNX PS640-IP Normal Operation Diagnostics > In starting position, press key \triangleright once.

Line Reset > Data Memory > **■** Operating Data > Language > Move the cursor (flashing rectangle at right edge) to the "Data memory" menu with the keys ∇ and \triangle and confirm with key \triangleright .

Hours ofOperation> **■** Overload > Ext. Overvoltage > Int. Overvoltage > Short circuit > Excess Temperat. >

Move the cursor to the desired menu with the up and down keys and press key \triangleright .

Operating hours

Runtime: Øuears	The operating hours of the power supply system are
Ødau Øhrs.	displayed in years, days and hours.
	With key \lhd you return to the previous menu level.
< = Back	

Overload

Overload detected	The number of overload incidents and the total time in
Ø times. Duration:	days, hours and minutes are displayed.
0 day. 0 hrs. 0 min	With key \lhd you return to the previous menu level.
< = Back	

External overvoltage

External Overvoltage	The number of external overvoltage incidents	is	
was detected	displayed.		
Ø times.	With key \triangleleft you return to the previous menu level.		

Internal overvoltage

Internal Overvoltage	The number of internal overvoltage incidents i	s		
was detected	displayed.			
Ø times.	With key \triangleleft you return to the previous menu level.			
< = Back				

Short circuit

bus	IS
el.	
7(′el.

Excess temperature

Excess Temperature	The number of excess temperature incidents on the				
on the board	circuit board of the device is displayed.				
was detected	With key ⊲ you return to the previous menu level.				
Ø times!					

Operating data

elsner elektronik
KNX PS640-IP
Normal Operation
Diagnostics >

In starting position, press key \triangleright once.

Line	Reset		>	
Data	Memor	Ч	\geq	
Oper	ating	Data	\geq	
Lang	ha de _		>	

Move the cursor (flashing rectangle at right edge) to the "Operating Data" menu with the keys ∇ and \triangle and confirm with key \triangleright .

Bus Voltage	29.4V
Bus Current	320 mA
Temperature	42.1°C

The current values of

- Bus voltage
- Bus current

• Temperature on the circuit board of the device are displayed.

With key \triangleleft you return to the previous menu level.

Language

```
elsner elektronik
KNX PS640-IP
Normal Operation
Diagnostics >
```

In starting position, press key \triangleright once.

Line Reset	\geq	
Data Memory	\geq	
Operating Data	\geq	
Language	\geq	

Move the cursor (flashing rectangle at right edge) to the "Language" menu with the keys ∇ and \triangle and confirm with the key \triangleright .

Sprache Language	 Deutsch 📗 English
Idioma ⁻ Taal	 Espanol Hollands

Move the cursor to the desired language with the up and down keys and press the key **ok**. The display automatically jumps to the previous menu in the desired language.

With key \triangleleft you get back by one menu level to the basic setting.

Setting of parameters (Software ETS)

General

1.1.0 KNX PS640-IP			
General	General		
IP-Configuration 1 Routing (KNX -> IP)	Device more		
Routing (IP -> KNX)			
	Monitoring of bus voltage	enable	
	IP-Address Assignment	automatic (DHCP)	
	OK Can	cel Default Info Help	

Device name	[free entry]		
The KNX PS640-IP can be assigned a name	of your choice. The device name should be		
descriptive (e. g. Line TF). It is used to searc	h for and recognize a device.		
Monitoring bus voltage failure	disable • enable		
If a KNX failure is detected, it is reported on	the IP. Return of the bus voltage is also		
reported.			
IP address assignment	automatic (DHCP) • manual		
Automatic (DHCP): The IP address is automatically assigned on the DHCP, i.e.			
additional settings are not required. To be able to use this function, there must be a			
DHCP server in the LAN (many DSL routers have an integrated DHCP server).			
Manual: In this case, the IP address, the sub	onet and the gateway IP address must be		
entered manually.			

IP configuration

1.1.0 KNX PS640-IP					
General		IP-Configuration 1			
IP-Configuration 1 IP-Configuration 2 Routing (KNX -> IP)	IP Routing Multicast addresse				
Routing (IP -> KNX)	Byte 1	224	×		
	Byte 2	0	*		
	Byte 3	23	A		
	Byte 4	12	×		
	IP-Address				
	Byte 1	0	*		
	Byte 2	0	×		
	Byte 3	0	*		
	Byte 4	0	*		
	ОК	Cancel Default Info H	elp		

IP Routing Multicast address		
Byte 1 / 2 / 3 / 4	0 255	
This address is used for routing telegrams on IP. The multicast IP address 224.0.23.12 was reserved (KNXnet/IP) at the IANA (Internet Assigned Numbers Authority) for this purpose. If a different multicast IP address is required, it must lie within the range of 239.0.00 to 239.255.255.255.		
IP address		
Byte 1 / 2 / 3 / 4	0 255	
This is the IP address of the KNX PS640-IP.		

1.1.0 KNX PS640-IP				X
General IP:Configuration 1	IP-Configuration 2			
IP-Configuration 2 Routing (KNX -> IP)	IP-Subnet			
Routing (IP -> KNX)	Byte 1		0	×
	Byte 2		0	•
	Byte 3		0	
	Byte 4		0	•
	IP-Gateway address			
	Byte 1		0	•
	Byte 2		0	•
	Byte 3		0	•
	Byte 4		0	•
		OK Cance	I Default Info Help	

IP subnet		
Byte 1 / 2 / 3 / 4	0 255	
Enter the subnet mask here. The device uses the values entered in this mask to determine whether there is a communications partner in the local network. If there is no partner in the local network, the device will not send the telegrams directly to the partner but to the gateway that routes the telegram.		
IP gateway address		
Byte 1 / 2 / 3 / 4	0 255	
Enter the IP address of the gateway here. Note: If the KNX PS640-IP will only be used in the local LAN, the entry of 0.0.0.0 can remain unchanged.		

Example of assigning IP addresses

A PC is to be used to access the KNX PS640-IP.IP address of the PC:192.168.1.30Subnet of the PC:255.255.255.0

The KNX PS640-IP is located in the same local LAN, i. e. it uses the same subnet. The subnet constrains the IP addresses that can be assigned. In this example, the IP address of the KNX PS640-IP must be 192.168.1.xx, where xx can be a number from 1 to 254 (with the exception of 30, which is already in use). It must be ensured that no numbers are assigned twice.

IP address of the KNX PS640-IP: 192.168.1.31 Subnet of the KNX PS640-IP: 255.255.255.0

Routing (KNX -> IP)

1.1.0 KNX PS640-IP				
General	Routing (KNX -> IP)			
IP-Configuration 1 IP-Configuration 2				
Routing (KNX -> IP)	Group telegrams (main groups 0 to 13)	filter 💌		
Routing (IP -> KNX)	Group telegrams (main groups 14 and 15)	route		
	Group telegrams (main groups 16 to 31)	block 💌		
	Individual addressed telegrams	filter 💌		
	Broadcast telegrams	route		
	Acknowledge (ACK) of group telegrams	only if routed		
	Acknowledge (ACK) of individual addressed telegrams	only if routed		
	OK Cancel	Default Info Help		

Group telegrams (main group 0 to 13)	block • route • filter			
Block: No group telegrams of this main group are routed to IP.				
Route: All group telegrams of this main grou	up are routed to IP independent of the filter			
table. This setting is for testing purposes on	ly.			
<i>Filter:</i> The filter table is used to check wheth	er or not the received group telegram			
should be routed to IP.				
Group telegrams (main groups 14 and 15)	block • route			
Block: No group telegrams of main groups 1	4 and 15 are routed to IP.			
Route: All group telegrams of main groups 1	I4 and 15 are routed to IP.			
Group telegrams (main groups 16 to 31)	block • route			
Block: No group telegrams of these main group	oups are routed to IP.			
Route: An additional page appears on which	the routing of main groups 16 to 31 can be			
disabled or enabled in pairs.				
Note: The group addresses of main groups 16 to 31 are reserved addresses that can be				
used for special applications (e.g. in Easy Mode). These group addresses are not				
available in the ETS.				
Physically addressed telegrams	block • route • filter			
Block: No physically addressed telegrams are routed to IP.				
Route: All physically addressed telegrams are routed to IP.				
<i>Filter:</i> The physical address is used to check whether the received physically addressed				
telegram should be routed to IP.				
Broadcast telegrams	block • route			
Block: No received broadcast telegrams are routed to IP.				
<i>Route:</i> All received broadcast telegrams are routed to IP.				

Acknowledge (ACK) of group telegrams always • only if routed

Always: An acknowledge is generated for every received group telegram (from KNX).*Only if routed:* An acknowledge is only generated for received group telegrams (from KNX) if they are routed to IP.Acknowledge (ACK) of physicallyalways • only if routed • answer with

addressed telegrams NACK

Always: An acknowledge is generated for every received physically addressed telegram (from KNX).

Only if routed: An acknowledge is only generated for received physically addressed group telegrams (from KNX) if they are routed to IP.

Answer with

NACK: Every received physically addressed telegram (from KNX) is responded to with NACK (not acknowledge). This means that communication with physically addressed telegrams on the corresponding KNX line is not possible. Group communication (group telegrams) is not affected. This setting can be used to block attempts at manipulation.

Routing (IP -> KNX)

1.1.0 KNX PS640-IP			
General	Routing (IP -> KNX)		
IP-Configuration 1 IP-Configuration 2 Roouting (KNX -> IP)	Group telegrams (main groups 0 to 13)	filter 💌	
Houting (IP -> NNX)	Group telegrams (main groups 14 and 15)	route	
	Group telegrams (main groups 16 to 31)	block	
	Individual addressed telegrams	filter 💌	
	Broadcast telegrams	route	
	Repetition of group telegrams	enable 💌	
	Repetition of individual addressed telegrams	enable 💌	
	Repetition of broadcast telegrams	enable 💌	
	OK Cance	al Default Info Help	

Group telegrams (main groups 0 to 13)block • route • filterBlock: No group telegrams of these main groups are routed to KNX.Route: All group telegrams of this main group are routed to KNX independent of thefilter table. This setting is used for testing purposes only.Filter: The filter table is used to check whether the received group telegram should berouted to KNX.

Group telegrams (main groups 14 and 15)	block • route				
Block: No group telegrams of main groups 14 and 15 are routed to KNX.					
Route: All group telegrams of the main grou	Route: All group telegrams of the main groups 14 and 15 are routed to KNX.				
Group telegrams (main groups 16 to 31)	block • route				
Block: No group telegrams of these main gr	oups are routed to KNX.				
Route: An additional page appears on which	n the routing of main groups 16 to 31 can be				
disabled or enabled in pairs.					
Physically addressed telegrams	block • route • filter				
Block: No physically addressed telegrams a	re routed to KNX.				
Route: All physically addressed telegrams a	re routed to KNX.				
Filter: The physical address is used to check	whether the received physically addressed				
telegram should be routed to KNX.					
Broadcast telegrams	block • route				
Block: No received broadcast telegrams are	routed to KNX.				
Route: All received broadcast telegrams are	routed to KNX.				
Resending of group telegrams	block • route				
Disable: The received group telegram is not resent to KNX in case of a fault.					
Enable: The received group telegram is rese	ent up to three times in case of a fault.				
Resending of physically addressed	block • route				
telegrams					
Disable: The received physically addressed telegram is not resent to KNX in case of a					
fault.					
Enable: The received physically addressed telegram is resent up to three times in case					
of a fault.					
Resending of broadcast telegrams	block • route				
<i>Disable:</i> The received broadcast telegram is not resent to KNX in case of a fault.					
Enable: The received broadcast telegram is	<i>Enable:</i> The received broadcast telegram is resent up to three times in case of a fault.				

ETS Connection Manager

If the IP configuration of the KNX PS640-IP is valid, the router can be used as an interface to KNX. To use this function, select the "Communication" tab under Extras -> Options in the ETS (version 3.0c and higher):

Options				X
Database	Presentation	Strategy	Communication	Troubleshooting
Select Co	mmunication In	terface:	Configu	re Interfaces
USB				~
Te	est			
Settir	ngs	Prompt wh	nen connecting	
Problem Analysis				
	ок	Abbreche	n Übernehme	n Hilfe

Click **Configure interfaces...** to open the ETS Connection Manager.

Create a new connection.

If the connection is to be used for *Tunnelling*, select "KNXnet/IP" under Type:

The ETS has direct access to the particular line with this protocol. Communication via IP takes place with a defined device here. The ETS automatically searches for all KNXnet/IP devices and displays them. Select the required device. This device will take over the function of the bus interface. Access to devices in other lines is possible.

If the connection is to be used for **Routing**, select "KNXnet/IP Routing" under Type: With this protocol, the ETS does not communicate with a certain device, but directly accesses the routing telegrams. The routing protocol is not suitable for access to an installation via internet.

Configured Connections	Properties-	
KNXnet/IP	Name: S	Serial PEI16 - COM1
USB New Delete	Type: k	(NXnet/IP
	K	NXnet/IP NXnet/IP Routing
	Communic F	RS.232 Standard RS.232 FT1.2 P (FIRIih/IP)
	(P)' indicate	es programming mode active
	00-50-C2-5	5-00-00 (190.190.190.35)
	MAC addr.:	00:50:C2:55:00:00
	Name:	00-50-C2-55-00-00
	IP address:	190.190.190.35
	Port:	3671 NAT mode
		KNXnet/IP Diagnostic Wizard

To be able to access KNX, the KNX PS640-IP requires an additional physical address. This second physical address is only used for bus access and must be set up separately: Select the "Communication" tab under Extras -> Options in the ETS. The communications interface is the connection that is currently configured. Click on **Settings...** to open the following window:

Local Interface Settings			
Use the following settings to configure the local interface. It is important that these settings are correct.			
Mask version:	\$091A		
Individual Address:	0.0.0	Is this address free?	

Enter a physical address of your choice. This address should lie in the same topological line but should not be in use by another device.

A dummy device may have to be added to the ETS project to reserve this address.