



KNX Capacitive Colour Touch Panel

ZVI-Z41LIT
ZVI-Z41PRO
ZVI-Z41COM

Application Program Version Z41 Pro / Z41 Lite: [3.1.0]

Application Program Version Z41 COM: [1.0.0]

User Manual Version: [3.1.0]_b

www.zennio.com

CONTENTS

Contents	2
Document Updates	5
1 Introduction	7
1.1 Z41 Pro / Z41 Lite / Z41 COM	7
1.2 Functionality.....	9
1.3 Installation.....	11
1.3.1 Firmware Updates.....	13
2 Configuration.....	15
2.1 Menu Page	15
2.2 General-Purpose Pages	16
2.3 Configuration Page.....	16
2.3.1 Device	20
2.3.2 Program Configuration (Z41 Pro and Z41 Lite)	21
2.3.3 Profile	22
2.3.4 Video Intercom Configuration (Z41 COM)	24
2.4 Screen Orientation	26
2.5 Screensaver	27
2.5.1 Screensaver image charging.....	27
2.6 Welcome Back Object	28
2.7 Welcome Greeting	28
2.8 Backlight.....	28
2.9 Security.....	29
2.10 Page Shaping	30
2.11 Translations.....	31
2.11.1 Import and export translations	31
2.12 Video Intercom (Z41 COM)	33
2.12.1 Video Intercom Control.....	33
2.12.2 Incomming Call.....	36
2.12.3 Ongoing Call	37
3 ETS Parameterisation	38

3.1	Default Configuration.....	38
3.2	Main Configuration	42
3.2.1	General	42
3.2.2	Translations	45
3.2.3	Backlight	46
3.2.4	Screensaver	48
3.2.5	Welcome Back Object	49
3.2.6	Welcome Greeting	50
3.2.7	Calendar	52
3.2.8	Security.....	53
3.2.9	Touch Lock.....	55
3.2.10	Internal Temperature Sensor	56
3.2.11	Ethernet (Z41 Pro and Z41 COM)	57
3.2.12	Firmware Update	58
3.2.13	Video Intercom (Z41 COM)	59
3.2.14	NTP (Z41 Pro and Z41 COM).....	60
3.3	Video Intercom <i>n</i> (Z41 COM)	61
3.4	Menu	64
3.4.1	Configuration.....	64
3.5	Page <i>n</i>	66
3.5.1	Configuration.....	66
3.5.2	Box <i>i</i>	67
3.6	Configuration Page.....	123
3.6.1	Configuration.....	123
3.6.2	Device	123
3.6.3	Program Configuration.....	125
3.6.4	Profile	125
3.6.5	Video Intercom Configuration (Z41 COM)	126
3.7	Thermostat <i>n</i>	128
3.8	Inputs (Z41 Pro and Z41 Lite)	129
3.8.1	Configuration.....	129
3.8.2	Binary Input.....	129
3.8.3	Temperature Probe.....	130

3.8.4 Motion Detector..... 130

3.9 Status After Programming and Bus Failure 131

ANNEX I. Remote Control via IP (Z41 Pro and Z41 COM)..... 132

 Configuring Z41 Pro Z41 Pro / Z41 COM 132

 Pairing Procedure..... 133

 ‘Push’ Notifications 135

 Remote Applications 136

ANNEX II. Communication Objects of Z41 Lite and Z41 Pro 137

ANNEX III. Communication Objects of Z41 COM 149

DOCUMENT UPDATES

Version	Modifications	Page(s)
[3.1.0]_b	Changes in the application program: <ul style="list-style-type: none"> - Synchronize Time/Date via NTP (Z41 Pro / Z41 COM). - Video Intercom (Z41 COM) 	-
	Video Intercom (Z41 COM)	24-25, 33-37, 59, 61-63, 121-122, 126-127
	Synchronize Time/Date via NTP (Z41 Pro / Z41 COM).	60
	Minnor texts changes.	-
[3.1.0]_a	Changes in the application program: <ul style="list-style-type: none"> - Translations - Backlight brightness level - Screensaver - Welcome back object - Welcome Greeting - Update objecte - Security for boxes - 14-byte indicators - New controls: Macro, Scheduler, Logic Function and Page Direct Link. 	-
[2.3.0]_a	Changes in General Configuration: <ul style="list-style-type: none"> - Screen Orientation 	-
[2.2.0]_a	Changes in the application program: <ul style="list-style-type: none"> - Twelve general-purpose control pages. - Holiday calendar. - Water/gas monitor. - Four-byte indicators. - Error log. - Light intensity regulation on RGB / RGBW 	-

	controls. <ul style="list-style-type: none">- Fan speed control.- New outline of the Configuration page.	
[1.1.0]_a	Changes in the application program: <ul style="list-style-type: none">- Remote control via LAN¹.	-

¹ Only in Z41 Pro.

1 INTRODUCTION

1.1 Z41 PRO / Z41 LITE / Z41 COM

Z41 Pro, Z41 Lite y Z41 COM are the easily and intuitively controllable high-performance **colour touch screens** from Zennio. The built-in features and functions make them the ideal solution for integral room control in hotels, offices or any other environments where controlling climate systems, lighting systems, shutters, scenes, etc. is required.

The main differences between Z41 Lite, Z41 Pro and Z41 COM are indicated in the following table:

Functionality	Z41 Lite	Z41 Pro	Z41 COM
Analogue-digital inputs	✓	✓	✗
Ethernet Interface:			
- Firmware update via Ethernet.	✗	✓	✓
- Synchronize Time/Date via NTP.			
- Remote control,			
Video Intercom.	✗	✗	✓
Battery (internal clock without power)	✓	✓	✗

Table 1. Differences between Z41 Lite, Z41 Pro and Z41 COM

The most outstanding features of Z41 Pro, Z41 Lite and Z41 COM are:

- **4.1 inch** backlit **capacitive** touch panel.
- User interface with various pre-set **colour patterns** and themes.
- Multiple **direct action functions**, fully customisable.
- Control distribution across up to **12 customisable pages**.
- **Video Intercom** function compatible with **GetFace IP** (Only in Z41 COM).
- Full **climate** management.
- Programmable **timers**.

- **Holiday calendar.**
- **Scene control.**
- **Alarm control.**
- **Macros.**
- **Schedulers.**
- **Logic functions.**
- **Direct links** to other pages.
- **Screensaver** with custom image.
- **Multi-Language.**
- 2 independent **thermostats.**
- Built-in **temperature** sensor.
- 2 customisable analogue-digital **inputs** (Only in Z41 Pro and Z41 Lite).
- **Ethernet interface** for firmware updates and for the control of the device from **remote IP applications** (Only in Z41 Pro and Z41 COM).
- **Elegant** design, available in various **colours.**

1.2 FUNCTIONALITY

Versions 2.0 and later of the Z41 Pro / Lite / COM application program feature the following functions:

- **12 General-Purpose Pages**, with up to 8 Fully-Customisable Boxes each, which the integrator may configure as indicators or controls.

- **Indicators:**

- Binary (icon or text).
- Enumerated (icon or text).
- Unsigned integer (2 / 4 bytes)
- Signed integer (1 / 2 / 4 bytes).
- Scaling (percentage).
- Floating point (2 / 4 bytes)
- Text (14 bytes).

- **1-button Controls:**

- Binary (pre-set value; switch; hold & release; short press, long press...).
- Unsigned integer (1 / 2 bytes).
- Signed integer (1 / 2 bytes).
- Scaling (percentage).
- Floating point (2 bytes).
- Scene (run / save).

- **2-button Controls:**

- Binary (icon, text, number).
- Enumerated (icon, text).
- Unsigned integer (1 / 2 bytes).
- Signed integer (1 / 2 bytes).
- Percentage (Scaling).
- Floating point (2 bytes).
- 2 scenes (run / save).
- Shutters.
- Light dimming.

- **Climate Specific Controls:**

- Temperature Setpoint control.
- Mode (cool/heat or extended).
- Special modes
- Fan.

- **Other Controls:**

- RGB.
- RGBW.
- Energy or Water/gas consumption.
- Daily / Weekly timer.
- Chrono-thermostat.
- Alarm.
- Holiday calendar.
- Macro.
- Scheduler.
- Logic function.
- Page direct link.
- Video Intercom (Only in Z41 COM)

- **1 Configuration Page** (optional), which contains the time/date settings, the calibration of the built-in temperature probe, the alarm, error and/or call log and the contrast & brightness adjustment, among others.

Notes:

- *Z41 Pro / Lite / COM supports Latin, Arab, Chinese, Korean, Japanese, Greek, Cyrillic and Hebrew characters for the on-screen, customisable labels. However, only certain combinations are possible within the same parameterisation:*
 - *Latin and Arab characters,*
 - *Latin, Chinese, Korean and Japanese characters,*
 - *Latin, Greek, Cyrillic and Hebrew characters*
- *Texts parameterised in ETS that may show in Z41 must comply with the UTF-8 codification format.*

1.3 INSTALLATION

Figure 1 shows the connection outline of the device:

1. **Internal temperature probe.**
2. **KNX connector.**
3. **Input connectors.**
(Only in Z41 Pro and Z41 Lite)
4. **Battery.**
(Only in Z41 Pro and Z41 Lite)
5. **Prog./Test button.**
6. **Prog./Test LED.**
7. **Ethernet connector**
(Only in Z41 Pro and Z41 COM).
8. **Magnet.**
9. **Mini-USB connector.**
10. **External power supply.**




Figure 1 Schematic diagram.

Z41 Pro / Lite / COM is connected to the KNX bus through the built-in terminal (2). An external **DC power supply** (12v / 24v / 29v) which delivers at least 150 mA of current is also required. The KNX power and the external power must be electrically isolated and provided by separate supplies, in order to avoid interference to the KNX bus. This external power must be supplied to the device through the corresponding terminal (10) provided within the original packaging, ensuring that each cable is properly connected and respecting the electrical polarities –positive and negative– from the supply to the device.

In addition to the external supply, Z41 Pro / Lite makes use of a **button battery**, located at the corresponding slot (4), to help maintain the time and date updated in case of a failure of the external power supply.

Note: *immediately after connecting the external supply, the device will perform an automatic calibration, which may result deviated if it takes place while any type of pressure is being made over the front panel. In case of an unexpected behaviour in touch recognition, it will be necessary to disconnect and connect the device back, avoiding making pressure over the panel, in order to perform a new calibration.*

After the connection of the external power supply, the screen will blink for an instant. A few seconds later, a **welcome screen** containing the Zennio logo and the “Loading...”

label will be shown. Once the load process ends, the **Status page** will come up (see Figure 2).



Figure 2 Status Page.

This screen is divided into boxes, which contain the following information:

- The **“KNX”** box shows the individual address assigned to the screen (in case of no assignment or no bus connection, this will show as “x.x.x”).
- The **“Software”** box will show empty in absence of an application program. In general, it will indicate if the download software is correct (“OK”) or if it is found to be corrupt due to download issues (“ERROR”).
- The **“Sync”** box shows, as a percentage, the progress of the internal synchronisation of the device during the start-up. Once it reaches 100%, the Status page will disappear and the Menu page will come up.
- The **“Ethernet”** box (only in Z41 Pro and Z41 COM) shows the IP address assigned to the device, provided that an Ethernet cable has been attached (7) and the network is running a DHCP server
- Last, the **“SW Version”** box shows the version of the firmware currently loaded to the device.

The Status page will also show up during bus failures in case the external power (12-24-29v) is not interrupted.

Note: *although the device will not turn functional until it is powered with the external supply, the KNX bus power should be enough to perform downloads from ETS (application program, group addresses, etc.).*

A short press on the **Prog./Test button** (5) will make the device enter the programming mode. The **Prog./Test LED** (6) will then light in red. On the contrary, if this button is held while the device gets connected to the bus, Z41 Pro / Lite / COM will enter the **safe mode**. In such case, the programming LED will blink in red colour.

Firmware updates (see section 1.3.1) can be performed through the Mini-USB (9) and Ethernet (7) connectors. It is important to take into account that USB memories must be formatted in FAT32.

For detailed information about the technical features of Z41 Pro / Lite / COM, as well as on security and installation procedures, please refer to the device **Datasheet**, bundled within the device packaging and also available at www.zennio.com.

1.3.1 FIRMWARE UPDATES

This device incorporates **two separate microcontrollers**. One of them is focused on interfacing with the KNX bus and on running the application program itself, while the second one is dedicated to running the firmware that implements the operating system and the management of the peripherals.

Therefore, updating Z41 Pro / Lite / COM may consist in two stages:

- Downloading the new **application program** (from ETS),
- Downloading the new **firmware**. There are two methods available:
 - Connect a **flash memory USB drive** to the Mini-USB port (see 9 in Figure 1), through the proper adapter cable.
 - In the particular case of Z41 Pro and Z41 COM, it is also possible to perform this update via Ethernet (see 7 in Figure 1).

For further details on the update process, please refer to the “**Firmware update**” specific document, available at www.zennio.com.

Note: *firmware updates do not re-set the consumption, alarm and error logs, nor does it clear the on-screen user configuration. For further information please consult section 3.9.*

Important: *firmware updates via USB can be disabled in parameters (see section 3.2.12). Please bear in mind that if such possibility is left disabled and a new version of the application is downloaded before having updated the firmware to the corresponding version, then it will not be possible to re-enable it unless the application program is reverted to the version that corresponds to the current firmware version.*

In other words: the device does not apply any further parameter changes in case of a version mismatch between the application program and the firmware. Therefore, it is always advisable to update the firmware (which will imply having the USB option already enabled, if necessary) prior to updating the application program.

2 CONFIGURATION

2.1 MENU PAGE

The user interface is organised into **pages** (up to twelve different pages, in addition to the Configuration page), each of which can be accessed from the **Menu page**, which (unless the contrary has been parameterised) is automatically shown after the start-up.



Figure 3 Menu Page (example).

As Figure 3 shows, the access to the pages is provided by a set of icons, which may show other (smaller) icons overlaid, such as an **exclamation** or a **lock**. Exclamations reflect that there are active alarms (see epigraph 3.5.2.5.7 in section 3.5.2.5) within the page, while a lock reflects that the access to the page is password-protected (see section 3.2.8), which also applies to the Configuration page.

All the twelve pages are **general-purpose**, at the entire disposal of the integrator, who may include up to 8 controls/indicators (with different functionalities) per page, being even possible to combine alarm, climate or any other controls within the same page. The remaining **Configuration** page is specific-purpose, as it is provided for user customisation of the device.

The user interface permanently shows a top bar (containing the name of the current page as well as the current time of day and temperature) and a **button at the bottom** of every page to get back to the Menu page:



Figure 4 Menu button.

2.2 GENERAL-PURPOSE PAGES

The integrator can make use of up to 12 general-purpose pages, each of which can host up to 8 different indicators or controls (with no restrictions for combining them) which will show inside the pages, automatically distributed or not, according to page parameterisation. For more details on the box distribution, refer to section 2.10.

The configurable control parameters for the general-purpose pages and their behaviour will be described in detail in section 3.

2.3 CONFIGURATION PAGE

The Configuration page lets the user know or adjust certain technical values about the device, as well as customise the visual and audio adjustments of the user interface:




Figure 5 Configuration Page.

The specific controls that can be enabled for the Configuration page are:

- **Date/Time:** even though the device implements two communication objects (see section 3.1) for setting the internal time and date from an external device,

they can also be adjusted (if such option has been enabled by parameter) directly from the user interface.

Pressing this button pops up a set of controls to let the user set the current hour (0-23), minutes, day, month and year.




Figure 6 Time Set Control.

Notes:

- *Z41 Pro / Lite incorporate an internal clock powered by a battery (see section 1.3). Therefore, time/date is not lost after downloads or reboots.*
- *Z41 COM has no battery, so it is recommended to enable the NTP functionality (see section 3.2.14) or to obtain the date and hour externally, through the bus.*
- *In Z41 COM, having the date and time updated is very important, so that the data of the call log entries of the video intercom are reliable. This is particularly important when there are several Z41 COM synchronized in the installation. It is recommended that all of the Z41 obtain the date and hour from the same source.*
- **Device:** button that provides access to a set of device-specific controls, such as the programming button or the reset button. For further details please refer to section 2.3.1.
- **Program Configuration** (only in Z41 Pro and Z41 Lite): button that provides access to the program information window, which shows the current version of the application program and the individual address. For further details please refer to section 2.3.2.

Note: *In Z41 COM, the information of “Program Configuration” will be shown in the “Device” window.*

- **Alarm Log:** button that provides access to the log file where alarm events are incorporated as soon as they occur. This centralised file may be useful when the user needs to check the status of a set of alarm controls distributed across several pages.

Hence, the alarm log will contain a listing, in reverse chronological order, where the name, time and date of every alarm event will be shown. In addition, the log will show the current status of each of them, which may be:

- **“ON”:** the alarm is still active or has not been acknowledged by the user.
- **“OK”:** the user has acknowledged the alarm event, but the corresponding object is still in the alarm state.
- **“OFF”:** the user has acknowledged the alarm event and the corresponding object has already left the alarm state.




Figure 7 Alarm Log

For more information on alarms, see epigraph 3.5.2.5.7 in section 3.5.2.5.

- **Profile:** button that permits entering the visual and audio settings of the user interface. For further information please refer to section 2.3.3.
- **Error Log:** button that provides access to the log file where any errors that may arise during normal operation of the device will be incorporated chronologically.




Figure 8 Error Log.

The following error types will be registered into the log:

- KNX bus failure: labelled as “**KNX**”.
- External power failure: labelled as “**Reboot**”.
- Loss of LAN connectivity (Z41 Pro / COM): labelled as “**Network**”.
- Loss of WAN connectivity (Z41 Pro / COM): labelled as “**Internet**”.
- Inconsistent firmware / application program versions: labelled as “**Version Mismatch**”. See section 1.3.1.
- Loss of remote control service connectivity (Z41 Remote) (Z41 Pro / COM): labelled as “**Remote Control**”.

The dialogue will look quite similar to the **alarm log**, as illustrated in the above figure. One text line with the following fields will be shown per registered error:

- **Date** (format yyyy/mm/dd).
- **Time** (format hh:mm:ss).
- **Error Type:**
 - KNX.
 - Reboot.
 - Network.
 - Internet.
 - Version Mismatch.
 - Remote Control.

- **Probe Calibration:** control for setting a certain correction over the values thrown by the internal temperature probe. This way, if the value of the measurement is found to be slightly over (or below) the actual temperature due to external factors, the final user will have the option to set an adjustment of between -5.0°C and +5.0°C, in steps of 0.1°C. In addition, it is possible to set an initial value for such correction by parameter.

Note: any changes made to the calibration of the internal probe will be applied once the next measurement takes place. Therefore, they may not be perceived immediately.

- **Device Pairing** (only in Z41 Pro / Z41 COM): button for entering the device pairing function, which needs to be run prior to be controlling the device from a remote IP application. See ANNEX I. Remote Control via IP for more details about controlling Z41 remotely.
- **Video Intercom Configuration** (Only in Z41 COM): button for entering to the video intercom sound adjustments page, such as ringtone, volume and “Do Not Disturb” mode.

The labels of the controls in the Configuration page, as well as the title of the page itself, are customisable in ETS. Moreover, it is possible to make any of the described controls stay hidden for the final user. These details are explained in section 2.11, together with the entire parameterisation process.

2.3.1 DEVICE

The following controls may be found in the Device screen, although they can be disabled in parameters:




Figure 9 Configuration. Device.

- **Programming Button:** control/indicator that shows the status of the Prog./Test LED of the device. In particular, it permits entering/leaving the programming

mode as by pressing the actual programming button of the device (see 0) in case the rear side of Z41 Pro / Lite / COM cannot be accessed.

- **Reset:** holding this button for a few seconds (i.e., a long press is required) sets the device back to a certain state, which can be set in ETS:
 - **“Parameters Reset”:** similar to restoring the device to the just-parameterised state, with the subsequent reset of the object values, alarm controls, timers, etc.
 - **“Z41 Reboot”:** simple device reset, with no data loss.
 - **“Parameters Reset and Z41 Reboot”:** the above two, combined.

Note: *alarm logs, consumption logs or any other logs are not reset to zero in any case. Nevertheless, the “ETS Reset Device” option does reset any adjustment performed by the final user from the Profile and Configuration pages (excepting the time / date, which is controlled by an internal clock).*

In Z41 COM, in addition, the indicators listed in the section 2.3.2 can be enabled in this page, as shows the following figure:



Figure 10 Configuration. Device

2.3.2 PROGRAM CONFIGURATION (Z41 PRO AND Z41 LITE)

The indicators that can be enabled for the Program Configuration window are:

- **KNX:** indicator that reflects the current individual address of the device within the KNX installation.

- **Program version:** indicator that shows the version of the device and, on the right, of the application program currently installed on the device. See section 1.3.1 for more details.
- **IP Address** (only in Z41 Pro / Z41 COM): indicator showing the IP address of the device. The IP address can be static or dynamic, assigned for a DHCP server.
- **MAC Address** (only in Z41 Pro / Z41 COM): indicator showing the MAC address of the device.




Figure 11 Configuration. Program Configuration.

Note: In Z41 COM this indicators can be found in the Device window (see section 2.3.1)

2.3.3 PROFILE

It is possible to enable the following controls for the Profile page:




Figure 12 Configuration. Profile (Left: Z41 Lite / Z41 Pro, right: Z41 COM).

- **Contrast.**
- **Brightness.**

- **Theme:** desired colour combination, among eight different options:



Figure 13 Themes

- **Melody** (Z41 Lite and Pro): desired tune (among three different options) for the beeps emitted on button presses or as a feedback on action executions. One more possibility is to make these beeps silent (alarm beeps will still sound).
- **Volume** (Z41 COM): in Z41 COM, instead of melody, the lower left box will control the volume of the beeps. There are three volume levels, apart from the mute option.

Note that the labels of the controls in the Profile page, as well as the title of the page itself, are customisable in ETS. Moreover, it is possible to make any of the described

controls remain hidden for the final user. These details are explained in section 2.11, together with the entire parameterisation process.

2.3.4 VIDEO INTERCOM CONFIGURATION (Z41 COM)

Only in Z41 COM the Video Intercom function is available. In its configuration page there are four controls and two indicators, as shown in the following figure:



Figure 14 Video Intercom Configuration

- **Ringtone:** Desired tune reproduced when receiving a call. There are three different ringtones.
- **Ringtone Volume:** Control to select the ringtone volume when receiving a call. There are five levels available and the mute option.
- **“Do Not Disturb” Mode: Enabling:** When enabled, incoming calls will not be received neither notified when attended from another Z41 COM linked to the same GetFace IP. However, new entries will be saved in the call log.

When enabling the mode, the value ‘1’ is sent through the object “[Video Intercom] “Do Not Disturb” Mode” and when disabling it is sent the value ‘0’.

Note: if “Do Not Disturb” mode is enabled during a call, the call will go on normally and the “Do Not Disturb” mode will be activated when the call finishes.

- **“Do Not Disturb” Mode: Timing:** Countdown to disable do not disturb mode. If set to 0 this mode will be active indefinitely.

When enabling the mode, the value ‘1’ is sent through the object “[Video Intercom] “Do Not Disturb” Mode” and when the timing expires it is sent the

value '0'. It is also possible to stop the countdown by manually disabling the mode (or through the communication object).

- **IP Address:** IP address to be indicated to the external video intercom unit (GetFace IP) to establish communication with Z41 COM. It is set by parameter (see section 3.2.13).
- **Gateway:** Gateway of the video Intercom (GetFace IP), set by parameter (see section 3.2.13).

2.4 SCREEN ORIENTATION

By default, all figures in this manual show a vertical arrangement of the device. However, it is also possible to set a horizontal orientation (see section 3.2.1):



Figure 15 Horizontal orientation

In the case of a horizontal arrangement, page titles can be configured as **two separate text lines**, instead of as only one:



Figure 16 Page title

Therefore, the current page label (at the bottom right in Figure 15) will make better use of the available space. However, the boxes that provide access to the pages will always show a sole text line by concatenating both texts (with a blank between them) and stretching accordingly so the whole text can fit, as in the “Laundry Room” box in Figure 15.

2.5 SCREENSAVER

The screensaver is a special page that will only be shown after a period of inactivity, configurable by parameter.

It is possible to configure the screensaver to show the current **Time**, the current **Temperature** (selecting the desired measurement source: the internal temperature sensor or an external value), **both** or an **image** uploaded via USB (see section 2.5.1).

The screensaver will disappear when touching the screen (also when the illumination mode or the language changes).

Note: *when showing the welcome greeting (see section 2.7), screensaver will not become active.*

2.5.1 SCREENSAVER IMAGE CHARGING

To upload a screensaver image just need to be copied into an USB memory device and connect it to the USB connector of Z41. The image must fulfil the following requirements:

- It has to be a JPEG image (file extension “.jpg”).
- The image name must be “**screensaver**”, without capital letters.
- The product of the width by the height of the image in pixels should not exceed 2.5 megapixels.
- The USB memories must be formatted in FAT32.

If there was already a screensaver image in Z41, the image will be overwritten.

If the image resolution is greater than the screen's, the image will be resized. To obtain an ideal visualization it is recommended to choose an image which has the same aspect ratio than the screen, depending on the parameterized orientation.

2.6 WELCOME BACK OBJECT

Z41 Pro / Lite / COM can send a specific object (the *welcome back object*) to the KNX bus when the user presses a touch button after a significant amount of time since the last press. Sending it or not can also depend on an **additional, configurable condition** consisting in the evaluation of up to five binary objects.

The welcome back object can consist in a **one-bit** value or a **scene** value (or both), depending on the parameterisation.

2.7 WELCOME GREETING

This function permits showing the user a welcome message of up to four lines of text on the display, each of which can be object-dependant or set in parameters.

When a “1” is received through the welcome greeting one-bit object, the display will become blank and show the welcome text. The same will happen if any of the 14-byte objects that define the text lines receives a new value from the bus.

2.8 BACKLIGHT

It is possible to configure brightness user-defined levels for the display of Z41 Pro / Lite / COM. Two operation modes are available: the **normal mode** and the **night mode**. The second one is optional. It is provided for temporary situations and environments where an excess of brightness may disturb the user. In such cases, it will be possible to switch the mode by means of a one-bit object and/or a scene object.

In order to prevent unnecessary power consumption while the device is idle, the backlight of the screen is partially faded out after a few minutes without any user interaction. After that, if the inactivity persists for a few more minutes, the backlight is completely turned off. While partially or totally faded out, any press on the screen will bring back the normal light level.

The timings for the above behaviour may differ in case a pop-up window is open, as well as depending on the configuration set in parameters (see section 3.2.3 for details).

2.9 SECURITY

It is possible to configure one or two different passwords, so the integrator can afterwards configure whether the access to a page or box will be protected by one password or another, or remain unprotected – every page can be independently configured. Figure 17 shows the “enter password” dialog shown to the user when trying to access a protected page.




Figure 17 Password Insertion Dialog (for password-protected pages)

In case of setting up **two levels**, the first one is assumed to be *enclosed* by the second one. This means that whenever the device asks the user to type password #1 (to enter a certain page); password #2 will also be accepted. On the contrary, password #1 cannot be used instead of password #2. This behaviour permits, therefore, making password #2 available to users with further privileges while password #1 is assigned to users with fewer privileges.

Moreover, when accessing to a protected page, all the boxes and pages with the same or lower access level of the introduced password, are automatically unlocked. It can be set if the elements are relocked after a time period or a page switch.

2.10 PAGE SHAPING

Each of the pages of the user interface –including Menu and Profile– can be independently parameterised to display its control/indicator boxes statically distributed or automatically ordered.

- **Static (grid) Distribution:** all the eight boxes of the page will be shown, remaining empty those not having been assigned a function.




Figure 18 Static Distribution

- **Automatic Distribution:** the active boxes will be dynamically ordered, so that they make use of all the available space. The final distribution of the page will therefore depend on the number of boxes with a function assigned.




Figure 19 Dynamic Distribution of the enabled boxes

2.11 TRANSLATIONS

Texts shown on the screen can be translated into up to five different languages. Switching from language to another can be done through two types of communication objects:

- **A one-byte object.** The values expected by this object are fixed from 0 to 4, to select the corresponding language. When receiving the value of a non-enabled language, the main language will be activated. When the received value is out of range, the active language remains unchanged.
- **A two-byte ASCII object.** The values expected by this object are two ASCII code characters corresponding to the ISO 639-1 standard. When receiving the value of a non-enabled language, the main language is selected.

Note: please refer to http://en.wikipedia.org/wiki/List_of_ISO_639-1_codes for a table with the language codes

The language corresponding to the texts introduced in ETS must be indicated by means of a parameter and will be the one shown by default (main language).

Translations should be uploaded to the device through an external USB memory. The desired language can be selected by means of the mentioned communication object. If the value does not correspond to any language the current language will be maintained.

2.11.1 IMPORT AND EXPORT TRANSLATIONS

The translations will be saved in “.xlf” files in the Z41. After a download, the ETS parameterized texts will be the ones in the main language (or language 0 file), and it will be overwritten.

Other languages files will have to be generated externally and, afterwards, uploaded to the Z41. For this purpose, it will be possible to export and import languages via USB. Only 1 to 4 languages can be imported and only the main language or language 0 can be exported. The next requirements must be fulfilled:

- **Export:** it must be created an **empty** folder named “*lang_export*” on the root directory of a pen drive and connect it to the Z41. A file named “*text-dflt_0.xlf*”, with all the parameterised texts in ETS will be created in the mentioned folder.

- **Import:** it must be created another folder named “*lang_import*” containing the files with extension “.xlf” of the desired languages to incorporate. The files names should follow the nomenclature “*text-xx_n.xlf*”, where “xx” must be the two letters code from the ISO-639-1 rule, and “n” the number associated to the translation. For example, “*text-es_1.xlf*” would be language 1 corresponding to Spanish. Once the translations are finished, plug in the USB to the Z41, and the translations will be imported automatically.

Notes:

- *The duration of actions to import/export translations via USB can become 1 min. During this time there should be no interruptions on the connection.*
- *The USB memories must be formatted in FAT32.*
- *After partial download, the .xlf file for the main language is overwritten, but not for the other languages.*
- *Translations files should not include the characters <’ or &’. Their escape symbols should be used instead: ‘& lt;’ and ‘&’, respectively.*

For texts translations, it is recommended to use a translation management tool such as OLT (Open Language Tool), to facilitate the translation process with ‘.xlf’ files.

2.12 VIDEO INTERCOM (Z41 COM)

Z41 COM, through its Ethernet connection, will be able to receive calls and show images from the camera of a Zennio video intercom outdoor unit, **GetFace IP**. Moreover it is possible to open the door and a call log will be available for each video intercom configured.

Up to 4 video intercoms are available in a Z41 COM, each one controlling up to 3 doors, for a total of up to 12 doors controllable by one Z41 COM. GetFace IP is responsible for controlling the doors locks.

On the other hand, one GetFace IP can make a call to a maximum of 8 Z41 COM at a time. There is a communication object to synchronize the call logs of the Z41 COM connected to the same GetFace IP when the call is accepted or rejected by one of them.

For more information about the Zennio GetFace IP, his parameterisation and the network configuration, please refer to the user manual of this device.

The following sections detail the functions and controls available in the pop ups of Z41 COM related to the functionalities of the video intercom.

2.12.1 VIDEO INTERCOM CONTROL

There hay two types of video intercom: community or private.

The community video intercom only has access to the call log. However, the private video intercom can access to the visualization of the images of the camera of the outdoor unit (GetFace IP) at any time, without receiving a call.

2.12.1.1 CALL LOG

A box configured as a Video Intercom (see section 3.5.2.5.13) has a button to access to a **Call Log**.

An example of a Call Log is shown in the Figure 20. Every entry contains the firs image captured by the video intercom camera, the number of the entry and the date and hour of the call reception, as well as whether the call has been attended or not. In case of the image cannot be captured, a default image will be shown (see Figure 21).




Figure 20 Video Intercom. Call Log




Figure 21 Video Intercom. Call Log. Default Image



The attended calls, considering attended calls the accepted and the rejected calls and those where the door has been opened from the incoming call dialog, are represented by the icon  , and the not attended ones by the icon  . Moreover, if there is a not attended call since the last time the call log was accessed, the indicative icon appears on the button to access the call log, as shows the following figure.



Figure 22 Video Intercom. Not attended call.

If several Z41 COM are associated to the same GetFace IP, it is required a synchronization between them to prevent inconsistent data in the call log. This synchronization is carried out by notifying the actions performed in a Z41 COM via communication object. When another Z41 COM receives, through the mentioned object, a call has been accepted or rejected from another device, a message will be displayed for a short time (see Figure 23). These messages can be changed by parameter (see section 3.2.2)




Figure 23 Video Intercom. Synchronisation messages

2.12.1.2 VIEWING IMAGES FROM THE CAMERA

When a Video Intercom is parameterised as **private**, another button is available to access to the camera visualization page. In this page it is possible to open the doors. (see Figure 24).




Figure 24 Video Intercom. Camera Visualization Page.

2.12.2 INCOMMING CALL

The interface of the Z41 during an incoming call is as shown in the Figure 25.

It comprises: the camera images visualization, the buttons for accept or reject the call, the buttons to open the doors, the button to silence the call and the exit button.




Figure 25 Video Intercom. Incoming Call

During an incoming call, the functions available are:

- **Reject Call:** the call dialog is closed and the synchronisation object is sent to the bus to notify others Z41 COM linked to the same GetFace IP. The call is registered as attended. The GetFace IP does not manifest the call rejected, so the call continues from the point of view of the visitor.
- **Accept Call:** opens the ongoing call dialog (see section 2.12.3 for details) and the synchronisation object is sent to the bus to notify others Z41 COM linked to the same GetFace IP. The call is registered as attended
- **Open Door:** sends the command to open the door through a communication object or/and through a HTTP command (it is possible to enable secure opening with username and password), as parameterised. Besides the synchronisation object is sent to the bus to notify others Z41 COM linked to the same GetFace IP. The call will continue but is saved in the log as attended. Up to three buttons can be enabled to open up to three doors.

Note: *It is possible to configure automatic door opening when receiving a call (see section 3.2.13)*

- **Exit:** the incoming call dialog is closed but no notification is sent to the bus, so the call will continue in the others Z41 COM.
- **Mute Call:** mutes the call ringtone and the synchronisation object is sent to the bus to mute the others Z41 COM linked to the same GetFace IP.

2.12.3 ONGOING CALL

When accepting the call, the ongoing call dialog pops up, as shown in Figure 26:




Figure 26 Video Intercom. Established Call

During an ongoing call, i.e. a call accepted the voice communication with the GetFace IP starts. The functions available are:

- **Reject Call:** ends the communication and closes the ongoing call dialog.
- **Open Door:** sends the command to open the door through a communication object or/and through a HTTP command (it is possible to enable secure opening with username and password), as parameterised.

Note: *It is possible to configure automatic door opening when receiving a call (see section 3.2.13).*

- **Speakers Volume:** up to 5 levels of volume available plus level 0 or mute. The selected value is saved to apply in future calls.
- **Mute Microphone:** toggles between mute and enable the microphone.
- **Exit:** equivalent to reject call button.

3 ETS PARAMETERISATION

To begin with the parameterisation of the device, once the ETS program is running it is necessary to import the product database (Z41 Pro, Z41 Lite or Z41 COM application programs). Next, the device is added to the project. The configuration process begins by entering the Parameters tab of the device.

The next sections explain the ETS parameterisation of the device in depth.

Note: *the amount of characters permitted for text parameters (labels, etc.) by ETS may differ depending on whether they contain special characters (symbols, accents...) coded with more than one byte. It is advisable to verify that these texts fit properly on the screen, with independence of whether they reach the maximum text length allowed by ETS or not.*

Important: *whenever the device is updated to a new version of the application program from ETS, it is also necessary to update the firmware of the secondary microcontroller (responsible for the operating system; see section 1.3.1) in case an updated version exists. If the installed versions of the application program and the firmware do not match, the device may not work correctly (the Software box in the Status page will show the word "Error").*

3.1 DEFAULT CONFIGURATION

This section illustrates the default initial state of the device.

1	[General] Time	Current Time	3 bytes	C	R	W	T	U	time of day
2	[General] Date	Current Date	3 bytes	C	R	W	T	U	date
3	[General] Scenes: Send	Scene Value	1 byte	C	-	-	T	-	scene control
4	[General] Scenes: Receive	Scene Value	1 byte	C	-	W	-	-	scene number
5	[General] Internal Temperature	Current Temperature (Built-in Sensor)	2 bytes	C	R	-	T	-	temperature (°C)
7	[General] Select Language	0 = Main; 1 = Lang. 2; ...; 4 = Lang. 5	1 byte	C	-	W	-	-	
8	[General] Select Language	Language Selection Through ISO 639_1 Two Letters Code	2 bytes	C	-	W	-	-	language code (ASCII)
9	[General] Illumination	0 = No Action; 1 = Light Display	1 bit	C	-	W	-	-	acknowledge
11	[General] Touch Lock	0 = Unlocked; 1 = Locked	1 bit	C	-	W	-	-	enable
23	[Profile] Brightness	0-100%	1 byte	C	-	W	-	-	percentage (0..100%)
24	[Profile] Contrast	0-100%	1 byte	C	-	W	-	-	percentage (0..100%)
25	[Profile] Volume	0-100%	1 byte	C	-	W	-	-	percentage (0..100%)
26	[Profile] Theme	0 = Ocean; 1 = Sky; 2 = Night; 3 = Twilight; 4 = Egg Shell;...	1 byte	C	-	W	-	-	

Figure 27 Default Configuration.

The general objects enabled by default are:

- **[General] Time:** 3-byte object for setting the internal time of the device, for example, by linking it to a KNX clock. This object also allows read requests, so the current time of the device can be checked. It is also automatically sent after time changes made by the user from the screen itself.

Note: *although the DPT of this object considers a field for setting the day of the week, Z41 Pro / Lite / COM calculates it from the date and therefore ignores that field.*

- **[General] Date:** 3-byte object for setting the internal date of the device, for example, by linking it to a KNX clock. This object also allows read requests, so the current date of the device can be checked. It is also automatically sent after date changes made by the user from the screen itself.
- **[General] Scene: Receive** and **[General] Scene: Send:** objects for respectively receiving and sending scene values from/to the KNX bus whenever it is necessary (e.g., when the user touches a button that has been configured to send scene commands; see section 3.5.2.2).
- **[General] Internal Temperature:** 2-byte object through which the value of the current measurement of the built-in sensor will be sent to the bus, according to the parameterisation (see section 3.2.10).
- **[General] Select Language:** 1 and 2-byte objects for changing the language showed in the screen when receiving a value through the bus (see section 3.2.2)
- **[General] Illumination:** 1-bit object that, after the reception of the value “1” from the bus, will bring the backlight of the screen to the maximum level, while the reception of the value “0” will have no effect. This maximum illumination will last for a certain time, according to the explanation in section 2.8.
- **[General] Touch Lock:** 1-bit object that, after the reception of the value “1” from the bus, will lock the touch panel so that user presses are ignored from that moment. Touch locking will be interrupted as soon as the value “0” is received through this object. See section 3.2.9.
- **[Profile] Brightness:** 1-byte object for changing the screen brightness level when receiving a value through the bus (1-100%).

- **[Profile] Contrast:** 1-byte object for changing the screen contrast level when receiving a value through the bus (1-100%).
- **[Profile] Melody:** 1-byte object for changing the melody when receiving a value through the bus (0-2 for selecting the melody and 3 for muting).
- **[Profile] Theme:** 1-byte object for changing the theme when receiving a value through the bus (0-7).

During the parameter configuration, a screen similar to Figure 28 will be shown.




Figure 28 Parameter Screen shown by default

As shown in Figure 28, the parameter window is initially divided into several main tabs:

- **Main Configuration**, which contains a few more tabs:
 - General,
 - Translations,
 - Backlight,

- Calendar,
 - Security,
 - Touch Lock,
 - Internal Temperature Sensor,
 - Ethernet (Z41 Pro and Z41 COM),
 - Firmware Update.
 - Video Intercom (only in Z41 COM)
- **Menu**, which contains one more screen by default:
 - Configuration, from which it is possible to activate and configure each of the general-purpose pages of the device (see section 2.2).
 - **Configuration Page**, which itself will contain the following tabs:
 - Configuration, from which it will be possible to activate and configure the Configuration page (see section 2.3).
 - Device, which allows enabling and configuring the controls of the Device screen (see section 2.3.1).
 - Profile, which allows enabling and configuring the controls of the Profile screen (see section 2.3.3)

The following sections will detail the parameterisation process of each of the above tabs, including the initially hidden screens, which will become visible depending on the selected options.

3.2 MAIN CONFIGURATION

This tab is divided into multiple screens, all of which contain a set of global parameters regarding the general functionality of the device, and therefore not specifically related to a particular page of the user interface.

3.2.1 GENERAL

The General screen contains the following parameters:

Figure 29 General (Main Configuration)

- **Power Supply Voltage:** lets the integrator specify the particular voltage of the external supply powering Z41 Pro / Lite / COM. The available values are “12” (by default), “24” and “29” volts. Selecting one option or another will only cause an internal correction over the temperature value measured by the built-in probe.
- **Screen Orientation:** sets the desired on-screen orientation: “Vertical” or “Horizontal” (see section 2.4).

- **Default Theme (after programming):** permits selecting the user interface colour scheme (out of 8 different options) to be loaded after the ETS download. The final user will have the option to switch the scheme from the Profile window of the Configuration page (see section 2.3.3), unless such option is disabled by parameter.
- **Show Time:** sets whether the current time (according to the internal clock) should show in the upper left corner of every page. The default is “Yes”.
- **Show Temperature:** sets whether the current temperature should show or not in the upper right corner of every page, being necessary in such case to choose the source of the temperature value: “Internal temperature probe” or “External value”. If the latter is chosen, an object named **[General] External temperature** will be enabled, so that it can be grouped with any other object that sends temperature values.
- **Screensaver:** enables or disables the “Screensaver” tab in the tree on the left. See section 3.2.4 for details.
- **Welcome back object:** enables or disables the “Welcome back” tab in the tree on the left. See section 3.2.5 for details
- **Welcome greeting:** enables or disables the “Welcome greeting” tab in the tree on the left. See section 3.2.6 for details.
- **Update Objects:** enables the sending of read requests to update status objects and indicators. There are four options available, some of them with a configurable **delay**:
 - “Disabled”: no read request, therefore objects are not updated.
 - “After Programming”: read requests are sent after a complete or partial download (or when pressing the reset button in the configuration page, if set as “Parameters Reset”, see section 3.6.2).
 - “After Reset”: read request are sent when a reset occurs (bus failure or the Reset Device ETS option), after the parameterised **delay** (0-65535 s).
 - “After Programming and Reset”: combination of the two above options.
- **Synchronize Time/Date via NTP** (only in Z41 Pro and Z41 COM): when enabled, the device will update the time and date obtained from the

parameterised NTP server and time zone. This functionality is only available in Z41 Pro and Z41 COM. See section 3.2.14.

- **Time/Date Sending Period:** when enabled (value different from zero), whenever the device is restarted, the date and time objects (“**[General] Date**” and “**[General] Time**”) will be sent to the bus, and thereafter, they will be sent again every time the period expires. Setting a new time to the device either through object or from the date/time configuration window will not restart the count of the sending period. Range: [0-65535] x 1 min. The default value is 10 min.

Note: *to prevent time lags, it is advisable to only have one master clock within the installation. Having multiple devices overwriting each other their time and date registers periodically may end up inducing delays.*

- **Thermostat 1:** checkbox (unselected by default) that activates/deactivates the Thermostat 1 parameter screen. See section 3.7.
- **Thermostat 2:** idem for Thermostat 2. See section 3.6.5.
- **Inputs** (only in Z41 Pro and Z41 Lite): checkbox (disabled by default) to show/hide the additional Inputs screen. See section 3.8.

3.2.2 TRANSLATIONS

This screen entails certain aspects in relation to the texts languages shown on the display.

Figure 30 Translations (Main Configuration)

- **Main language:** read-only parameter to make it evident that the main language is always enabled.
 - **Select language:** list of the available languages.
- **Language X:** enables or disables the additional language X.
 - **Select language:** list of available languages to select the language X.
- **Label for “X”:** sets certain labels showed in boxes of type macro, scheduler, logic functions or video intercom (see section 3.5.2.5).

Only the Main language is enabled by default.

While Translations stays enabled, the following objects are visible:

- “[General] Select language” (one-byte).
- “[General] Select language” (two-byte).

These objects work accordingly to the behaviour mentioned in section 2.11.

After download, the main language is loaded.

3.2.3 BACKLIGHT




Figure 31 Backlight (Main Configuration)

This screen entails certain aspects in relation to the backlight of the display.

- **Normal Mode:** enabled by default.
 - **Backlight Level:** display brightness percentage (0-100%).
 - **Backlight Attenuation:** lets defining whether the backlight should behave during inactivity according to section 2.8 (“Turn Off the Screen after a Long Time of Inactivity”), or if on the contrary the screen should never turn off entirely (“Attenuate the Screen after a Long Time of Inactivity”) or not even attenuate the light level (“Max illumination always”).

Notes:

- *This parameter is not available when the screensaver is enabling. However it is possible to configure an attenuation when the screensaver activates (see section 3.2.4)*

- *Maintaining the default option is encouraged. Permanent illumination may affect adversely the device lifetime, and is only intended for special circumstances.*
- **Night Mode:** in case of being this mode necessary, this checkbox needs to be marked, which will incorporate some new parameters:
 - **Backlight Level:** display brightness percentage (0-100%).
 - **Change Theme:** lets select the theme when night mode is active. Options: “No change” or any of the available themes (see section 2.3.3).

In case of enabling the night mode, some more options can be configured to carry out the backlight mode control:

- **Control Object: 1-Bit:** when marked, it will be possible to switch the mode by writing to a binary object (“**[General] Illumination**”). It is possible to select which value should trigger which mode (“0 = Normal Mode; 1 = Night Mode” or “0 = Night Mode; 1 = Normal Mode”).
- **Control object: Scene:** when marked, it will be possible to switch the mode by writing a certain scene value to “**[General] Scene: Receive**”. Two specific textboxes will show up to enter what scenes (1 through 64) will trigger each mode.
- **Backlight Mode after ETS download:** sets which of the two modes (“Normal Mode” or “Night Mode”) will be active after an ETS Download.
- **Light Up when the Screen is Pressed:** allows changing temporarily the brightness level when the screen is touched in night mode.
 - **Backlight Level after Touch:** display brightness percentage (0-100%).
 - **Length of Lighting:** when the time set in this parameter elapses, Z41 Lite / Pro / COM will switch to Night Mode (provided that it was not already in this mode). The range is 1 to 65535 seconds (10 by default).

3.2.4 SCREENSAVER

After enabling “Screensaver” from “General” screen (see section 3.2.1), a new tab will be incorporated into the tree on the left.




Figure 32 Screensaver (Main Configuration)

This screen contains the following parameters:

- **Activation timeout:** time to automatically show the screensaver after the last button touch. Range: 1 – 255 seconds, minutes or hours.
- **Attenuate Display:** sets whether to decrease the display brightness when showing the screensaver.
- **Time/Date:** sets whether to show the current time or not.
- **Temperature:** sets whether to show the current temperature or not. When enabled, the following parameter will show up:
 - **Taken from:** defines the source of the temperature value: “Internal sensor” or “External reference”. The latter will bring a new two-byte object to the project topology (“**[General] Screensaver - External temperature**”) so that it the device can receive the required values from the bus.
- **Image:** sets whether to show the screensaver image (see section 2.5).

Note: The Screensaver will not appear if the Welcome Greeting is shown.

3.2.5 WELCOME BACK OBJECT

After enabling “**Welcome Back Object**” (see section 3.2.1), a new tab will be incorporated into the tree on the left.

– MAIN CONFIGURATION	Time to Activate the Welcome Object	1
GENERAL		h
Translations	Additional Condition	No Additional Condition
Backlight	Welcome Back Object (1-Bit)	<input type="checkbox"/>
Welcome Back Object	Welcome Back Object (Scene)	<input type="checkbox"/>
Calendar		
Security		
Touch Lock		
Internal Temp. Sensor		
Ethernet		
Firmware Update		
+ MENU		
+ Configuration Page		

Figure 33 Welcome Back Object (Main Configuration)

- **Time to Active the Welcome Object:** sets the minimum time (1 to 255 seconds, 1 to 255 minutes, or 1 to 255 hours) that should elapse after the last button touch before the next one trigger the execution of the welcome back function.
- **Additional Condition:** sets if sending the welcome back object should also depend on an external condition. The option by default is “No Additional Condition”. The following are available too:
 - Do not send unless all additional conditions are 0: the welcome back object will only be sent if all the condition objects are found to have the value “0”.
 - Do not send unless all additional conditions are 1: the welcome back object will only be sent if all the condition objects are found to have the value “1”.

- Do not send unless at least one of the additional conditions is 0: the welcome back object will only be sent if at least one of the condition objects is found to have the value “0”.
 - Do not send unless at least one of the additional conditions is 1: the welcome back object will only be sent if at least one of the condition objects is found to have the value “1”.
- **Welcome Back Object (1 Bit)**: checkbox to enable the sending of a 1-bit value (through “[General] Welcome back”) when the welcome back function is triggered and the condition (if any) evaluates to true. The desired value (0 or 1) should to be set in “Value”.
 - **Welcome Back Object (Scene)**: checkbox to enable the sending of a scene run request (through “[General] Scene: send”) when the welcome back function is triggered and the condition (if any) evaluates to true. The desired scene number (1 through 64) should to be entered in “Value”.

3.2.6 WELCOME GREETING

After enabling “Welcome greeting” (see section 3.2.1), a new tab will be incorporated into the tab tree. A one-bit object named “[General] Welcome Greeting” will also be shown in the project topology, to trigger the welcome message by sending the value “1”.




Figure 34 Welcome Greeting (Main Configuration)

This screen (Figure 34) contains the following parameters:

- **Line X:** sets whether the corresponding text line will be pre-defined (“Fixed”) or object-dependent (“Received from text object”).

If “Fixed” is selected, the following parameter will appear:

- **Text:** textbox to enter the desired text for the corresponding line.

The 14-byte object “[**General**] **Welcome Greeting – Line X**” will be shown up to four times, depending on how many text lines have been assigned the option “Received from text object”.

With a parameterisation as the one shown in Figure 34, if “Mr. Marshall” is received through the “[**General**] **Welcome Greeting – Line 2**” object, the display will show the following message:




Figure 35 Welcome greeting message example.

3.2.7 CALENDAR

This screen entails certain aspects in relation to the following controls: Calendar, Daily Timer, Weekly Timer and Chrono-Thermostat (see section 3.5.2.5).

Parameter	Value
First Weekday	Monday (selected), Sunday
Default Labels (Main Language)	
Weekdays Initials [e.g. MTWTFSS]	MTWTFSS
January Label	JANUARY
February Label	FEBRUARY
March Label	MARCH
April Label	APRIL
May Label	MAY
June Label	JUNE
July Label	JULY
August Label	AUGUST
September Label	SEPTEMBER
October Label	OCTOBER
November Label	NOVEMBER
December Label	DECEMBER

Figure 36 Calendar (Main Configuration)

The parameters involved are:

- **First Weekday:** sets the first weekday in the calendar. The options are “Sunday” and “Monday” (default option).
- **Weekdays Initials (Mon... Sun):** permits customising the label that will represent each of the weekdays on the screen. A seven-character string (including letters or numbers), ordered according to the above First Weekday parameter, must be entered – each of the characters will represent one weekday. The default value is “MTWTFSS”, which stands for the day names in English.
- **Label for “X”:** sets the label that will represent the twelve months of the year. Their default values are the English names.

3.2.8 SECURITY

This screen permits selecting how many security levels (one or two) will be available for the configuration of the access to the control pages or the boxes.

Figure 37 Security (Main Configuration)

The parameters on the Security screen are:

- **Security Levels:** dropdown list for selecting whether one (default option) or two security levels will be available. Depending on the selection, the parameter below (Password) may show once or twice.

Note: with independence of the option selected here, it will be necessary to establish the security level desired for each specific page of controls.

- **Protect again:** sets when is re-activated the security of pages or boxes unlocked. The options are: "After a Time Period", "After a Page Switch" or "After a Time Period or a Page Switch" (by default). When selecting the first or the last option, a new parameter **Time** appears to set the time period (from 10 to 655350 seconds).
- **Password:** parameter made of four additional textboxes, each of which should contain one of the four consecutive digits (0-9) that will compose the password. The default password is "1234".

In case of enabling two security levels, the Password parameter will show twice, being the first one referred to the password of Level 1, and the second one to the password of Level 2. The default password for Level 2 is “5678”.

Section	Parameter	Value
Security Levels	One Level / Two Levels	Two Levels
Protect again	Protect again	After a Time Period or a Page Switch
Time	Time	6 x 10s
LEVEL 1 PASSWORD	- Default Password (1)	1
	- Default Password (2)	2
	- Default Password (3)	3
	- Default Password (4)	4
LEVEL 2 PASSWORD	- Default Password (1)	5
	- Default Password (2)	6
	- Default Password (3)	7
	- Default Password (4)	8
SECURITY PAD LABELS	- Label for "Password 1"	Password 1
	- Label for "Password 2"	Password 2
	- Label for "Error"	ERROR
	- Label for "New Password"	New Password
	- Label for "Repeat Password"	Repeat Password
	- Label for "Updated"	Updated

Figure 38 Two Security Levels

Important: *the password insertion dialog features a specific option (lower left button) that lets the user change, in runtime, the passwords originally set by parameter. After accessing this option and prior to typing the new password, the user will be required to type the corresponding old password (level 1 or level 2). Note that although it will be possible to type password 2 even if the device asks for password 1, the new password typed afterwards will be anyway stored as the new password for level 1.*

- **Security Pad Labels:** parameter consisting in six additional textboxes, intended for the customisation of the messages that the device shows (or may show) when the user interacts with the password insertion dialog. Up to 15 characters are permitted per label.

- **Label for “Password 1”:** message shown when the user is required to type in the password for level 1. By default, “Password 1”.

- **Label for “Password 2”**: message shown when the user is required to type in the password for level 2. By default, “Password 2”.
- **Label for “Error”**: message shown to the user when the typed password is not valid. By default, “ERROR”.
- **Label for “New password”**: message shown to ask the user for a new password, during the password change process. By default, “New password”.
- **Label for “Repeat password”**: message shown when the user is required to re-type the new password. By default, “Repeat password”.
- **Label for “Updated”**: message shown to the user as a confirmation of the password change. By default, “Updated”.

Buttons that lead to a protected page or box will show a little lock icon overlaid on their lower left corner.

3.2.9 TOUCH LOCK




Figure 39 Touch Lock (Main Configuration)

This screen is provided for the configuration of the “welcome” and “touch lock” objects. Contains a single parameter:

- **Touch Locking:** dropdown list with the following options: “0=Unlocked; 1=Locked” (default value) and “0=Locked; 1=Unlocked”. Depending on the selection, sending one value or another (“0” or “1”) to object **[General] Touch lock** will lock/unlock the touch panel. The detailed behaviour of this object is described in section 3.1.

3.2.10 INTERNAL TEMPERATURE SENSOR

MAIN CONFIGURATION	Temperature Sensor CALIBRATION	0	x 0.1 °C
GENERAL	Temperature Sending PERIOD (0 = Disabled)	0	x 10 s
Translations	Send with a Temperature Change (0 = Disabled)	0	x 0.1 °C
Backlight			
Calendar			
Security			
Touch Lock			
Internal Temp. Sensor			
Ethernet			
Firmware Update			
+ MENU			
+ Configuration Page			

Figure 40 Internal Temperature Sensor (Main Configuration)

This screen permits configuring the internal temperature sensor of the device. Three parameters are provided for this:

- **Sensor Calibration:** permits setting a certain correction over the values thrown by the internal temperature probe. This way, if the value of the measurement is found to be slightly over (or below) the actual temperature due to external factors, it is possible to set an adjustment between -5.0°C and 5.0°C (0.0°C by default), in steps of 0.1°C . The value set here may be optionally changed, in runtime, from the Configuration page (see section 2.3).
- **Sending Period:** cycle time (in tens of a second) for sending the value of the measured temperature to the bus. This sending is made through the **[General] Internal temperature** object (see section 3.1), enabled by default. The permitted values are 0 to 100 tens of a second. The value “0” (set by default) deactivates this sending to the bus.

- **Send with a Temperature Change:** permits performing a specific sending of the temperature value to the bus –through the **[General] Internal Temperature** object– whenever an increase or decrease greater or equal than a certain value is detected between two consecutive measurements, no matter if a periodic sending has been enabled or not. Such value (unsigned) must be entered here, in terms of tenths of a degree. To avoid having this extra sending on temperature changes, simply leave the default value (“0”).

3.2.11 ETHERNET (Z41 PRO AND Z41 COM)

The Ethernet tab permits configuring the Ethernet network interface of Z41 Pro or Z41 COM.

Therefore, from this parameter screen, it is possible to specifically enable the remote control function (see [ANNEX I. Remote Control via IP](#)) by marking the **Remote Control through the Internet** checkbox.




Figure 41 Ethernet (Main Configuration)

The parameters available are:

- **Remote Control through the Internet:** enables or disables the remote control function (see [ANNEX I. Remote Control via IP](#)).
- **Device Description:** gives a name to the device, so that it turns easier to identify it from the “Z41 Update” desktop application (which may detect other Z41 devices on the same local network), provided for performing firmware updates on Z41 Pro / COM through the Ethernet interface.

- **IP Address Assignment:** allows selecting whether the IP is set by the “DHCP” protocol or it is “Static” (only available in Z41 COM).

The Ethernet interface is also intended to let the integrator update the firmware of the device (see section 1.3.1) across a local network (alternatively, this process can be performed through the built-in USB interface). Note, however, that the parameters related to the firmware update (either via USB or via Ethernet) can be found in the **Firmware Update** tab (see section 3.2.12).

3.2.12 FIRMWARE UPDATE

This tab lets the integrator enable or disable the device firmware update function (see section 1.3.1) through the USB port. The only parameter is:




Figure 42 Firmware Update (Main Configuration)

- **USB Updating:** “Enabled” (default option) or “Disabled”.
- **Network Updating** (Z41 Pro / Z41 COM): “Enabled” (default option), “Disabled” or “Enabled (Password Protected)”. The latter brings the option to restrict the updates via Ethernet to those who can provide the required password to the update tool before the firmware download starts. This password, consisting in four numerical figures, needs to be set in ETS by the integrator.

Note: reading the specific user manual of the firmware update process available at the Zennio webpage is encouraged, as it contains particular remarks regarding the password protection.

3.2.13 VIDEO INTERCOM (Z41 COM)

In this tab is possible to set the Video Intercom network configuration as well as enabling the Video Intercoms.




Figure 43 Video Intercom. Main Configuration.

Z41 COM IP Configuration:

- **IP Address:** IP address to be indicated to the external video intercom unit (GetFace IP) to establish communication with Z41 COM.
- **Subnet Mask:** must match the mask of the network to which Z41 COM belongs.
- **Specify Gateway:** when enabled permits introduce a gateway. This parameter is required when GetFace IP is in a different network from Z41 COM.
- **Video Intercom n:** checkbox that enables a new tab with the same name in the left menu where each video intercom is configured (see section 3.3).

Note: When enabling and configuring a Video Intercom from “General”, the Z41 COM will receive calls but it is required necessary to parameterise a box as a Video Intercom to access his call log and also for the visualization of the image of the camera on private Video Intercoms. For further information see section 3.5.2.5.13.

3.2.14 NTP (Z41 PRO AND Z41 COM)

After enabling “**Synchronize Time/Data via NTP**” from “General” screen (see section 3.2.1), a new tab will be incorporated into the tree on the left.

The “**NTP**” tab allows configuring the time zone and NTP server to automatically update the internal clock of Z41 Pro / Z41 COM.




Figure 44 NTP (Main Configuration).

- **Time Zone:** dropdown list for selecting a time zone from the *Coordinated Universal Time (UTC)* standard. "(UTC) Coordinated Universal Time" is the default option, which corresponds to **GMT+00** (Greenwich Mean Time standard).
- **NTP Server:** NTP server for Z41 Pro / Z41 COM internal clock synchronization. "0.pool.ntp.org" is the default server, which belongs to NTP Pool Project's servers.

Note: it is recommended to use the specific server of the continental zone where the installation is. For example "0.europe.pool.ntp.org" for Europe or "uk.pool.ntp.org" for United Kingdom. Please refer to www.pool.ntp.org for further information.

3.3 VIDEO INTERCOM *n* (Z41 COM)

After enabling “**Video Intercom *n***” in the “Video Intercom” screen (section 3.2.13), a new tab will be incorporated into the tab tree.

Name	<input type="text"/>
Type	<input checked="" type="radio"/> Private <input type="radio"/> Community
The Outdoor Unit Is in a Different Network	<input type="checkbox"/>
Define ID	<input type="checkbox"/>
Number of Doors	1
Opening Settings	
HTTP command	<input checked="" type="checkbox"/>
Secure Opening	<input checked="" type="checkbox"/>
Username	<input type="text"/>
Password	<input type="text"/>
KNX Object	<input checked="" type="checkbox"/>
Object Value	<input checked="" type="radio"/> 1 = Open <input type="radio"/> 0 = Open
Automatic Door Opening	<input checked="" type="checkbox"/>
Door 1	<input checked="" type="checkbox"/>
Initial Status after ETS Download	<input type="radio"/> Disabled <input checked="" type="radio"/> Enabled
Disable if "Do Not Disturb" Mode Is Active	<input checked="" type="checkbox"/>

Figura 45 Video Intercom *n*. Configuration

The parameters available are:

- **Name:** title of the call dialogs and the call log.
- **Type:** “Private” or “Community”. The private type allows accessing at any time to the visualization of images from the camera of the outdoor unit. The community type does not.
- **The Outdoor Unit Is in a Different Network:** required when Z41 COM and GetFace IP are in different networks. When enabled, two parameters appear:
 - **Video Intercom ID:** numerical identifier of GetFace IP (field *Phone Number (ID)*).
 - **IP Address:** IP address of GetFace IP.
- **Define ID:** when enabled the following parameter appear:

- **Video Intercom ID:** numerical identifier of GetFace IP (field *Phone Number (ID)*).

If this parameter is not enabled or the video intercom ID is empty, it will be considered as a “free” video intercom, i.e., it will receive calls from any GetFace IP which knows the Z41 COM IP address.

Note: *This parameter is only available when the parameter **The Outdoor Unit is in a Different network** is disabled.*

- **Number of Doors:** up to 3 doors per Video Intercom.
- **Opening Settings**
 - **HTTP Command:** the order to open a door will be sent via a HTTP command. When enabled, the following parameters appear:
 - **Secure Opening:** allows setting a **username** and **password** required to send through the HTTP command to open the door in order to increase the security (must match with the ones set in GetFace IP).
 - **KNX Object:** the order to open a door will be sent via the communication object “[VI n] Switch X”, where X is the number of the door. It is possible to choose the **value of the object** that will open the door (“1 = Open” or “0 = Open”).
- **Automatic Door Opening:** allows opening the doors automatically when receiving a call.
 - **Door n:** door/s responding to the automatic opening.
 - **Initial Status after ETS Download:** sets whether the automatic opening is enabled or not after ETS Download. It also can be changed at runtime through the object “[VI n] Enable Automatic Door Opening”.
 - **Disable if “Do Not Disturb” Mode Is Active:** disables the automatic door opening when do not disturb mode mode is active.

On the other hand, when enabling a video intercom, the following objects are available, apart from the mentioned above:

- “[Video Intercom] Synchronization”: 14-Byte object for sharing information between different Z41 COM linked to the same GetFace IP. Therefore this object should be linked to the same group address in each Z41 COM that require to be synchronized.

Through this object is notified to the bus if a call has been attended, if it has been muted or if the call log has been consulted (for removing the notification in case there was a not attended call, see Figure 22).

- “[Video Intercom] “Do Not Disturb” Mode”: 1-bit object to activate or deactivate the do not disturb mode.
- “[Video Intercom] Ringtone”: 1-Byte object to change the ringtone. Three values available: 0 = Ringtone 1, 1 = Ringtone 2 and 2 = Ringtone 3.
- “[Video Intercom] Ringtone Volume”: 1-Byte object to change the ringtone volume (0-100%).
- “[Video Intercom] Incoming Call”: 1-bit object which is sent with value ‘1’ when Z41 COM receives a call.
- “[Video Intercom] Play Ringtone”: When this object receives the value “1”, the ringtone is reproduced one time.

3.4 MENU

The Menu tab contains only one screen, Configuration.

3.4.1 CONFIGURATION

+ MAIN CONFIGURATION	Title	<input type="text"/>
- MENU	Automatic Page Shaping	<input checked="" type="radio"/> No <input type="radio"/> Yes
CONFIGURATION	Default Page	Menu
+ Configuration Page	Page 1	<input type="checkbox"/>
	Page 2	<input type="checkbox"/>
	Page 3	<input type="checkbox"/>
	Page 4	<input type="checkbox"/>
	Page 5	<input type="checkbox"/>
	Page 6	<input type="checkbox"/>
	Page 7	<input type="checkbox"/>
	Page 8	<input type="checkbox"/>
	Page 9	<input type="checkbox"/>
	Page 10	<input type="checkbox"/>
	Page 11	<input type="checkbox"/>
	Page 12	<input type="checkbox"/>
	Configuration Page	<input checked="" type="checkbox"/>

Figure 46 Configuration (Menu) (Vertical)

If the screen orientation is set horizontally (see section 3.2.1), the title field is divided into two maximum 10-character fields (instead of one maximum 20-character field).

+ MAIN CONFIGURATION	Title (Line 1)	<input type="text"/>
- MENU	Title (Line 2)	<input type="text"/>
CONFIGURATION	Automatic Page Shaping	<input checked="" type="radio"/> No <input type="radio"/> Yes
+ Configuration Page	Default Page	Menu
	Page 1	<input type="checkbox"/>
	Page 2	<input type="checkbox"/>
	Page 3	<input type="checkbox"/>
	Page 4	<input type="checkbox"/>
	Page 5	<input type="checkbox"/>
	Page 6	<input type="checkbox"/>
	Page 7	<input type="checkbox"/>

Figure 47. Configuration (Menu) (Horizontal)

The Configuration screen, under the Menu tab, permits configuring the Menu page itself, as well as a set of general options related to the enabled pages of controls that can be accessed from the Menu page.

The parameters available are:

- **Title:** text field that defines the title that will be shown on the top of the Menu page.
- **Automatic Page Shaping:** dropdown list that allows choosing whether the boxes in the Menu page should be automatically distributed (option “Yes”) depending on the number of boxes configured, or be displayed as a static 2x4 grid (option “No”). See section 2.10.
- **Default Page:** dropdown list that sets the page (Menu, or any of the general-purpose pages) that will behave as the default page. This page will be the one shown after one minute of inactivity, assuming that such page has been enabled and it is not protected with password.

In addition, one checkbox is shown per general-purpose page (that is, pages 1 to 12), as well as one more checkbox for the Configuration page. Each of these checkboxes will allow enabling or disabling the corresponding page in the device – a specific ETS tab will appear upon the activation of a page.

3.5 PAGE *n*

When any of the general-purpose pages is enabled from the Configuration screen under the Menu tab, a new tab named **Page *n*** will appear, where *n* is the number of the page.

Under this tab, one screen (**Configuration**) will be initially displayed to let the integrator enable or disable each of the boxes in the page. Depending on that, more parameter screens will appear.

Note: figures in this section will show the parameters of a certain page (for instance, page 1) or a certain box (for instance, box 1). The parameters for other pages or boxes are totally analogous.

3.5.1 CONFIGURATION

+ MAIN CONFIGURATION	Title	<input type="text"/>
- MENU	Automatic Page Shaping	<input checked="" type="radio"/> No <input type="radio"/> Yes
CONFIGURATION	Icon	Home
- Page 1	Protected	No
Configuration	Box 1	<input checked="" type="checkbox"/>
Box 1	Box 2	<input type="checkbox"/>
+ Configuration Page	Box 3	<input type="checkbox"/>
	Box 4	<input type="checkbox"/>
	Box 5	<input type="checkbox"/>
	Box 6	<input type="checkbox"/>
	Box 7	<input type="checkbox"/>
	Box 8	<input type="checkbox"/>

Figure 48 Configuration (Page *n*)

This screen contains the following parameters:

- **Title:** text field that sets the title shown on the top of the Menu page.
- **Automatic Page Shaping:** dropdown list that allows choosing whether the boxes in the Menu page should be automatically distributed (option “Yes”) depending on the number of boxes configured, or be displayed as a static 2x4 grid (option “No”). See section 2.10.
- **Icon:** sets the icon that will represent the page in the Menu page.

Note: a list with all icons available can be found in document “Z41 Icon list”, available at www.zennio.com.

- **Protected:** sets whether the page will be password-protected or not. Depending on the security levels configured (one or two; see section 3.2.8) this list will contain the following options:

One level:

- **No:** the page will not be protected by password. All users can access it.
- **Yes:** the page will be protected by password. Users will be asked to type the password when trying to access it.

Two levels:

- **No:** the page will not be protected by password. All users can access it.
- **Level 1:** the page will implement security level 1. To access it, users will be required to enter password 1 or password 2.
- **Level 2:** the page will implement security level 2. To access it, users will be required to enter password 2.

Finally, eight checkboxes are provided to let the integrator enable or disable each of the eight boxes in the page. When enabled, every box will have its own parameter screen (**Box i**) under the corresponding **Page n** tab. The next section explains the parameterisation process of these boxes.

3.5.2 BOX i




Figure 49 Box i (Page n)

This screen contains the following parameters common to all type of boxes:

- **Label:** identifying title for the box.
- **Visualization:** box format, which may be: Indicator (default option; the box will simply work as a status indicator), 1-button control (the box will work as a one-button control), 2-button control (the box will work not only as a status indicator, but also as a two-button control), Climate control (the box will act as a climate indicator and a climate control) or Other (the box will implement some other functionality).

Depending on the Visualization type selected, the parameters below will change. The following sections explain the available parameters depending on the visualization type selected.

- **Protected:** sets whether the control will be password-protected or not (does not apply to indicator type boxes). Depending on the security levels configured (one or two; see section 3.2.8) this list will contain the following options:

One level:

- No: the box will not be protected by password. All users can access it.
- Yes: the box will be protected by password. Users will be asked to type the password when trying to access it.

Two levels:

- No: the box will not be protected by password. All users can access it.
- Level 1: the box will implement security level 1. To access it, users will be required to enter password 1 or password 2.
- Level 2: the box will implement security level 2. To access it, users will be required to enter password 2.

When selecting the protection to controls of type macro, logical function or scheduler, one more parameter appears:

The screenshot shows a configuration window with two sections. The first section is labeled 'Protected' and has two radio buttons: 'No' (unselected) and 'Yes' (selected). The second section is labeled 'Protect' and has two radio buttons: 'Both Buttons' (unselected) and 'Only Configuration Button' (selected).

Figure 50 Protection parameters of macro, logic function and scheduler controls.

- **Protect:** determines if the password protection will apply to both buttons (“Both Buttons”) or only o the configuration button (“Only Configuration Button”). The second case allows triggering the macro without the password restriction.

Important: macros will in any case allow setting actions corresponding to password-protected boxes (see section 3.5.2.5 for details about the configuration of these type of controls).

3.5.2.1 INDICATOR



Figure 51 Indicator (Box)

Boxes configured as indicators permit implementing a set of different functions. The desired function must be selected through the **Function** parameter. The available functions and the related parameters are:

3.5.2.1.1 Binary Indicator (Icon)

The box will behave as a binary state indicator. Each of the two states will be shown in the box through the selected icon. When this function is assigned to the box, the **[Pn][Bi] Binary indicator** communication object become available, as well as the parameters that permit selecting the icon to be displayed when the object acquires the value “0” (**Icon Off**) and the icon to be displayed when it acquires the value “1” (**Icon On**).

Visualization	Indicator
Function	Binary Indicator (Icon)
Off Icon	Off 1
On Icon	On 1

Figure 52 Binary Indicator (Icon)

Therefore, when the device receives the values “0” or “1” through the aforementioned object, the box will show one icon or another.

Note: a list with all icons available can be found in document “Z41 Icon list”, available at www.zennio.com.

3.5.2.1.2 Binary Indicator (Text)

The box will behave as a binary state indicator. Each of the two states will be shown in the box through a different label. When the box is assigned this function, the **[Pn][Bi] Binary indicator** object will become available, as well as the parameters that permit typing the text to be shown when the object receives a “0” (**Text Off**) and that to be shown when it becomes “1” (**Text On**).

Therefore, when the device receives the values “0” or “1” through the aforementioned object, the box will show one text or another.

Visualization	Indicator
Function	Binary Indicator (Text)
Off Text	<input type="text"/>
On Text	<input type="text"/>

Figure 53 Binary Indicator (Text)

3.5.2.1.3 Enumerated Indicator (Icon)

The box will behave analogously to the case of the Binary indicator, (Icon) however, it will be possible to distinguish up to 6 states (configurable through the **# Enums** parameter) instead of only two. The states will be determined by the reception of any values between 0 and 255, instead of only values 0 and 1.

Visualization	Indicator
Function	Enumerated Indicator (Icon)
# Enums	2
Value 1	0
Icon 1	Off 1
Value 2	0
Icon 2	Off 1

Figure 54 Enumerated Indicator (Icon)

When this function is assigned to the box, a 1-byte communication object, **[Pn][Bi] Enumerated Indicator**, will become available as well as two more parameters (**Value** and **Icon**) for each of the states to be distinguished. This allows setting which icon will be shown in the box upon the reception of which value through the communication object.

Example: a three-state enumerated indicator (“3” under “# Enum”) is parameterised as follows:

Value 1 = “1”	Icon 1 = “One”
Value 2 = “3”	Icon 2 = “Two”
Value 3 = “5”	Icon 3 = “Three”

When the **[Pn][Bi] Enumerated Indicator** object receives the value “1”, the box will show icon “One”. When it receives the value “3”, icon “Two” will be shown. And when it receives the value “5”, icon “Three” will show. In case of receiving any other value, no icon will be shown.

3.5.2.1.4 Enumerated Indicator (Text)

The box will behave analogously to the case of the Binary indicator (Text) however it will be possible to distinguish up to 6 states (configurable through the **# Enums** parameter) instead of only two. The states will be determined by the reception of any values between 0 and 255, instead only by values 0 and 1.




Figure 55 Enumerated Indicator (Text)

When this function is assigned to the box, one 1-byte communication object, **[Pn][Bi] Enumerated Indicator**, will become available as well as two additional parameters (**Value** and **Text**) for each of the states to be distinguished. This allows setting which

texts will be displayed in the box upon the reception of which values through the communication object.

3.5.2.1.5 Numerical Indicators




Figure 56 1-Byte Indicator (Unsigned Integer)

The remaining functions under Indicator are shown in Table 1. In all of these cases, the box will behave as a numerical state indicator that permanently displays the value of a certain communication object, which is enabled when the function is assigned to the box.

Function	Range	Related object
1-byte (unsigned int.)	0– 255	[Pn][Bi] 1-byte unsigned int indicator
1-byte (signed int.)	-128 – 127	[Pn][Bi] 1-byte signed int indicator
Percentage indicator	0% – 100%	[Pn][Bi] Percentage indicator
2-byte (unsigned int.)	0 – 65535	[Pn][Bi] 2-byte unsigned int indicator
2-byte (signed int.)	-32768 – 32767	[Pn][Bi] 2-byte signed int indicator
2-byte (floating point)	-671088.64 – 670760.96	[Pn][Bi] 2-byte float indicator
4-byte (signed integer)	-2147483648 – 2147483647	[Pn][Bi] 4-byte Signed Int Indicator
4-byte (floating point)	-3.403E-38 – 3.403E-38	[Pn][Bi] 4-byte Float Indicator

Table 1 Numerical indicators

The table also reflects the allowed value ranges and the name of the object for each case.

In all cases the integrator will be shown a text field (**Unit**), empty by default, that permits specifying the measuring units (up to 6 characters) of the displayed value. For percentage indicators, the symbol % always will be displayed as unit.

In the particular case of the floating point indicators (2-byte or 4-byte), the device will dynamically adjust the number of the decimal figures shown depending on the order of magnitude of the current value: two for values greater than 0 and lower than 0.1; one for values between 0.1 and 100; and none for other cases (and analogously for negative values).

All these numerical indicators incorporate an additional parameter, **Save Log?** In case of enabling this option (“Yes”), any changes in the value of the indicator will be continuously saved to an internal log file, so the final user can be afterwards offered a visual representation that reflects the chronological evolution of such value with several levels of detail, depending on the parameterisation:




Figure 57 Plot Zoom Levels

Boxes for which this option has been enabled will show a small icon overlaid on their upper left corner.




Figure 58 Indicator implementing the Log Function

Boxes showing this icon let the user press them, which will bring up a pop-up window similar to Figure 59.




Figure 59 Graphical representation of the Log File

The graph (where the vertical scale will dynamically adapt to the values being represented) shows the chronological evolution of the value, with higher or lower detail (hourly, daily, weekly or monthly, depending on the zoom levels enabled and on the level selected by the user through the on-screen magnifying glass control; see Figure 60). In the case of the lower detail levels, the graph will show the average values per time unit (day or month) as well as the maximum and minimum values.

Finally, the bin icon (lower right corner of the screen) lets the user, by performing a long press the contents will be deleted from the log file, thus setting the values of the monitor to zero.




Figure 60 Different Detail Levels (log file)

Note: large values (especially 2-byte and 4-byte values) may be rounded in order to make them fit on the screen. In some cases, the measuring units defined in parameters may show with a prefix (kilo, Mega, Tera, etc.).

3.5.2.1.6 14-Byte Text Indicator




Figure 61 14-byte text indicator

The box will show the text received through the communication object “[Pn][Bi] 14-Byte Text Indicator”.

Note: objects associated to the text indicator are stored in non-salved zone, so its value will not be maintained after a restart.

3.5.2.2 1-BUTTON CONTROL

Boxes configured as 1-button controls show one centred button and a title.




Figure 62 1-Button Control (Box)

The desired function must be selected through the **Function** parameter. The available functions and the parameters related to each are:

3.5.2.2.1 Binary Control

The central button of the box will react to user presses by sending a binary value to the bus through the [Pn][Bi] **Binary control** object, which turns visible as soon as this function is assigned to the box.




Figure 63 Binary control

On the other hand, **Action** permits setting what value will be sent to the bus through the mentioned object, and on what events. The options are:

- **Toggle**: pressing the button will cause an alternate sending of the values “1” and “0”. Particularly, on the first press one “1” will be sent; on the second, one “0”; on the third, one “1”; and so on.
- **0**: one “0” will be sent whenever the button is pressed.
- **1**: one “1” will be sent whenever the button is pressed.
- **Short 1 – Long 0**: short presses will cause the sending of the value “1”, while long presses will cause the sending of the value “0”.
- **Short 0 – Long 1**: inverse to the previous case.
- **Hold 0 – Release 1**: one “0” will be sent when the button press starts, and one “1” as soon as the button is released.
- **Hold 1 – Release 0**: one “1” will be sent when the button press starts, and one “0” as soon as the button is released.

Finally, the dropdown list next to **Button off** and **Button on** (or **Button (in the middle)** when only one value is sent) permits selecting the icon to be displayed inside the button for each value.

Note: a list with all icons available can be found in document “Z41 Icon list”, available at www.zennio.com.

3.5.2.2.2 Numerical Constant Controls




Figure 64 1-byte constant (unsigned int)

If the box is assigned any of the remaining “constant” control options, the central button in the box will react to user presses by sending a certain numerical value, which is required to be specified under **Constant value**.

Table 2 shows, for every available Function, the permitted value range and the name of the object through which the values are sent to the bus.

Function	Range	Object
1-byte constant (unsigned int.)	0 – 255	[Pn][Bi] 1-byte unsigned int control
1-byte constant (signed int.)	-128 – 127	[Pn][Bi] 1-byte signed int control
Constant percentage value	0% – 100%	[Pn][Bi] Percentage control
2-byte constant (unsigned int.)	0 – 65535	[Pn][Bi] 2-byte unsigned int control
2-byte constant (signed int.)	-32768 – 32767	[Pn][Bi] 2-byte signed int control
2-byte constant (float)	-671088.64 – 670760.96	[Pn][Bi] 2-byte float control

Table 2 Numerical constant controls

Finally, the dropdown list next to **Button (in the middle)** permits selecting an icon to be displayed inside the button.

Note: a list with all icons available can be found in document “Z41 Icon list”, available at www.zennio.com.

3.5.2.2.3 Scene Control




Figure 65 Scene control

In this case, the central button of the box will react to user presses by sending a scene value to the KNX bus through the **[General] Scenes: send** object, which is enabled by default. Parameter **Scene number** permits specifying the number of the scene (1 – 64) to be sent. Moreover, **Action** (which shows the options “Run” and “Run and save”) sets whether the device will only send scene execution orders (after a short press) or if it will

be possible, in addition to sending execution orders upon short presses, to send scene save orders in the case of a long press.

Finally, the dropdown list next to **Button (in the middle)** permits selecting an icon to be displayed inside the button.

Note: *a list with all icons available can be found in document “Z41 Icon list”, available at www.zennio.com.*

3.5.2.3 2-BUTTON CONTROL




Figure 66 2-button control (Box)

Boxes configured as 2-button controls consist in an indicator and two buttons that, when touched, trigger the sending of an action to the KNX bus through a certain object. This category also includes some specific controls such as **light dimming** and **shutter control**.

As a general rule, most of the 2-button controls permit configuring a pair of parameters, **Left button** and **Right button**, each containing a dropdown list for the selection of the icons to be displayed inside the buttons in the box.

Notes:

- *A list with all icons available can be found in document “Z41 Icon list”, available at www.zennio.com.*
- *When multiple presses are made consecutively on the buttons of a control that regulates (e.g. increases / decreases) the value of a certain variable, only the final value selected by the user will be sent to the bus, to prevent an unnecessary bus traffic due to all the intermediate values.*

On the other hand, the **Function** parameter contains a dropdown list for the selection of the particular two-button control type to be assigned to the box. The available options (and their related parameters) are:

3.5.2.3.1 Binary Control (Icon)

When the user touches the buttons, a binary value will be sent through the **[Pn][Bi]** **Binary control** object, while the status object, **[Pn][Bi]** **Binary indicator**, will determine the icon shown in the box.

Visualization	2-Button Control
Function	Binary Control (Icon)
Action	<input checked="" type="radio"/> Left 0, Right 1 <input type="radio"/> Left 1, Right 0
Off Icon	Off 1
On Icon	On 1
Left Button	Off 1
Right Button	On 1
Protected	<input checked="" type="radio"/> No <input type="radio"/> Yes

Figure 67 Binary Control (Icon)

The parameters available are:

- **Action:** sets the value to be sent on button touches. This can be “Left 0, Right 1” (by default) or “Left 1, Right 0”.
- **Off Icon** and **On Icon:** dropdown lists for the selection of the icons that will represent the two states (0 / 1) of the **[Pn][Bi]** **Binary Indicator** object, which gets automatically updated whenever an order is sent through the control object. It may also receive values from the bus.

3.5.2.3.2 Binary Control (Text)

Visualization	2-Button Control
Function	Binary Control (Text)
Action	<input checked="" type="radio"/> Left 0, Right 1 <input type="radio"/> Left 1, Right 0
Off Text	
On Text	
Left Button	Off 1
Right Button	On 1
Protected	<input checked="" type="radio"/> No <input type="radio"/> Yes

Figure 68 Binary Control (Text)

When the user touches the buttons, a binary value will be sent through the **[Pn][Bi] Binary Control** object, while the status object, **[Pn][Bi] Binary Indicator**, will determine the text that will be shown in the box.

The parameters available are:

- **Action:** sets the value to be sent on button touches. This can be “Left 0, Right 1” (default) or “Left 1, Right 0”.
- **Text Off** and **Text On:** indicative texts that will be shown in the box depending on the state (0 / 1) of the **[Pn][Bi] Binary Indicator** object, which gets automatically updated whenever an order is sent through the control object. It may also receive values from the bus.

3.5.2.3.3 Enumerated Control (Icon)

The box will behave analogously to the case of the Binary control (Icon) however it will be possible to distinguish up to 6 states (configurable through the **# Enums** parameter) instead of only two. The states will be determined by the reception of any values between 0 and 255, as the control (**[Pn][Bi] Enumerated Control**) and the status (**[Pn][Bi] Enumerated Indicator**) objects are not binary but 1-byte objects.

Visualization	2-Button Control
Function	Enumerated Control (Icon)
# Enums	2
Value 1	0
Icon 1	Off 1
Value 2	0
Icon 2	Off 1
Left Button	Arrow Left
Right Button	Arrow Right
Protected	<input checked="" type="radio"/> No <input type="radio"/> Yes

Figure 69 Enumerated Control (Icon)

The parameters available are:

- **# Enums:** number of states (up to 6) that will be distinguished. For every distinguished state, the parameters **Value** and **Icon** will become available, in

order to relate every significant value of the communication object to a certain icon that will represent it.

- **Value j** : numerical value (0 – 255) that will be sent through the control object when the user, after pressing the buttons, sets the control box to state j .
- **Icon j** : indicative icon that will be displayed in the box when the status object (which gets automatically updated whenever a control order is sent, although it may also receive values from the bus) acquires the numerical value defined in the above parameter.

3.5.2.3.4 Enumerated Control (Text)

The box will behave analogously to the case of the Binary control (Text) however it will be possible to distinguish up to 6 states (configurable through the **# Enums** parameter) instead of only two. The states will be determined by the reception of any values between 0 and 255, as the control (**[Pn][Bi] Enumerated Control**) and the status (**[Pn][Bi] Enumerated Indicator**) objects are not binary but 1-byte objects.

Visualization	2-Button Control
Function	Enumerated Control (Text)
# Enums	2
Value 1	0
Text 1	
Value 2	0
Text 2	
Left Button	Arrow Left
Right Button	Arrow Right
Protected	<input checked="" type="radio"/> No <input type="radio"/> Yes

Figure 70 Enumerated Control (Text)

The parameters available are:

- **# Enums**: number of states (up to 6) that will be distinguished. For every distinguished state, the parameters **Value** and **Icon** will become available, in order to relate every significant value of the communication object to a certain icon that will represent it.

- **Value *j***: value (0 – 255) that will be sent through the control object when the user, after pressing the buttons, sets the control box to state *j*.
- **Text *j***: indicative text that will be displayed in the box when the status object (which gets automatically updated whenever a control order is sent, although it may also receive values from the bus) acquires the numerical value defined in the above parameter.

3.5.2.3.5 Numerical Controls

If the box is assigned any of the six numerical functions, user touches over the buttons will trigger the sending of a certain numerical value to the bus (which will be progressively increased or decreased with every touch on one button or the other) through the control object, while the box itself will permanently reflect the current value of the status object (which gets automatically updated after a control order is sent, although it may also receive values from the bus).

Table 3 shows, for each of the six functions, the permitted value range and the name of the control and status objects.

Range	Control object	Status object
1-byte (unsigned int.)		
0 – 255	[Pn][Bi] 1-byte unsigned int control	[Pn][Bi] 1-byte unsigned int indicator
1-byte (signed int.)		
-128 – 127	[Pn][Bi] 1-byte signed int control	[Pn][Bi] 1-byte signed int indicator
Percentage control		
0% – 100%	[Pn][Bi] Percentage control	[Pn][Bi] Percentage indicator
2-byte (unsigned int.)		
0 – 65535	[Pn][Bi] 2-byte unsigned int control	[Pn][Bi] 2-byte unsigned int indicator
2-byte (signed int.)		
-32768 – 32767	[Pn][Bi] 2-byte signed int control	[Pn][Bi] 2-byte signed int indicator
2-byte (float)		
-671088.64 – 670760.96	[Pn][Bi] 2-byte float control	[Pn][Bi] 2-byte float indicator

Table 3 Numerical Controls

For all the six functions, the parameters available are:

Visualization	2-Button Control
Function	1-Byte (Unsigned Int)
Action	<input checked="" type="radio"/> Left Decrease, Right Increase <input type="radio"/> Left Increase, Right Decrease
Initial Value	0
Minimum Value	0
Maximum Value	255
Increment Short	1
Increment Long	10
Left Button	Minus
Right Button	Plus
Protected	<input checked="" type="radio"/> No <input type="radio"/> Yes

Figure 71 1-Byte (Unsigned Int.) 2-Button Control

- **Action:** sets which of the two buttons will increase the current numerical value and which will decrease it on user presses. The allowed options are “Left Decrease, Right Increase” (default) and “Left increase, Right Decrease”.
- **Initial Value:** sets which value from the permitted range will be assumed by the control prior to any button presses. It is always 0 by default.
- **Minimum Value:** sets which value from the available range will be the minimum value permitted by the control after a number of presses on the decrease button.
- **Maximum Value:** sets which value from the available range will be the maximum value permitted by the control after a number of presses on the increase button.
- **Short Increment:** sets the increase or decrease to be applied to the current value on every short press over the increase or decrease buttons, respectively (i.e., the smaller the increment is, the more presses will be required). It is 1 by default, except for the case of the 2-byte floating point control, where it is 0.5.
- **Long Increment:** sets the increase or decrease to be applied to the current value on every long press over the increase or decrease buttons, respectively

(i.e., the smaller the increment is, the more presses will be required). It is 10 by default, except for the case of the 2-byte floating point control, where it is 1.

Note: *if the increments configured are too small, certain button touches may not cause a perceptible value change on the indicator, due to precision restrictions of the KNX standard.*

3.5.2.3.6 Two-button Scene Control

Analogously to the 1-button scene control, 2-button scene controls allows sending the KNX bus a scene value through the **[General] Scenes: send** object, however in this case there will be two buttons in the box, each of which can be configured independently.

Through the **Scene** parameter it is possible to assign each of the two buttons (left / right) the number of the scene to be sent (1 – 64). In addition, **Action** (which permits the options “Run” and “Run and save”) lets the integrator set whether the device will only send execution orders for the specified scene (after a short press), or it will possible, apart from sending execution orders on short presses, to also send save orders for such scene, in the case of performing a long press on the button

Last, the dropdown list under **Button Icon** sets the icon to be displayed by the buttons.

Note: *a list with all icons available can be found in document “Z41 Icon list”, available at www.zennio.com.*

Visualization	2-Button Control
Function	Two-Button Scene Control
Left Scene	1
Action	<input type="radio"/> Run <input checked="" type="radio"/> Run and Save
Button Icon	Scene
Right Scene	1
Action	<input type="radio"/> Run <input checked="" type="radio"/> Run and Save
Button Icon	Scene
Protected	<input checked="" type="radio"/> No <input type="radio"/> Yes

Figure 72 2-Button Scene Control

3.5.2.3.7 Shutter Control

Visualization	2-Button Control
Function	Shutter Control
Action	<input checked="" type="radio"/> Left Down, Right Up <input type="radio"/> Left Up, Right Down
State Indicator	<input checked="" type="checkbox"/>
Left Button	Shutter Down 1
Right Button	Shutter Up 1
Protected	<input checked="" type="radio"/> No <input type="radio"/> Yes

Figure 73 Shutter Control

Shutter controls permit sending move up, move down, stop or step shutter orders to the KNX bus by pressing the buttons in the box. In addition, the box will contain an indicator that will permanently show, as a percentage, the value of the status object.

The only specific parameter for this function is:

- **Action:** sets which of the two buttons will send the move up orders and which the move down orders. Options are “Left Down, Right Up” (default) and “Left Up, Right Down”.

Setting up a box as a shutter control enables three communication objects, **[Pn][Bi] Shutter Position** (1 byte), **[Pn][Bi] Move Shutter** and **[Pn][Bi] Stop Shutter** (both, binary objects). The first one acts as the status object, which determines the value shown in the box; it will be necessary to link it to the analogous object from the shutter actuator (as it does not get automatically updated on user presses) so it receives the value 100% when the shutter is completely down, and the value 0% when it is totally up. On their side, control orders will be sent through one of the two remaining objects:

- Orders to move the shutter up/down (completely) are sent through **[Pn][Bi] Move Shutter** after a long press on the corresponding button. Value “0” represents the move up order, while “1” represents the move down order.
- Orders to perform a step movement (value “0” for steps up and “1” for steps down) are sent through **[Pn][Bi] Stop Shutter** after a short press on the corresponding button. If the shutter was already in movement, these orders are interpreted by the actuator as a stop order.

- **State indicator:** enables (by default) or disables the shutter status indicator.

3.5.2.3.8 Light Dimming

Figure 74 Light Dimming.

The light control function permits making use of the two buttons in the box to send orders to a light dimmer, either through a binary object or through a 4-bit object. Moreover, the box will permanently display the current value of the dimming status object, which needs to be linked to the analogous object from the dimmer (as it does not get automatically updated on button presses).

The parameters available are:

- **Action:** sets which of the two buttons will send the “turn on” orders and which the “turn off” orders. Options are “Left Off, Right On” (default) and “Left On, Right Off”.
- **Dimming Step:** sets the increase or decrease in the light level (in terms of percentage) the dimmer must perform with every step order. How step dimming works is detailed below.

Setting up a box as a dimming control brings up the objects **[Pn][Bi] Light Indicator** (1 byte), **[Pn][Bi] Light On/Off** (1 bit) and **[Pn][Bi] Light Dimming** (4 bits). The first one acts as the dimming status object, which is required to be linked to the analogous object from the dimmer and whose value, in percentage, will be permanently reflected in the box. On their side, control orders will be sent through one of the two remaining objects:

- After a short press on the “turn on” button, the value “1” will be sent through the **[Pn][Bi] Light On/Off** binary object, while a short press on the “turn off” button will trigger the sending of the value “0”.
- When a long press on the “turn on” button takes place, the object **[Pn][Bi] Light Dimming** will send the light increment order corresponding to the parameterised dimming step, while a stop order (value “8”) will be sent through the same object as soon as the user releases the button.
- When a long press on the “turn off” button takes place, the object **[Pn][Bi] Light Dimming** will send the light decrement order corresponding to the parameterised dimming step, while a stop order (value “0”) will be sent through the same object as soon as the user releases the button.

Table 4 shows the number of steps (that is, of long presses) required for a complete light regulation (from totally off to totally on, or vice versa) depending on the value parameterised as the dimming step.

Dimming Step	Button Presses Required for Complete Dimming (0 – 100%)
(1) 100%	1
(2) 50%	2
(3) 25%	4
(4) 12,5%	8
(5) 6,25%	16
(6) 3,1%	32
(7) 1,5%	64

Table 4 Dimming Steps

Note: *most light dimmers implement light step dimming progressively (i.e., sending a dimmer a step order of 25% typically does not imply that the light level is suddenly incremented/decremented by 25%, but a progressive increment or decrement of the light level by 25% which is in fact interrupted if a stop order arrives (such order is sent by Z41 Pro / Lite / COM when the user releases the button). Due to this behaviour, it is advised to parameterise dimming steps of 100%, so that the user can perform a complete dimming (from totally off to totally on, or vice versa) or a partial dimming by simply holding the button and then releasing it as soon as he gets the desired light level, therefore with no need of performing successive long presses for regulations greater than the parameterised step.*

3.5.2.4 CLIMATE CONTROL

This category covers a set of functions related to the climate control. The available options for **Function** (and for the dependent parameters) are as follows:

3.5.2.4.1 Setpoint Control

This function permits controlling the temperature setpoint of an external thermostat by means of a two-button box and of the parameters enabled to that effect: **[Pn][Bi] Temperature Control** for the control and **[Pn][Bi] Temperature Indicator** for the status. In addition, the box itself will permanently reflect the value (in °C) of the status object, whose value gets automatically updated after sending control orders (that is, after pressing the buttons), being even possible to receive values from the bus, for example, from the corresponding setpoint status object from the external thermostat.

Visualization	Climate Control
Function	Setpoint Control
Action	<input checked="" type="radio"/> Left Decrease, Right Increase <input type="radio"/> Left Increase, Right Decrease
Setpoint Type	Absolute
Minimum Value	10 x 1°C
Maximum Value	30 x 1°C
Increment Short	1 x 0.5°C
Increment Long	2 x 0.5°C
Left Button	Temp Decrease
Right Button	Temp Increase
Protected	<input checked="" type="radio"/> No <input type="radio"/> Yes

Figure 75 Setpoint

Therefore, after every press on the temperature increment button, the bus will be sent (through the control object) a certain value, progressively increased on every button press until the parameterisable maximum setpoint value has been reached. Analogously, after every press on the temperature decrement button, the bus will be sent a progressively decreased value until the parameterisable minimum setpoint value has been reached.

The parameters available are:

- **Action:** sets which of the two buttons will permit increasing the setpoint value and which one will permit decreasing it. Options are “Left decrease, Right increase” (default) and “Left increase, Right decrease”.
- **Setpoint Type:** it may be “Absolute” (default), “Relative (1-bit object)” or “Relative (Float Object)”.

If the first is selected, the control object will be a 2-byte floating point object and its value will correspond to the actual setpoint value to be sent to the thermostat, being progressively higher or lower as the user touches the control buttons. It is possible to set different increments for short press (**short increment**) and long press (**long increment**). On the other hand, the permitted temperature setpoints will be delimited by a **maximum value** and a **minimum value**, defined by the so-named parameters.

Setpoint Type	Absolute	
Minimum Value	10	x 1°C
Maximum Value	30	x 1°C
Increment Short	1	x 0.5°C
Increment Long	2	x 0.5°C

Figure 76 Absolute Setpoint Control

If the second option is selected (1-bit object setpoint control), the control object will be binary, and it will throw a “0” to the bus whenever the user asks for a setpoint decrement, and a “1” when the user asks for an increment. How much it is incremented or decreased after every order is defined through the **offset** parameter (which accepts values between 1 and 255 tenths of a degree), thus permitting a consistent self-update of the label in the box after every user press, although the status object will also admit the reception of feedback from the bus, i.e., the updated absolute setpoint value sent from the external thermostat.

Setpoint Type	Relative (1-Bit Object)	
Offset	5	x 0.1°C

Figure 77 Relative (1 Bit) Setpoint Control

Finally, when “Relative (float object)” is selected, the control will send 2-byte floating point values. However, these values will correspond to the particular increment or decrement (or offset) to be applied each time. This offset refers to a base temperature and will always be a multiple of 0.5°C. As the user touches the increase/decrease buttons in the box, this offset will vary, always within a certain range defined through the **Minimum Offset** and **Maximum Offset** parameters.

Setpoint Type	Relative (Float Object)	
Minimum Offset	-10	x 1°C
Maximum Offset	10	x 1°C
Increment	1	x 0.5°C

Figure 78 Relative (Float Object) Setpoint Control

Example: suppose the following parameterisation:

- Relative setpoint with a floating point object,
- Minimum offset = -10°C,
- Maximum offset = 10°C.

The objects are linked to those from an external thermostat, which can be supposed to have a base temperature setpoint of 25°C. After the parameter download:

1. The first touch on the increase button will trigger the sending of the value “0.5”, so that the thermostat sets the setpoint to **25.5°C**. This value will be then sent through the status object, and afterwards shown on screen in the corresponding box.
2. A second touch will trigger the value “1”, after which the setpoint will become **26°C**.
3. On the third touch, the value sent will be “1.5”, so the setpoint will be set to **26.5°C**.

And so on until the offset sent becomes 10 (setpoint of **35°C**). Any further presses on the increase button will send the value “10” again, so the setpoint will remain at **35°C**, while touching the decrease button for the first time will trigger the sending of the value “9.5”, setting the temperature back to **34.5°C**. On the second button press, the value “9” will be sent, and the setpoint will become **34°C**. And so on until an offset of “-10” (setpoint of **15°C**) is reached. From that moment, any further presses on the decrease button will re-send the value “-10” and the setpoint will remain at **15°C**.

Important: the control object for the floating point relative setpoint control has its Write flag enabled with the intention of permitting the reception of feedback from the thermostat, which may reset or modify the status of the offset for any reason at any time. This feedback lets Z41 Pro / Lite / COM update its own value to equal that from the external thermostat. Thinking of the above example, if Z41 Pro / Lite / COM receives the value “0” after having the user performed three presses on the increase button (therefore, after having been sent the value “1.5” to the bus), it will happen that on the forth press the value sent will be “0.5” and not “2”.




Figure 79 Relative (Float) Setpoint Control. Object Linking.

Note: the parameterised setpoint type becomes transparent to the final user, as the aspect of the on-screen box remains the same in all cases. In addition, the setpoint status object is always a 2-byte floating point object and will represent, in any case, the absolute value of the current temperature setpoint.

- **Left Button** and **Right Button:** permit selecting the desired icon to be displayed inside each button in the box.

Note: a list with all icons available can be found in document “Z41 Icon list”, available at www.zennio.com.

3.5.2.4.2 Mode Control

This function turns the box into a climate mode control.

Visualization	Climate Control
Function	Mode Control
Mode Type	<input checked="" type="radio"/> Heat/Cool <input type="radio"/> Extended
Left Button	Mode Cool
Right Button	Mode Heat
Protected	<input checked="" type="radio"/> No <input type="radio"/> Yes

Figure 80 Heat/Cool Mode Type

Two mode control types are possible: the **Heat / Cool** control type and the **Extended** (HVAC) control type. Selecting the former or the latter is possible through the **Mode Type** parameter.

• Heat / Cool

Selecting this type of mode control turns the box into a 2-button control one of which will activate the Heat mode, while the other one will activate the Cool mode. A centred indicator will reflect, as an icon, the currently active mode.



Figure 81 Heat/cool Mode (Box)

Two communication objects are also enabled: the **[Pn][Bi] Mode Control** control object and the **[Pn][Bi] Mode Indicator** status object. When the user activates the Cool mode, the device will send the value “0” through the control object, while on the activation of the Heat mode the value “1” will be sent. Moreover, the box will automatically commute between one icon and the other every time the user executes a mode change, and also on the reception of a new value (from the bus) through the status object.

• Extended

Selecting this type of mode control turns the box into a 2-button control, which permit sequentially commuting among the different HVAC climate modes. A centred indicator will reflect, as an icon, the currently active mode.




Figure 82 Extended Mode (Box)

Up to five modes (Heat, Cool, Auto, Fan and Dry) are available, each of which can be enabled/disabled in ETS by means of the proper checkbox, which permits setting which of all the five extended modes will be included into the sequential scrolling implemented by the buttons.




Figure 83 Extended Mode

When this type of mode control is assigned to the box, two 1-byte communication objects are enabled: the **[Pn][Bi] Mode Control** control object, and the **[Pn][Bi] Mode Indicator** status object. Depending on the mode selected by the user, the control object will be sent to the bus a certain value (see Table 5), after which the box will display the icon that corresponds to the new mode. Additionally, if the status object receives from the bus a value that represents any of the modes, the box will adopt the corresponding icon, while if an unrecognised value is received, no icon will be shown.

Mode	Value sent
Heat	1 (0x01)
Cool	3 (0x03)
Auto	0 (0x00)
Fan	9 (0x09)
Dry	14 (0x0E)

Table 5 HVAC Mode vs. Object Value

Finally, the **Left Button** and **Right Button** parameters permit selecting the icon that will be displayed inside the buttons of the box.

Note: a list with all icons available can be found in document “Z41 Icon list”, available at www.zennio.com.

3.5.2.4.3 Fan Control

Visualization	Climate Control
Function	Fan Control
Action	<input checked="" type="radio"/> Left Decrease, Right Increase <input type="radio"/> Left Increase, Right Decrease
Speed Levels	1
Control Type	1 bit (Decrease/Increase)
Cyclical	<input type="checkbox"/>
Auto Mode	<input type="checkbox"/>
Allow Speed 0	<input type="checkbox"/>
Left Button	Minus
Right Button	Plus
Protected	<input checked="" type="radio"/> No <input type="radio"/> Yes

Figure 84 Fan Control

This function implements a 2-button (increase / decrease) fan control, as well as an icon indicator.

When this function is assigned to the box, object **[Pn][Bi] Fan Control** as well as the **[Pn][Bi] Fan Indicator** 1-byte status object are enabled. The status object (which needs to be linked to the status object of the fan actuator) will express, as a percentage, the value of the current fan level, which will be represented with a variable icon on the box.

- **Action:** permits setting the increase or decrease actions to one button or another. Options are: “Left: decrease, Right increase” (default) and “Left increase, Right decrease”.
- **Speed Levels:** sets how many speed levels will be available in the control. 1 to 5 levels.
- **Control Type:** sets the type of the communication objects that will control the fan level.
 - “1 bit (decrease/increase)”: orders of speed increase/decrease are sent through the one-bit object “**[Btn] [X] Fan control (1 bit)**”.
 - “Scaling”: scaling values are sent through the one-byte object “**[Btn] [X] Fan control (scaling)**”.

- **“Enumeration”**: integer values are sent through the one-byte object “[Btn] [X] Fan control enumerated”.
- **Cyclical**: sets whether scrolling through the speed levels is circular or not. If checked, an increase order in the maximum level switches to the minimum and vice versa (in the minimum level a decrease order switches to the maximum).
- **Auto Mode**: sets whether the fan Auto mode will be available or not. If checked, the following parameters are also shown.
 - **Dedicated Object for Auto Mode**: sets how the Auto mode should be activated. In the absence of a dedicated object, the Auto fan mode will be activated by switching to fan level 0.





Figure 85 Fan Control – Auto Mode.

In this case (supposing that Speed Levels has been set to “3”), the fan levels that can be navigated through short presses are:



On the other hand, marking the checkbox enables the one-bit object “[Btn] [X] Fan control – Auto mode”, which will trigger the Auto mode when it receives the value “1” (or “0”, depending on the subsequent parameter “Value to Set the Auto Mode”).




Figure 86 Fan Control – Dedicated Object for Auto Mode.

However, two alternative (and mutually exclusive) methods are possible to activate this mode:

- By short press: the Auto mode can be reached as a further level above the maximum one. In this case the fan levels activated by short presses are (note that **speed 0 is optional**):

(0)	Minimum	Medium	Maximum	Auto
-------	---------	--------	---------	------

- By long press on any of the buttons of the control (requires checking **Long Press to Activate Auto Mode**).

A further long press deactivates back the Auto mode and sends the minimum fan level. Instead, a short press deactivates the Auto mode and switches to the next level (or previous, depending on the button). In this case the fan levels reachable through short presses are (**speed 0 is optional**):

(0)	Minimum	Medium	Maximum
-------	---------	--------	---------

Here, the Auto mode is only activated by long press.

- **Allow speed 0**: sets whether the speed level 0 will be present or not. When the Auto Mode without a dedicated object has been configured, this option will be necessarily activated.

Finally, the **Left Button** and **Right Button** parameters permit selecting the icon that will be displayed inside the buttons of the box

Note: a list with all icons available can be found in document “Z41 Icon list”, available at www.zennio.com.

3.5.2.4.4 Special Mode Control

Boxes configured as special mode controls include two buttons that let the user sequentially commute between the different special climate modes, as well as an icon indicator that will adopt an aspect or another depending on the currently active special mode.



Figure 87 Special Mode Control (Box)

Visualization	Climate Control
Function	Special Mode Control
Allow Protection Mode	<input checked="" type="radio"/> No <input type="radio"/> Yes
Allow Auto Mode	<input checked="" type="radio"/> No <input type="radio"/> Yes
Left Button	Arrow Left
Right Button	Arrow Right
Protected	<input checked="" type="radio"/> No <input type="radio"/> Yes

Figure 88 Special Modes

When this function is assigned to the box, two 1-byte objects (**[Pn][Bi] Special Mode Control** as the control object, and **[Pn][Bi] Special Mode Indicator** as the status object) will be enabled. The former will be sending the bus the value that corresponds to the mode that the user selects by touching the buttons (see Table 6), while the status object (which can receive values from the bus although it gets self-updated as well on button presses) will determine the indicative icon represented in the box at any time. If this object receives an unrecognised value from the bus, no icon will be displayed in the indicator.

Special Mode	Icon	Object Value
Comfort		1 (0x001)
Standby		2 (0x002)
Economy		3 (0x003)
Protection		4 (0x004)
Auto Mode		5 (0x005)

Table 6 Special Modes vs. Icon vs. Object Value

The remaining parameters for this function are:

- **Allow Protection Mode:** this parameter permits excluding (“No”, default option) or including (“Yes”) the “building protection” mode from the special modes listed in the sequential scrolling performed by the buttons.
- **Allow Auto Mode:** this parameter permits excluding (“No”, default option) or including (“Yes”) the “auto” mode from the special modes listed in the sequential scrolling performed by the buttons.
- **Left Button and Right Button:** permit selecting the icon that will be displayed inside the buttons in the box.

Note: a list with all icons available can be found in document “Z41 Icon list”, available at www.zennio.com.

3.5.2.5 OTHER

This category involves the following functions, which can be selected through the **Function** parameter.

3.5.2.5.1 RGB

This function is intended for sending orders to three-colour LED light regulators, such as LUMENTO X3 RGB from Zennio.

Visualization	Other
Function	RGB Control
Object Type	<input checked="" type="radio"/> Three Single Colour Objects (DPT 5.001) <input type="radio"/> One RGB Object (DPT 232.600)
Left Button	Light On/Off
Right Button	Themes
Protected	<input checked="" type="radio"/> No <input type="radio"/> Yes

Figure 89 RGB

When the function is assigned to the box, the following parameters come up:

- **Object Type:** permits selecting what type of object will be used for controlling the light level of the RGB channels. It may be “Three single colour objects (DPT 5.001)” (by default) or “One RGB object (DPT 232.600)”. If the former is selected, three 1-byte objects will be enabled (with their **Write** and **Read** flags

activated, so they can both send regulation orders and receive the status from the regulator) named:

- **[Pn][Bi] Red Channel**
- **[Pn][Bi] Green Channel**
- **[Pn][Bi] Blue Channel**

Control orders will consist in sending the light level (as a percentage) of the different channels through the corresponding objects.

If the second option is selected, only one 3-byte object will be enabled:

- **[Pn][Bi] RGB Colour**

In this case, the light levels of the three channels are sent (and received) concatenated into the above 3-byte object.

Note: *if statuses are received while the luminaire performs a regulation, this control may become hardly serviceable until such regulation ends.*

- **Left Button and Right Button:** permit selecting the icon that will be displayed inside the buttons in the box.

Regarding the RGB control boxes themselves, a central label will permanently show, as a percentage, the current light level (which is determined by the channel with the highest current light level). This **indicator** gets updated automatically as the user interacts with the box, but is also conditioned by the values received from the bus through the already described objects.



Figure 90 RGB (Box)

Moreover, two buttons can be found in the box:

- Short-pressing on the left button it permits commuting between a total absence of light in the three channels, and their respective states previous to the switch-off. **Long**-pressing it, on the other hand, will make the device send a 4-bit dimming order through object **[Pn][Bi] Intensity Dimming**, analogously as in a light dimming control (see h) in section 3.5.2.3).

- The button on the right, when pressed, launches a pop-up² containing **colour palette** that permits the selection of a light level for every channel, either by touching on any of the pre-set colours, or by separately selecting the level of each channel (R, G, B).




Figure 91 RGB Colour Palette

A set of recently used colours is shown at the bottom of the palette. These colours refer to those recently used within that particular box.

3.5.2.5.2 RGBW

The RGBW control is entirely analogous to the above RGB control, although it also lets controlling a specific fourth channel for white, in case such feature is supported by the dimmer, as in LUMENTO from Zennio.




Figure 92 RGBW

² Every pop-up screen will be auto-closed if the inactivity time expires. The actions will be saved if they are correctly configured.

Therefore, the functionality is similar to that of the RGB control, although in this case the R, G and B channels must be controlled through a joint 3-byte object. In addition, object **[Pn][Bi] White Channel** will send the dimming orders to the white channel.

Finally, RGBW control boxes look similarly to RGB control boxes:



Figure 93 RGBW (Box)

Nevertheless, when the colour palette of an RGBW box is accessed, a fourth increase/decrease regulator is shown together with the three regulators shown in the case of the RGB control boxes:



Figure 94 RGBW Colour Palette

3.5.2.5.3 Consumption Monitor

This function permits making use of one of the boxes of Z41 Pro / Lite / COM as a monitor of the consumption of energy or water/gas (as reported by external devices such as KES and KCI from Zennio), and particularly as a monitor of the evolution of the instant power or water/gas flow.

Figure 95 Consumption Monitor



Figure 96 Consumption Monitor. Box.

The box indicator shows the instant power or flow. When the user touches any of these boxes, a pop-up window similar to the Figure 97 will be shown.




Figure 97 Energy Monitor. Pop-Up Window.

Prior to detailing the elements shown in the pop-up window, the ETS parameters for this type of function are described next:

- **Measurement Type:** sets whether the values received refer to electric power or water/gas flow. Both are managed analogously; however the units of measurement and the parameter/object names will differ.
 - If “Power”, specific parameters will show up to set the **electric power units** (kW or W) and whether the accumulated energy consumption should be shown within the pop-up window (and, if so, the **energy measurement units**: kWh or Wh).

Measurement Type	<input checked="" type="radio"/> Power <input type="radio"/> Gas/Water
Power Unit	<input type="radio"/> W <input checked="" type="radio"/> kW
Energy Consumption	<input checked="" type="checkbox"/>
Energy Unit	<input type="radio"/> Wh <input checked="" type="radio"/> kWh

Figure 98 Energy consumption monitor.

- If “Water/Gas”, two specific parameters will show up to set the **water/gas flow units** (litres per hour or m³ per second) and whether the accumulated volume should be shown within the pop-up window (in such case, the **volume units** will be m³, as defined by the KNX standard).

Measurement Type	<input type="radio"/> Power <input checked="" type="radio"/> Gas/Water
Flow Unit	<input type="radio"/> m ³ /s <input checked="" type="radio"/> l/h
Volume	<input checked="" type="checkbox"/>

Figure 99 Water/Gas Consumption Monitor.

The electric power or water/gas flow measurement reports should be received, respectively, through objects **[Pn][Bi] Consumption Monitor: Power** and **[Pn][Bi] Consumption Monitor: Flow**.

The energy or water/gas volume consumption reports should be received, respectively, through objects **[Pn][Bi] Consumption Monitor: Energy** and **[Pn][Bi] Consumption Monitor: Volume**.

- **CO2**: determines whether the pop-up window should show the instant value of the **[Energy x] CO2** object or not.
- **Cost**: determines whether the pop-up window should show the instant value of the **[Energy x] Cost** object or not.

When this function is assigned to the box, two 1-bit communication objects will also be added to the project topology:

- **[Pn][Bi] Energy Monitor: Request**, which will be sent to the bus (value “1”) to request the updated value of the measurements. This object must be linked to the analogous object of the external measurement device.
- **[Pn][Bi] Energy Monitor: Reset**, which will be sent to the bus (value “1”) to request a value reset to the external measurement device, so the consumption, CO₂ and cost variables are re-set to zero. This object must be linked to the analogous object of the external measurement device.

Finally, back to the pop-up window that shows up when the box is pressed, the following elements must be highlighted:

- Evolution of the Power/Flow object: shows, as a graph, the chronological evolution of the value of the power or flow object, according to the measurement type. The horizontal axis will show different time lapses (hours, days, or months), depending on the selected zoom level.
- Instant Value of the Energy, CO₂ and Cost objects: indicator that shows the current value of the already mentioned energy / volume, CO₂ and cost objects, provided that the **Energy Consumption / Volume**, **CO2** and **Cost** checkboxes have been marked.
- Zoom Level: two-button control that lets the user change the time scale, so more / less detail is shown in the graph of the evolution of the power / flow object. The behaviour and the representation of the data are similar to those of the numeric data log (see epigraph 3.5.2.1.5 in section □).
- Validation / Refresh / Reset buttons: permit, respectively, closing the pop-up window, sending an order to re-set the consumption data (through the already mentioned reset object) and requesting an updated sending of the consumption data (through the request object, already mentioned as well). Note that the Reset button requires a long press to perform this action.

3.5.2.5.4 Daily Timer




Figure 100 Daily Timer

Boxes configured as daily timers let the final user program a timed sending of a value to the bus, being possible to send binary or scene values (according to the parameterisation) at a certain time (either every day or only once) or at the end of a countdown.



Figure 101 Daily Timer (Box)

Hence, when the user presses on the box, a window containing the necessary controls for setting up a timed sending (either at a specific time or after a countdown) will pop up.








Figure 102 Daily Timer (Pop-Up Window)

This window contains the following elements:

- Timer Type: two-button selector to step through the following options:

			
Timer inactive.	Timer active (every day).	Timer active (no repetition).	Timer active (countdown).

- **Time Selector:** depending on the selected timer type, permits setting the time for the automated sending, or the length of the countdown.
- **Value to be Sent:** in case of having parameterised the sending of a binary value, this control lets the user determine the concrete value to be sent (“OFF” or “ON”). In the case of the sending of a scene, this control is not shown, as the scene number is set by parameter.

Hence, at the time set by the user or once the countdown ends, the bus will be automatically sent the corresponding value, through the **[Pn][Bi] Daily Timer Control** object (for binary values) or through the **[General] Scenes: Send** object (in case of scene values). In both cases the **[Pn][Bi] Daily Timer Enabling** binary object will be available, making it possible to disable (by sending the value “0”) or to enable (value “1”) the execution of the timed sending set by the user. By default, timed sending is always enabled.

Note: in case of disabling a sending through **[Pn][Bi] Daily Timer Enabling**, the corresponding box will show the “forbidden” icon, although the box will not lose the configuration previously set by the user.

Finally, this function offers the following parameters in ETS:

- **Timer Type:** switches between “1-bit value” (default option) and “Scene”.
- **Scene Number:** shown only after selecting “Scene” for the above parameter. This field defines the number of the scene (1-64) that will be sent to the bus on the execution of the timed sending.
- **Enablement:** sets the value to enable and disable the timer through the object **[Pn][Bi] Daily Timer Enabling**. The options are “0=Disable; 1=Enable” (default option) “0=Enable; 1=Disable”.

3.5.2.5.5 Weekly Timer




Figure 103 Weekly Timer

Boxes configured as weekly timers let the final user program a timed sending of a binary or scene value to the bus (according to the parameterisation) at a certain time on certain days (on a weekly basis).

The difference between the daily and the weekly timers is that the latter does not permit the countdown-based sending, although it does permit that a time-based sending takes place every week, on the days selected by the user.




Figure 104 Weekly Timer (Box).

Hence, when the user presses on the box, a window similar to Figure 105 will pop up.




Figure 105 Weekly Timer (Pop-Up Window).

This window contains the following elements:

- **Day Selector:** lets the user select the days the timed sending will take place on. The first day of the week depends on the parameterisation of the Calendar tab (see section 3.2.7).
- **Value to be Sent (ON / OFF):** lets the user set the value to be sent. It can be “ON” or “OFF”, or even both at different times. One time selector is provided for each of the two values.

Note: *if instead of the sending of a binary value, the sending of a scene value has been parameterised, only one checkbox and one time selector will be shown, so the user can enable/disable the sending of the scene value and, if enabled, set the desired time.*

- **Time Selector:** let the user set the time at which the automatic sending will take place.

Hence, at the specified time on the days selected by the user, the bus will be automatically sent the corresponding value through the **[Pn][Bi] Weekly Timer Control** object (in the case of sending a binary value) or through the **[General] Scenes: Send** object (in the case of sending a scene number).

In both cases the **[Pn][Bi] Weekly Timer Enabling** binary object will be available, making it possible to disable (by sending the value “0”) or to enable (value “1”) the execution of the timings set by the user. By default, user timings are always enabled.

Note: *in case of disabling a sending through **[Pn][Bi] Weekly Timer Enabling**, the corresponding box will show the “forbidden” icon, although the box will not lose the configuration previously set by the user.*

Finally, this function offers the following parameters in ETS:

- **Timer Type:** switches between “1-bit value” (default option) and “Scene”.
- **Scene Number:** shown only after selecting “Scene” for the above parameter. This field defines the number of the scene (1-64) that will be sent to the bus on the execution of the timed sending.
- **Label for “Time ON”:** permits customising the label shown next to the checkbox that enables/disables the sending of the switch-on order. The default value is “Time ON”.

- **Label for “Time OFF”**: permits customising the label shown next to the checkbox that enables/disables the sending of the switch-off order. The default value is “Time OFF”.
- **Label for “Scene”**: permits customising the label shown next to the checkbox that enables/disables the scene sending. The default value is “Scene”.
- **Enablement**: sets the value to enable and disable the timer through the object **[Pn][Bi] Daily Timer Enabling**. The options are “0=Disable; 1=Enable” (default option) “0=Enable; 1=Disable”.

Note: *the execution of user-defined timers is triggered on the detection of state transitions, even if the clock does not specifically pass through the specified time. In other words, supposing one timed sending of the value “ON” at 10:00h am and one timed sending of the value “OFF” at 8:00h pm, if the internal clock is set to 9:00h pm just after 10:00h am (and therefore after having sent the value “ON”), then the “OFF” order corresponding to 8:00h pm will take place immediately after the time change.*

3.5.2.5.6 Chrono-thermostat

Boxes configured as chrono-thermostats let the final user schedule the timed sending of **temperature setpoint orders** (preceded by switch-on orders) or **switch-off orders** to a thermostat through the KNX bus.

To that end, it is necessary to configure the following two parameters:

Visualization	Other
Function	Chrono-thermostat
Minimum Setpoint Value	18 x 1°C
Maximum Setpoint Value	30 x 1°C
Enablement	<input checked="" type="radio"/> 0=Disable; 1=Enable <input type="radio"/> 0=Enable; 1=Disable
Protected	<input checked="" type="radio"/> No <input type="radio"/> Yes

Figure 106 Chrono-thermostat

- **Minimum Setpoint Value**: minimum setpoint value the user will be able to set. Range: [-20, 95] x 1°C. Default value: 18°C.

- **Maximum Setpoint Value:** maximum setpoint value the user will be able to set. Range: [-20, 95] x 1°C. Default value: 30°C.
- **Enablement:** sets the value to enable and disable the chrono-thermostat through the object **[Pn][Bi] Daily Timer Enabling**. The options are "0=Disable; 1=Enable" (default option) "0=Enable; 1=Disable".

When a box is configured as a chrono-thermostat, it looks as follows:





Figure 107 Chrono-thermostat (box)

The **switch button** on the left activates / deactivates the chrono-thermostat, that is, resumes or stops the execution of the timed actions that may have been configured (the configuration is not lost during the deactivation). While the chrono-thermostat is not active, icon  is shown next to the switch button.

On the other hand, when the user touches on the **calendar icon**, a new window will pop up to let the user set the actions to be executed:







Figure 108 Chrono-thermostat (pop up)

Each box configured as a chrono-thermostat contains **four pages** with **six customisable timers** each, being possible for the user to configure up to 24 timed actions.

The buttons on the bottom of the window let switching across the four pages, as well as closing the pop-up window (button ).

For each of the six timed actions of each page it is necessary to select, on the first hand, the **days of the week** on which the action should be performed, as well as the specific **time of day** (the first day of the week will depend on the parameterisation of the Calendar tab; see section 3.2.7).

After that, the user should select (through controls  and ) the **temperature setpoint that will be sent**. The range of this value is restricted by parameters “**Minimum Setpoint Value**” and “**Maximum Setpoint Value**”.


Note: *the timed sending of a temperature setpoint is always preceded by a **switch-on order**.*

Instead of a temperature setpoint, it is also possible to send a **switch-off** order to the thermostat. In such case, the user must successively press on the above control until one of the range limits is reached, after which the word “**OFF**” will show on the screen instead of a temperature value.

On the other hand, it is possible to **activate or deactivate** each action separately by marking its corresponding checkbox. While this checkbox remains unmarked, the action configured will not take place.

On **power failures and ETS downloads**, chrono-thermostat boxes behave as detailed in section 3.8.

Each chrono-thermostat box entails the following three objects:

- “[Pn][Bi] Chrono-thermostat: **Enabling**”: permits activating (value “1”) or deactivating (value “0”) the chrono-thermostat analogously as from the on-screen **switch button** of the box, which will show the icon  while deactivated.
- “[Pn][Bi] Chrono-thermostat: **Temperature Setpoint**”: this is the object through which the timed temperature setpoints will be sent.
- “[Pn][Bi] Chrono-Thermostat: **On/Off**”: this is the object through which the timed switch-off orders will be sent.

3.5.2.5.7 Alarm

Figure 109 Alarm

Boxes configured as alarms perform user warnings on anomalous events. For this purpose, boxes of this type are related to a binary object (**[Pn][Bi] Alarm Trigger**) that permits receiving alarm messages from the bus, thus making Z41 Pro / Lite / COM emit a continuous beep while the screen light blinks. In addition, the screen will automatically browse to the page containing the alarm box that has been triggered. After that moment, pressing on the “Menu” button will interrupt the beeps and blinks although the box will still show an intermitting icon, which means that the alarm is still active and unconfirmed. Additionally, the icon of the page that contains the box will also show an exclamation.



Figure 110 Alarm (Box).

The intermitting exclamation means that the alarm is active and unconfirmed.

However, alarm boxes implement an additional binary object, **[Pn][Bi] Alarm Confirmation**, intended for receiving the value “1” from the bus, which will be interpreted as an acknowledgement of the alarm, thus making the icon intermittence stop. Alternatively, the alarm can be acknowledged (and muted) by touching on the “OK” button in the box itself, which will cause the sending of the value “1” through the mentioned object.

The alarm will definitely become inactive once it has been confirmed and, in addition, once the **[Pn][Bi] Alarm Trigger** object goes back to the “no alarm” state (the order of these two events is irrelevant), after which the icon will finally turn off.




Figure 111 Alarm state diagram (case of confirmation previous to the alarm end)

There is also the possibility of **periodically monitoring** the status of the trigger object, for situations where this object is periodically received from the bus. This will let Z41 Pro / Lite / COM automatically assume the alarm situation if the “no alarm” value does not get sent through the trigger object after a certain time, for example upon failures of the transmitter. The maximum time window can be defined by parameter.

Consequently, alarm boxes permit configuring the following parameters:

- **Trigger:** defines the value that will trigger the alarm (“0” or “1”; it is “1” by default), i.e., the value that, when received through **[Pn][Bi] Alarm Trigger**, should be interpreted by Z41 Pro / Lite / COM as an alarm situation. Implicitly, this parameter also defines the inverse “no alarm” value.
- **Periodic Monitoring:** activates (“Yes”) or deactivates (“No”, default option) periodic monitoring of the alarm trigger object.
- **Cycle Time (x 1min.):** in case of having selected “Yes” under the above parameter, sets the maximum accepted time space without receiving the “no alarm” value before Z41 Pro / Lite / COM adopts the alarm situation.

Example I: *supposing a certain sensor responsible for sending the value “1” (once) to the bus when a flood is detected, and the value “0” (again, only once) when such situation terminates, if the object sent is linked to the alarm trigger object from an alarm box in Z41 Pro / Lite / COM where no periodical monitoring has been parameterised and where the value “1” has been set as the alarm value, then Z41 Pro / Lite / COM will notify an emergency every time a flood takes place. The notification will stop as soon as the user touches any button, although a warning icon will still blink on the screen. After that, if the user acknowledges the alarm, the icon will stop blinking; switching then off once the sensor sends a “0”.*

Example II: suppose a certain CO₂ sensor responsible for sending the value “0” to the bus every two minutes, except when it detects a dangerous CO₂ level; in such case, it will immediately send the value “1”. If the object being sent is linked to the alarm trigger object from an alarm box in Z41 Pro / Lite / COM where periodic monitoring has been parameterised and where the value “1” is configured as the alarm trigger value, then Z41 Pro / Lite / COM will notify the user about the emergency both if the CO₂ level reaches a dangerous level and if the sensor stops sending the value “0”, for example due to failures or sabotage. The user should proceed in the same manner as in the above example to manage the alarm notification.

3.5.2.5.8 Holiday Calendar

Figure 112 Holiday Calendar

Boxes configured as a Holiday Calendar let the end user set a number of holidays on a calendar, and to program the sending of one value or another when the date changes, depending on whether the new date is a weekday or not.

It is necessary to configure the following parameters:

- **Send 1-bit Object:** always-enabled parameter to make it evident that on a date change, the device will always send a 1-bit object to indicate whether the new day is a weekday or a holiday.
- **Value:** values that will be sent through the 1-bit object depending on whether the day is a weekday or a holiday. Options: “0 = Weekday; 1 = Holiday” (default option) and “1 = Weekday; 0 = Holiday”.

- **Send Scene:** checkbox to enable or disable a scene sending on date changes. When enabled, two more parameters will show:
 - **Scene Number (Workday):** number of the scene (between 1 and 64) that will be sent to the bus if the new day is a workday. If set to 0, no values will be sent.
 - **Scene Number (Holiday):** number of the scene (between 1 and 64) that will be sent to the bus if the new day is a holiday. If set to 0, no values will be sent.

Send Scene	<input checked="" type="checkbox"/>
Scene Number (Workday)	0 (0=Disabled)
Scene Number (Holiday)	0 (0=Disabled)

Figure 113 Send Scene

- **Send 1-byte Object:** checkbox to enable or disable the sending of a 1-byte object (0 to 255) on date changes. When enabled, two more parameters will show:
 - **Value (Workday):** number of the scene (between 0 and 255) that will be sent to the bus if the new day is a workday.
 - **Value (Holiday):** value (between 0 and 255) that will be sent to the bus if the new day is a holiday.

Send 1-Byte Object	<input checked="" type="checkbox"/>
Value (Workday)	0
Value (Holiday)	0

Figure 114 Send 1-byte Object.

- **Sending Frequency:** defines when the 1-bit, 1-byte and scene objects should be sent. Options: “Everyday” (default) and “Only on Transitions” (i.e., only when the new day is a different type).
- **Button Icon:** permits selecting the icon of the button that provides access to the calendar.

Note: a list with all icons available can be found in document “Z41 Icon list”, available at www.zennio.com.

Boxes of this type look similar to the following figure:




Figure 115 Holiday Calendar (box).

When the user presses on the calendar button, a new window will pop up to let them set the holidays by simply tapping on the calendar – days marked as holidays will remain highlighted in orange colour (all days are considered workdays by default).




Figure 116 Holiday Calendar.

Note: this configuration is year-dependent. Therefore, the holiday selection only applies to the year shown on the calendar, although it is possible to navigate to the subsequent years in order to set the corresponding holidays in advance.

The buttons on the upper section of the pop-up window let the user browse through the months of the year, while the button on the bottom (←) lets leaving the pop-up window.

On the change of day, the device considers the previous date and the new one, and determines their types (workday or holiday). Depending on the sending frequency configured, the corresponding one-bit, one-byte or scene objects (which are not exclusive of each other) will be sent or not.

3.5.2.5.9 Macro

Macros let the end user configure and execute a set of sequential actions, which will consist in actions from other boxes. A delay between them can also be configured.

This function allows defining scenes manually from the on-screen menu.

To configure a box as a macro control, the following parameters must be set:

Figure 117 Macro

- **Trigger Object:** sets the type of the object that will trigger the execution of the macro upon the reception of the proper value. If set to “1-Bit Object”, an object with name “[Pn][Bi] Macro: trigger” will be incorporated to the project topology. On the contrary, if set to “Scene Object”, the trigger value will be expected through the “[General] Scenes: Receive” object.
 - **Value:** “0=Stop; 1=Start” or “0=Start; 1=Stop” (in the case of the one-bit object) or two integer values in the range 1-64, one for triggering the execution and another one to stop it (in the case of the scene object).
- **Send Object When Macro Starts:** sets whether the device should send a value to the bus upon the execution of the macro. The options are: “Disabled”, “1-Bit Object” (in which case the value will be sent through “[Pn][Bi] Macro: Started”) or “Scene Object” (in which case the value will be sent through “[General] Scenes: Send”).
 - **Value:** sets the value to be sent, either “0”, “1” or an integer value in the range 1-64, depending on the above parameter.

A box configured as a Macro will be composed of two buttons, as shown in the Figure 118.




Figure 118 Macro (box)

- **Left button:** runs / stops the execution of the macro.
- **Right button:** opens up the macro configuration panel³ (Figure 119).



Figure 119 Macro Pop-Up

The centre of the panel shows the list of actions that make up the macro. The ↑ and ↓ arrows allow stepping through these actions, while a long press on the garbage icon allows removing the selected action. On the other hand, the ← and → arrows should be used to set the desired delay of the action, while the “+” icon allows inserting additional actions. The page, box and value corresponding to each of the actions in the list can be set through the upper section of the panel.

Up to 30 actions are available per macro.

3.5.2.5.10 Scheduler

Schedulers allow the execution of time-controlled actions of other boxes.

To configure a box as a macro control, the following parameters must be set:

³ Every pop-up screen will be auto-closed if the inactivity time expires. The actions will be saved if they are correctly configured.





Figure 120 Scheduler

- **Enablement:** sets the value to enable and disable the sending of actions of the scheduler through the object “[Pn][Bi] Scheduler Enabling”. The options are: “0=Disable; 1=Enable” or “0=Enable; 1=Disable”.

A box configured as a Scheduler will have the same appearance as a Chrono-Thermostat, as shown in Figure 121, and will be composed of two buttons and an indicator.



Figure 121 Scheduler (box)

- **Left Button:** enables or disables the Scheduler.
- **Right Button:** opens up the macro configuration panel⁴ (Figure 122).
- **Indicator:** nothing (enabled) or  (disabled).




Figure 122 Scheduler

⁴ Every pop-up screen will be auto-closed if the inactivity time expires. The actions will be saved if they are correctly configured.

In the upper section of the panel can be configured the day of the week and the hour of the execution of the action. Moreover, if there is any calendar configured (see section 3.5.2.5.8 above) it is possible to set if the action is executed in holidays or in workdays (or both if no calendar is selected). The page, box and value corresponding to the actions can be set through the central section of the panel. The “+” icon allows inserting additional actions. The ← and → arrows allow stepping through the time-controlled actions, while a long press on the garbage icon allows removing the action

Up to 30 time-controlled actions are available per scheduler.

3.5.2.5.11 Logic Function

A logical function allows the execution of the action any other box when certain conditions are fulfilled.

To configure a box as a Logic Function control, the following parameters must be set:




Figure 123 Logic Function

- **Trigger Object Value:** sets the value that triggers the execution of the logic function when received through the object “[Pn][Bi] Logical Function: Trigger”. The options are: “0=Nothing; 1=Evaluate” or “0=Evaluate; 1=Nothing”

A box configured as a logical function will be displayed as shown in Figure 124, and will be composed of two buttons without indicator.



Figure 124 Logic Function (box)

- **Left Button:** starts the execution of the logical function.

- **Right Button:** opens up the logical function configuration panel⁵ (Figure 125).



Figure 125 Logic Function

In the upper section of the panel can be configured the restrictions. The “+” icon allows inserting additional restrictions. In the central section of the panel the action to execute can be configured. The page, box and value corresponding to the selected item (either a restriction or an action) are set at the bottom of the display. A long pulse on the trash icon will remove whole configuration.

3.5.2.5.12 Page Direct Link

It is a shortcut to the page indicated by parameter.

To configure a box as a Logic Function control, the following parameters must be set:




Figure 126 Page Direct Link

- **Page Number:** 1 (by default) to 12.
- **Button (In the Middle):** permits selecting the icon of the button.

⁵ Every pop-up screen will be auto-closed if the inactivity time expires. The actions will be saved if they are correctly configured.

Note: a list with all icons available can be found in document “Z41 Icon list”, available at www.zennio.com.

The default aspect of a Page Direct Link box is show in Figure 127, but the icon and the text are also configurable:



Figure 127 Page Direct Link (box)

3.5.2.5.13 Video Intercom (Z41 COM)

Permits accessing to the call log of a video intercom and, if the video intercom type is private (see section 3.3), accessing to the visualization of the images from the camera of the outdoor unit (GetFace IP).



Figure 128 Video Intercom (box).

Label	Private
Visualization	Other
Function	Video Intercom
Video Intercom	1
Left Button	Video Intercom
Right Button	Call Log

Figure 129 Video Intercom

The parameters available are:

- **Video Intercom:** number of the VI to which the box is associated.

Note: A warning message will be shown in case that the video intercom selected is not enabled.

- **Left Button / Right Button:** dropdown list for the selection of the icons to be displayed inside the buttons in the box.

3.6 CONFIGURATION PAGE

The Configuration Page tab contains a set of secondary tabs.

3.6.1 CONFIGURATION

This screen permits the integrator configure the controls that will be available for the final user within the Configuration page (see section 2.3), as well as the label that will identify them on the screen. Note that the Configuration page itself can be activated or hidden from the Configuration screen, under the Menu tab (see section 3.4.1).

Title	<input type="text"/>
Automatic Page Shaping	<input type="radio"/> No <input checked="" type="radio"/> Yes
Protected	<input checked="" type="radio"/> No <input type="radio"/> Yes
Time/Date	<input checked="" type="checkbox"/>
Label	<input type="text"/>
Device	<input checked="" type="checkbox"/>
Label	<input type="text"/>
Program Configuration	<input type="checkbox"/>
Alarm Log	<input type="checkbox"/>
Profile	<input checked="" type="checkbox"/>
Label	<input type="text"/>
Error Log	<input type="checkbox"/>
Probe Calibration	<input type="checkbox"/>
Device Pairing	<input type="checkbox"/>

To enable this box, the parameter "MAIN CONFIGURATION/Ethernet/Remote control through the Internet" must be set

Figure 130 Configuration (Configuration Page)

By default, the **Time/Date** controls and the **Device** and **Profile** screens are marked as active. Please refer to section 2.3 for details.

On the other hand, for the Configuration page –as for any other page–, a label (parameter **Title**), a security level (parameter **Protected**; see section 3.2.8) can be set, and whether **Automatic Page Shaping** is required (see section 2.10).

Note: the *Device Pairing* option is only available in Z41 Pro / COM.

3.6.2 DEVICE

If the Device checkbox is marked in Configuration, a new tab named Device will also be shown.

From here it is possible to set the controls that will be accessible from within the Device window:

- Programming Button.
- Reset.




Figure 131 Device in Z41 Lite and Pro (Configuration Page)

Each of the two controls can be labelled on screen with a custom text (parameter Label).

In Z41 COM, in addition, the indicators listed in the section 2.3.2 can be enabled in this page, as shows the following figure:




Figure 132 Device in Z41 COM (Configuration Page)

Please refer to section 2.3.1 for details.

3.6.3 PROGRAM CONFIGURATION

If the Program Configuration checkbox is marked in Configuration, a new tab named Program Configuration will also be shown.

Configuration Page	Parameter	Status	Label	
+ MAIN CONFIGURATION	KNX	<input checked="" type="checkbox"/>		
	Label		<input type="text"/>	
	Program Version	<input checked="" type="checkbox"/>		
	Label		<input type="text"/>	
	IP Address	<input checked="" type="checkbox"/>		
	Label		<input type="text"/>	
	MAC Address	<input checked="" type="checkbox"/>		
	Label		<input type="text"/>	
	Configuration			
	Device			
Program configuration				
Profile				

Figure 133 Program Configuration (Configuration Page)

From here it is possible to set the indicators that will be included into the Program Configuration window:

- **KNX** (individual address).
- **Program Version.**

In addition, for the Z41 Pro to select two other indicators will also be possible:

- **IP Address.**
- **MAC Address.**

Each indicator can be labelled on screen with a custom text (parameter **Label**).

Note: In Z41 COM this indicators can be set in the Device tab (see section 3.6.2)

Please refer to section 2.3.2 for details.

3.6.4 PROFILE

If the Profile checkbox is marked in Configuration, a new tab named Profile will also be shown.




Figure 134 Configuration (Profile Page)

From here it is possible to set the controls that will be accessible from within the Profile window:

- **Brightness,**
- **Contrast,**
- **Melody,**
- **Theme.**

Each control can be labelled on screen with a custom text (parameter Label).

Please refer to section 2.3.3 for details.

3.6.5 VIDEO INTERCOM CONFIGURATION (Z41 COM)

If the Video Intercom Configuration checkbox is marked in Configuration, a new tab with the same name will also be shown.




Figure 135 Configuration (Video Intercom Configuration Page)

From here it is possible to set the controls that will be accessible from within the Video Intercom configuration window:

- Ringtone,
- Ringtone Volume,
- “Do Not Disturb” Mode: Enabling,
- “Do Not Disturb” Mode: Timing,
- IP Address.

Each control can be labelled on screen with a custom text (parameter Label).

Please refer to section 2.3.4 for details.

3.7 THERMOSTAT N




Figure 136 Configuration Screen (Thermostat n)

When functions “Thermostat 1” and “Thermostat 2” from the General screen under the Main configuration tab are enabled, the integrator will be shown two more tabs, both similar to each other, for the parameterisation of these functions independently. Under each of the tabs, a set of screens (Configuration, Setpoint, etc.) is provided to define the type of the thermostatic control the user will be performing from Z41 Pro / Lite / COM.

Note: for further information about the behaviour and the parameterisation of the Zennio “Building” thermostat implemented by Z41 Pro / Lite / COM, please refer to the specific documentation (“**Building Thermostat**”) available at www.zennio.com.

3.8 INPUTS (Z41 PRO AND Z41 LITE)

3.8.1 CONFIGURATION

Z41 Pro / Lite incorporates **two analogue/digital inputs**, each configurable as a:

- **Binary Input**, for the connection of a pushbutton or a switch/sensor.
- **Temperature Probe**, to connect a temperature from Zennio.
- **Motion Detector**, to connect a motion detector (models ZN1IO-DETEC-X and ZN1IO-DETEC-P from Zennio).

Important: *older models of the Zennio motion detector (e.g., ZN1IO-DETEC and ZN1IO-DETEC-N) will not work properly with Z41 Pro / Lite.*

When **Inputs** has been activated in the General screen (see section 3.2.1), the following drop-down lists will be available for the selection of the specific functions required.




Figure 137 Inputs

All inputs are disabled by default. Depending on the function selected for each input, additional tabs will be included in the menu on the left.

3.8.2 BINARY INPUT

Please refer to the specific user manual “**Binary Inputs**”, available in the Z41 Pro / Lite product section, at the Zennio website (www.zennio.com).

3.8.3 TEMPERATURE PROBE

Please refer to the specific user manual “**Temperature Probe**”, available in the Z41 Pro / Lite product section, at the Zennio website (www.zennio.com).

3.8.4 MOTION DETECTOR

It is possible to connect motion detectors (models **ZN1IO-DETEC-P** and **ZN1IO-DETEC-X** from Zennio) to the input ports of Z41 Pro / Lite.

Please refer to the specific user manual “**Motion Detector**”, available in the Z41 Pro / Lite product section, at the Zennio website (www.zennio.com).

Notes:

- *The ZN1IO-DETEC-P motion detector is compatible with a variety of Zennio devices. However, depending on the device it is actually being connected to, the functionality may differ slightly. Therefore, please refer specifically to the corresponding product section to obtain the aforementioned document.*
- *Motion detectors with references ZN1IO-DETEC and ZN1IO-DETEC-N are **not compatible** with Z41 Pro / Lite (may report inaccurate measurements if connected to this device).*
- *When connected to Z41 Pro / Lite, the rear micro-switch of model ZN1IO-DETEC-P should be set to position “**Type B**”.*

3.9 STATUS AFTER PROGRAMMING AND BUS FAILURE

After a **power failure** (either of KNX bus or auxiliary power), the status of all the controls will be recovered except:

- 14-byte indicator (see section 3.5.2.1).
- Energy consumption and cost indicators in consumption monitor boxes (see section 3.5.2.5).

On the other hand, after a **software update** the configuration of the following controls is maintained (while they remain in the same box and page in the new version):

- Chronothermostat,
- Calendar,
- Daily timer and Weekly timer (although need to be enabled again),
- Macro,
- Scheduler,
- Logic function.

RGB and RGBW colour selection history, indicators and consumption monitor logs as well as alarm, error and call logs are also maintained after software updating.

ANNEX I. REMOTE CONTROL VIA IP (Z41 PRO AND Z41 COM)

Z41 Pro and Z41 COM feature an Ethernet interface that makes it possible to perform actions over the device by means of remote IP applications. This brings the option to control its functions analogously as if the device were actually being controlled on site.

Moreover, versions 1.1.1 and later of the Z41 Pro / Z41 COM application program make it possible to perform this remote control without an Internet connection, as long as the Z41 device and the mobile terminal remain under the same local area network (LAN)

CONFIGURING Z41 PRO Z41 PRO / Z41 COM

In order to make the Z41 Pro / Z41 COM control function available for remote applications, it is necessary that the integrator specifically enables it in ETS through the **Remote Control through the Internet** parameter from the “Ethernet” window, under the “Main Configuration” tab (see section 3.2.11).




Figure 138 Configuration page with Device Paring enabled.

In addition, before being possible to remotely control Z41 Pro / Z41 COM, it is first necessary to pair it to the remote application. This requires that the integrator also enables the **Device Pairing** parameter in the “Configuration” window, under the “Configuration Page” tab (see section 2.3). After that, Z41 Pro / Z41 COM will include a

new icon into its Configuration page (as in Figure 138), which lets the final user start the pairing process.

The icon of the pairing function contains, on the upper left corner, a service state indicator. This indicator will automatically update if the state changes.






Indicator	Meaning
	No network connection available.
	No Internet access available. (*)
	Waiting for the Remote Control service. (*)
	Connection and service OK.
	Remote control in process (remote device currently connected).

Table 7 Service States

(*) This does not impede remote control through LAN, provided that both Z41 Pro / Z41 COM and the mobile device have been updated to versions that support such feature, are connected to the same local area network and have already been paired. See section [Remote Applications](#).

Note that the decision of disabling back the **Device Pairing** parameter or not after the pairing process is up to the integrator, depending on whether the final user needs or not to be allowed to pair their Z41 Pro / Z41 COM with further remote applications in the future.

It is also remarkable that disabling this icon is independent from disabling the remote control function itself (preventing further pairing does not block the remote access from previously paired devices), and that the access to this icon will be anyway subject to the **security level** set for the Configuration page by the integrator (see section 3.2.8).

Note: *it is possible to pair multiple Z41 Pro / Z41 COM devices to a particular remote application (or mobile device), as well as pairing a particular Z41 Pro / Z41 COM to multiple remote applications (or mobile devices).*

PAIRING PROCEDURE

Once Z41 Pro / Z41 COM has been configured as explained above, pressing on the Device Pairing icon will bring up a pop-up window similar to Figure 139.

The upper section of the pop-up window may display text messages to notify events to the user along the process, while the middle section contains the Pairing Code Request button and an icon with a numeric indicator:



Figure 139 Device Pairing dialog window

- On a short press, the Pairing Code Request button sends a Pairing Code request, which will be responded with an **alphanumeric key word** that Z41 Pro / Z41 COM will show on the upper section of the window, unless a communication error takes place (in such case, the word “ERROR” will be displayed on the screen). The user will be required to enter this key word on the remote application in order to set the link with Z41 Pro / Z41 COM. Note that this process is only required once, so the mobile device can register the particular Z41 Pro / Z41 COM.
- The indicator on the right shows the **currently active pairings** of the device, that is, the number of remote applications or devices Z41 Pro / Z41 COM remains paired to, and from which it can be controlled. The initial value is 0.

Finally, the lower portion of the window comprises the **validation button**, which lets the user confirm the process and close the pop-up window, and the **bin button**, which (after a long press) deletes all current pairings and clears the pairing counter.

'PUSH' NOTIFICATIONS

Z41 Pro / Z41 COM incorporates the “push” notification function, which consists in notifying the mobile devices (no matter if the remote control application has been started or not) about alarm events (see section 3.5.2.5):

- **Alarm activation:** a box that has been assigned the Alarm function has either received the alarm trigger value from the KNX bus, or exceeded the cyclical monitoring period.
- **Alarm confirmation:** a box with an active alarm has been acknowledged by the user.
- **Alarm deactivation:** a box that has already been acknowledged by the user has also received the no-alarm trigger value. Therefore, the alarm has been deactivated and acknowledged.

The above notifications are shown on the mobile device (unless “push” notifications are disabled by the operating system of the device, depending on the user settings) through messages similar to the following figure, and according to the label assigned to the involved alarm box:




Figure 140 Push Notification

Notes:

- *In case of network unavailability, Z41 Pro / Z41 COM will queue all notifications related to the alarm events that may take place and will send them as soon as the network is available.*
- *Queued (unsent) notifications are discarded on external power failures, but not on KNX bus power failures.*
- *In the unlikely event of a very long network failure, the queue may become out of space, and therefore further notifications will not be queued.*

- *Zennio Avance y Tecnología S.L. does not accept any responsibility for losses of “push” messages due to network, hardware or software failures of any kind.*

REMOTE APPLICATIONS

For instructions on configuring and using the available remote applications, please refer to the “**Z41 Remote**” specific document, available at the Zennio home site: <http://www.zennio.com>. This document, in addition, indicates which versions of the remote application provide support for certain functionalities, such as the **remote control through local area networks** (LAN).

ANNEX II. COMMUNICATION OBJECTS OF Z41 LITE AND Z41 PRO

- "Functional range" shows the values that, with independence of any other values permitted by the bus according to the object size, may be of any use or have a particular meaning because of the specifications or restrictions from both the KNX standard or the application program itself.

Number	Size	I/O	Flags	Data type (DPT)	Functional Range	Name	Function
1	3 Bytes	I/O	CTRWU	DPT_TimeOfDay	00:00:00 - 23:59:59	[General] Time	Current Time
2	3 Bytes	I/O	CTRWU	DPT_Date	01/01/1990 - 31/12/2089	[General] Date	Current Date
3	1 Byte		CT---	DPT_SceneControl	0-63; 128-191	[General] Scenes: Send	Scene Value
4	1 Byte	I	C--W-	DPT_SceneNumber		[General] Scenes: Receive	Scene Value
5	2 Bytes	O	CTR--	DPT_Value_Temp	-273.00 - 670760.00	[General] Internal Temperature	Current Temperature (Built-in Sensor)
6	2 Bytes	I	C--WU	DPT_Value_Temp	-273.00 - 670760.00	[General] External Temperature	Temperature to Show in the Display
7	1 Byte	I	C--W-		0-5	[General] Select Language	0 = Main; 1 = Lang. 2; ... ; 4 = Lang. 5
8	2 Bytes	I	C--W-	DPT_LanguageCodeAlpha2_ASCII		[General] Select Language	Language selection through ISO 639-1 two letters code
9	1 Bit	I	C--W-	DPT_Ack	0/1	[General] Illumination	0=No Action; 1=Light Display
10	1 Bit	I	C--W-	DPT_Switch	0/1	[General] Backlight Mode	0=Normal Mode; 1=Night Mode
	1 Bit	I	C--W-	DPT_Switch	0/1	[General] Backlight Mode	0=Night Mode; 1=Normal Mode
11	1 Bit	I	C--W-	DPT_Enable	0/1	[General] Touch Lock	0=Unlocked; 1=Locked
	1 Bit	I	C--W-	DPT_Enable	0/1	[General] Touch Lock	0=Locked; 1=Unlocked
12	1 Bit	O	CTR--	DPT_Switch	0/1	[General] Welcome Object	1-Bit Generic Control
13	1 Bit	I	C--W-	DPT_Switch	0/1	[General] Welcome Object - Additional Condition	Additional Condition Object 1
14	1 Bit	I	C--W-	DPT_Switch	0/1	[General] Welcome Object - Additional Condition	Additional Condition Object 2
15	1 Bit	I	C--W-	DPT_Switch	0/1	[General] Welcome Object - Additional Condition	Additional Condition Object 3
16	1 Bit	I	C--W-	DPT_Switch	0/1	[General] Welcome Object - Additional Condition	Additional Condition Object 4
17	1 Bit	I	C--W-	DPT_Switch	0/1	[General] Welcome Object - Additional Condition	Additional Condition Object 5
18	1 Bit	I	C--W-	DPT_Ack	0/1	[General] Welcome Greeting	1 = Welcome; 0 = Nothing

19-22	14 Bytes	I	C - - W -			[General] Welcome Greeting - Line X	Text to show on the display at Line X
23	1 Byte	I	C - - W -	DPT_Scaling	0% - 100%	[Profile] Brightness	0-100%
24	1 Byte	I	C - - W -	DPT_Scaling	0% - 100%	[Profile] Contrast	0-100%
25	1 Byte	I	C - - W -		0-3	[Profile] Melody	0=Mute; 1=Melody 1; 2=Melody 2; 3=Melody 3
26	1 Byte	I	C - - W -		0-7	[Profile] Theme	0=Ocean; 1=Sky; 2=Night; 3=Twilight; 4=Egg Shell; 5=Seaside; 6=Rioja; 7=Forest
27, 35, 43, 51, 59, 67, 75, 83, 91, 99, 107, 115, 123, 131, 139, 147, 155, 163, 171, 179, 187, 195, 203, 211, 219, 227, 235, 243, 251, 259, 267, 275, 283, 291, 299, 307, 315, 323, 331, 339, 347, 355, 363, 371, 379, 387, 395, 403, 411, 419, 427, 435, 443, 451, 459, 467, 475, 483, 491, 499, 507, 515, 523, 531, 539, 547, 555, 563, 571, 579, 587, 595, 603, 611, 619, 627, 635, 643, 651, 659, 667, 675, 683, 691, 699, 707, 715, 723, 731, 739, 747, 755, 763, 771, 779, 787	1 Bit	I	CT - W U	DPT_Switch	0/1	[Px][Bx] Binary Indicator	1-Bit Indicator
	1 Byte	I	CT - W U	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Enumerated Indicator	0...255
	1 Byte	I	CT - W U	DPT_Value_1_Ucount	0 - 255	[Px][Bx] 1-Byte Unsigned Int Indicator	0...255
	1 Byte	I	CT - W U	DPT_Value_1_Count	-128 - 127	[Px][Bx] 1-Byte Signed Int Indicator	-128...127
	1 Byte	I	CT - W U	DPT_Scaling	0% - 100%	[Px][Bx] Percentage Indicator	0-100%
	2 Bytes	I	CT - W U	DPT_Value_2_Ucount	0 - 65535	[Px][Bx] 2-Byte Unsigned Int Indicator	0...65535
	2 Bytes	I	CT - W U	DPT_Value_2_Count	-32768 - 32767	[Px][Bx] 2-Byte Signed Int Indicator	-32768...32767
	2 Bytes	I	CT - W U	9.xxx	-671088.64 - 670760.96	[Px][Bx] 2-Byte Float Indicator	-671088.64...670760.96
	1 Byte	I	CT - W U	DPT_Scaling	0% - 100%	[Px][Bx] Shutter Position	0%=Top; 100%=Bottom
	1 Byte	I	CT - W U	DPT_Scaling	0% - 100%	[Px][Bx] Light Indicator	0%=Off; 100%=On
	2 Bytes	I	CT - W U	DPT_Value_Temp	-273.00 - 670760.00	[Px][Bx] Temperature Indicator	Absolute Float Value
	1 Bit	I	CT - W U	DPT_Heat_Cool	0/1	[Px][Bx] Mode Indicator	0 = Cool; 1 = Heat
	1 Byte	I	CT - W U	DPT_HVACContrMode	0 = Auto 1 = Heat 3 = Cool 9 = Fan 14 = Dry	[Px][Bx] Mode Indicator	Heat, Cool, Auto, Fan and Dry
	1 Byte	I	CT - W U	DPT_HVACMode	1=Comfort 2=Standby 3=Economy 4=Building Protection	[Px][Bx] Special Mode Indicator	Comfort, Standby, Economy, Building Protection and Auto
	1 Byte	I/O	CTR W U	DPT_Scaling	0% - 100%	[Px][Bx] Red Channel	0-100%
	1 Bit	I	C - - W U	DPT_Alarm	0/1	[Px][Bx] Alarm Trigger	Trigger
	1 Bit	I	CT - W U	DPT_Enable	0/1	[Px][Bx] Weekly Timer Enabling	0 = Disabled; 1 = Enabled
	1 Bit	I	CT - W U	DPT_Enable	0/1	[Px][Bx] Daily Timer Enabling	0 = Disabled; 1 = Enabled
	3 Bytes	I/O	CTR W U	DPT_Colour_RGB	[0 - 255] * 3	[Px][Bx] RGB Color	Red, Green and Blue Components
	1 Bit	I	CT - W U	DPT_Enable	0/1	[Px][Bx] Chrono-thermostat: Enabling	0 = Disabled; 1 = Enabled
	4 Bytes	I	CT - W U	DPT_Value_Power	-3.403E+38...3.403E+38	[Px][Bx] Consumption Monitor: Power	W
	2 Bytes	I	CT - W U	DPT_Power	-670760 - 670760 kW	[Px][Bx] Consumption Monitor: Power	kW
4 Bytes	I	CT - W U	DPT_Value_Volume_Flux	-3.403E+38...3.403E+38	[Px][Bx] Consumption Monitor: Flow	m³/s	
2 Bytes	I	CT - W U	DPT_Value_Volume_Flow	-671088.64 - 670760.96	[Px][Bx] Consumption Monitor: Flow	l/h	
4 Bytes	I	CT - W U	14.xxx	-3.403E+38...3.403E+38	[Px][Bx] 4-Byte Float Indicator	-3.403E+38...3.403E+38	

	4 Bytes	I	CT-WU	DPT_Value_4_Count	-2147483648 - 2147483647	[Px][Bx] 4-Byte Signed Int Indicator	-2147483648...2147483647
	1 Byte	I	CT-WU	DPT_Scaling	0% - 100%	[Px][Bx] Fan Indicator	0 - 100%
	1 Byte	I	CT-WU	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Indicator	Enumerated Value
	1 Bit	I	C--WU	DPT_Switch	0/1	[Px][Bx] Macro: Trigger	0 = Start; 1 = Stop
	1 Bit	I	C--WU	DPT_Switch	0/1	[Px][Bx] Macro: Trigger	0 = Stop; 1 = Start
	1 Bit	I	CT-WU	DPT_Enable	0/1	[Px][Bx] Scheduler Enabling	0 = Disabled; 1 = Enabled
	1 Bit	I	C--WU	DPT_Switch	0/1	[Px][Bx] Logic Function: Trigger	0 = Nothing; 1 = Evaluate
	1 Bit	I	C--WU	DPT_Switch	0/1	[Px][Bx] Logic Function: Trigger	0 = Evaluate; 1 = Nothing
	1 Bit	I	CT-WU	DPT_Enable	0/1	[Px][Bx] Daily Timer Enabling	0 = Enabled; 1 = Disabled
	1 Bit	I	CT-WU	DPT_Enable	0/1	[Px][Bx] Chrono-thermostat: Enabling	0 = Enabled; 1 = Disabled
	1 Bit	I	CT-WU	DPT_Enable	0/1	[Px][Bx] Weekly Timer Enabling	0 = Enabled; 1 = Disabled
	1 Bit	I	CT-WU	DPT_Enable	0/1	[Px][Bx] Scheduler Enabling	0 = Enabled; 1 = Disabled
28, 36, 44, 52, 60, 68, 76, 84, 92, 100, 108, 116, 124, 132, 140, 148, 156, 164, 172, 180, 188, 196, 204, 212, 220, 228, 236, 244, 252, 260, 268, 276, 284, 292, 300, 308, 316, 324, 332, 340, 348, 356, 364, 372, 380, 388, 396, 404, 412, 420, 428, 436, 444, 452, 460, 468, 476, 484, 492, 500, 508, 516, 524, 532, 540, 548, 556, 564, 572, 580, 588, 596, 604, 612, 620, 628, 636, 644, 652, 660, 668, 676, 684, 692, 700, 708, 716, 724, 732, 740, 748, 756, 764, 772, 780, 788	1 Bit	O	CTR--	DPT_Switch	0/1	[Px][Bx] Binary Control	1-Bit Control
	1 Byte	O	CTR--	DPT_Value_1_Ucount	0 - 255	[Px][Bx] 1-Byte Unsigned Int Control	0...255
	1 Byte	O	CTR--	DPT_Value_1_Count	-128 - 127	[Px][Bx] 1-Byte Signed Int Control	-128...127
	1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Px][Bx] Percentage Control	0-100%
	2 Bytes	O	CTR--	DPT_Value_2_Ucount	0 - 65535	[Px][Bx] 2-Byte Unsigned Int Control	0...65535
	2 Bytes	O	CTR--	DPT_Value_2_Count	-32768 - 32767	[Px][Bx] 2-Byte Signed Int Control	-32768...32767
	2 Bytes	O	CTR--	9.xxx	-671088.64 - 670760.96	[Px][Bx] 2-Byte Float Control	-671088.64...670760.96
	1 Byte	O	CTR--	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Enumerated Control	0...255
	1 Bit	O	CTR--	DPT_UpDown	0/1	[Px][Bx] Move Shutter	0=Up; 1=Down
	1 Bit	O	CTR--	DPT_Switch	0/1	[Px][Bx] Light On/Off	0=Off; 1=On
	2 Bytes	O	CTR--	DPT_Value_Temp	-273.00 - 670760.00	[Px][Bx] Temperature Control	Absolute Float Value
	2 Bytes	I/O	CTRW-	DPT_Value_Tempd	-670760.00 - 670760.00	[Px][Bx] Temperature Offset Control	Relative Float Value
	1 Bit	O	CTR--	DPT_Step	0/1	[Px][Bx] Temperature Offset Control	0=Decrease; 1=Increase
	1 Bit	O	CTR--	DPT_Heat_Cool	0/1	[Px][Bx] Mode Control	0=Cool; 1=Heat
	1 Byte	O	CTR--	DPT_HVACContrMode	0 = Auto 1 = Heat 3 = Cool 9 = Fan 14 = Dry	[Px][Bx] Mode Control	Heat, Cool, Auto, Fan and Dry
	1 Byte	O	CTR--	DPT_HVACMode	1=Comfort 2=Standby 3=Economy 4=Building Protection	[Px][Bx] Special Mode Control	Comfort, Standby, Economy, Building Protection and Auto
	1 Byte	I/O	CTRWU	DPT_Scaling	0% - 100%	[Px][Bx] Green Channel	0-100%
	1 Bit	O	CTR--	DPT_Switch	0/1	[Px][Bx] Daily Timer Control	1-Bit Control
	1 Bit	O	CTR--	DPT_Switch	0/1	[Px][Bx] Weekly Timer Control	1-Bit Control
	1 Bit	I	CT-WU	DPT_Ack	0/1	[Px][Bx] Alarm Confirmation	0=No Action; 1=Confirm
2 Bytes	O	CTR--	DPT_Value_Temp	-273.00 - 670760.00	[Px][Bx] Chrono-thermostat:	Absolute Float Value	

						Temperature Setpoint	
1 Bit	O	CTR --	DPT_Bool	0/1	[Px][Bx] Holiday (1 bit)	0 = Holiday; 1 = Workday	
1 Bit	O	CTR --	DPT_Bool	0/1	[Px][Bx] Holiday (1 bit)	0 = Workday; 1 = Holiday	
1 Bit	O	CTR --	DPT_Step	0/1	[Px][Bx] Fan Control (1-Bit)	0 = Decrease; 1 = Increase	
1 Byte	O	CTR --	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	Auto, 20%, 40%, 60%, 80%, 100%	
1 Byte	O	CTR --	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	Auto, 25%, 50%, 75%, 100%	
1 Byte	O	CTR --	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	Auto, 33%, 67%, 100%	
1 Byte	O	CTR --	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	Auto, 50%, 100%	
1 Byte	O	CTR --	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	Auto, 100%	
1 Byte	O	CTR --	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	0%, 25%, 50%, 75%, 100%	
1 Byte	O	CTR --	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	0%, 33%, 67%, 100%	
1 Byte	O	CTR --	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	0%, 50%, 100%	
1 Byte	O	CTR --	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	0%, 100%	
1 Byte	O	CTR --	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	0%, 20%, 40%, 60%, 80%, 100%	
1 Byte	O	CTR --	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	20%, 40%, 60%, 80%, 100%	
1 Byte	O	CTR --	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	25%, 50%, 75%, 100%	
1 Byte	O	CTR --	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	33%, 67%, 100%	
1 Byte	O	CTR --	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	50%, 100%	
1 Byte	O	CTR --	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	100%	
1 Byte	O	CTR --	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	Auto, 1, 2, 3, 4, 5	
1 Byte	O	CTR --	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	Auto, 1, 2, 3, 4	
1 Byte	O	CTR --	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	Auto, 1, 2, 3	
1 Byte	O	CTR --	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	Auto, 1, 2	
1 Byte	O	CTR --	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	Auto, 1	
1 Byte	O	CTR --	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	0, 1, 2, 3, 4, 5	
1 Byte	O	CTR --	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	0, 1, 2, 3, 4	
1 Byte	O	CTR --	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	0, 1, 2, 3	
1 Byte	O	CTR --	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	0, 1, 2	
1 Byte	O	CTR --	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	0, 1	
1 Byte	O	CTR --	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	1, 2, 3, 4, 5	
1 Byte	O	CTR --	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	1, 2, 3, 4	
1 Byte	O	CTR --	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	1, 2, 3	
1 Byte	O	CTR --	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	1, 2	
1 Byte	O	CTR --	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	1	
1 Bit	O	CTR --	DPT_Switch	0/1	[Px][Bx] Macro: Started	0 = Macro Started; 1 = Nothing	
1 Bit	O	CTR --	DPT_Switch	0/1	[Px][Bx] Macro: Started	0 = Nothing; 1 = Macro Started	

29, 37, 45, 53, 61, 69, 77, 85, 93, 101, 109, 117, 125, 133, 141, 149, 157, 165, 173, 181, 189, 197, 205, 213, 221, 229, 237, 245, 253, 261, 269, 277, 285, 293, 301, 309, 317, 325, 333, 341, 349, 357, 365, 373, 381, 389, 397, 405, 413, 421, 429, 437, 445, 453, 461, 469, 477, 485, 493, 501, 509, 517, 525, 533, 541, 549, 557, 565, 573, 581, 589, 597, 605, 613, 621, 629, 637, 645, 653, 661, 669, 677, 685, 693, 701, 709, 717, 725, 733, 741, 749, 757, 765, 773, 781, 789	1 Bit	O	CTR--	DPT_Step	0/1	[Px][Bx] Stop Shutter	0=Stop/Step Up; 1=Stop/Step Down
	4 Bit	O	CTR--	DPT_Control_Dimming	0x0 (Stop) 0x1 (Dec. by 100%) 0x2 (Dec. by 50%) 0x3 (Dec. by 25%) 0x4 (Dec. by 12%) 0x5 (Dec. by 6%) 0x6 (Dec. by 3%) 0x7 (Dec. by 1%) 0x8 (Stop) 0x9 (Inc. by 100%) 0xA (Inc. by 50%) 0xB (Inc. by 25%) 0xC (Inc. by 12%) 0xD (Inc. by 6%) 0xE (Inc. by 3%) 0xF (Inc. by 1%)	[Px][Bx] Light Dimming	4-bit Dimming Control
	1 Byte	I/O	CTR WU	DPT_Scaling	0% - 100%	[Px][Bx] Blue Channel	0-100%
	2 Bytes	I	CT-WU		-670760,00 - 670760,00	[Px][Bx] Consumption Monitor: Cost	Local Currency
	1 Bit	O	CTR--	DPT_Switch	0/1	[Px][Bx] Chrono-thermostat: On/Off	0 = Off; 1 = On
	1 Byte	I/O	CTR WU	DPT_Scaling	0% - 100%	[Px][Bx] White Channel	0-100%
	1 Byte	O	CTR--	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Holiday (1 Byte)	0...255
	1 Bit	I/O	CTR WU	DPT_Switch	0/1	[Px][Bx] Fan Control - Auto Mode	Switch Auto Mode on Short Press
	1 Bit	I/O	CTR WU	DPT_Switch	0/1	[Px][Bx] Fan Control - Auto Mode	Switch Auto Mode on Long Press
	30, 38, 46, 54, 62, 70, 78, 86, 94, 102, 110, 118, 126, 134, 142, 150, 158, 166, 174, 182, 190, 198, 206, 214, 222, 230, 238, 246, 254, 262, 270, 278, 286, 294, 302, 310, 318, 326, 334, 342, 350, 358, 366, 374, 382, 390, 398, 406, 414, 422, 430, 438, 446, 454, 462, 470, 478, 486, 494, 502, 510, 518, 526, 534, 542, 550, 558, 566, 574, 582, 590, 598, 606, 614, 622, 630, 638, 646, 654, 662, 670, 678,	4 Bit	O	CTR--	DPT_Control_Dimming	0x0 (Stop) 0x1 (Dec. by 100%) ... 0x7 (Dec. by 1%) 0x8 (Stop) 0x9 (Inc. by 100%) ... 0xF (Inc. by 1%)	[Px][Bx] Light Dimming
1 Byte		O	CTR--	DPT_Scaling	0% - 100%	[Px][Bx] Shutter Positioning (Only Macros)	0%=Top; 100%=Bottom
1 Byte		O	CTR--	DPT_Scaling	0% - 100%	[Px][Bx] Precise Dimming (Only Macros)	1-Byte Dimmer Control

686, 694, 702, 710, 718, 726, 734, 742, 750, 758, 766, 774, 782, 790							
31, 39, 47, 55, 63, 71, 79, 87, 95, 103, 111, 119, 127, 135, 143, 151, 159, 167, 175, 183, 191, 199, 207, 215, 223, 231, 239, 247, 255, 263, 271, 279, 287, 295, 303, 311, 319, 327, 335, 343, 351, 359, 367, 375, 383, 391, 399, 407, 415, 423, 431, 439, 447, 455, 463, 471, 479, 487, 495, 503, 511, 519, 527, 535, 543, 551, 559, 567, 575, 583, 591, 599, 607, 615, 623, 631, 639, 647, 655, 663, 671, 679, 687, 695, 703, 711, 719, 727, 735, 743, 751, 759, 767, 775, 783, 791	4 Bytes 4 Bytes 4 Bytes 14 Bytes	I I I I	CT - W U CT - W U CT - W U CT - W U	DPT_Value_Volume DPT_ActiveEnergy DPT_ActiveEnergy_kWh	-3.403E+38 - 3.403E+38 -3.403E+38 - 3.403E+38 -2147483648 - 2147483647	[Px][Bx] Consumption Monitor: Volume [Px][Bx] Consumption Monitor: Energy [Px][Bx] Consumption Monitor: Energy [Px][Bx] 14-Byte Text Indicator	m ³ Wh kWh UTF-8 Text String
32, 40, 48, 56, 64, 72, 80, 88, 96, 104, 112, 120, 128, 136, 144, 152, 160, 168, 176, 184, 192, 200, 208, 216, 224, 232, 240, 248, 256, 264, 272, 280, 288, 296, 304, 312, 320, 328, 336, 344, 352, 360, 368, 376, 384, 392, 400, 408, 416, 424, 432, 440, 448, 456, 464, 472, 480, 488, 496, 504, 512, 520, 528, 536, 544, 552, 560, 568, 576, 584, 592, 600, 608, 616, 624, 632, 640, 648, 656, 664, 672, 680,	2 Bytes	I	CT - W U		-670760,00 - 670760,00	[Px][Bx] Consumption Monitor: CO ₂	kg CO ₂

688, 696, 704, 712, 720, 728, 736, 744, 752, 760, 768, 776, 784, 792						
33, 41, 49, 57, 65, 73, 81, 89, 97, 105, 113, 121, 129, 137, 145, 153, 161, 169, 177, 185, 193, 201, 209, 217, 225, 233, 241, 249, 257, 265, 273, 281, 289, 297, 305, 313, 321, 329, 337, 345, 353, 361, 369, 377, 385, 393, 401, 409, 417, 425, 433, 441, 449, 457, 465, 473, 481, 489, 497, 505, 513, 521, 529, 537, 545, 553, 561, 569, 577, 585, 593, 601, 609, 617, 625, 633, 641, 649, 657, 665, 673, 681, 689, 697, 705, 713, 721, 729, 737, 745, 753, 761, 769, 777, 785, 793	1 Bit	O	CTR--	DPT_Switch	0/1	[Px][Bx] Consumption Monitor: Request 0=No Action; 1=Request
34, 42, 50, 58, 66, 74, 82, 90, 98, 106, 114, 122, 130, 138, 146, 154, 162, 170, 178, 186, 194, 202, 210, 218, 226, 234, 242, 250, 258, 266, 274, 282, 290, 298, 306, 314, 322, 330, 338, 346, 354, 362, 370, 378, 386, 394, 402, 410, 418, 426, 434, 442, 450, 458, 466, 474, 482, 490, 498, 506, 514, 522, 530, 538, 546, 554, 562, 570, 578, 586, 594, 602, 610, 618, 626, 634, 642, 650, 658, 666, 674, 682,	1 Bit	O	CTR--	DPT_Reset	0/1	[Px][Bx] Consumption Monitor: Reset 0=No Action; 1=Reset

690, 698, 706, 714, 722, 730, 738, 746, 754, 762, 770, 778, 786, 794							
795, 801	1 Bit	I	C--W-	DPT_Enable	0/1	[Ix] Input Lock	0 = Unlock; 1 = Lock
796, 802	1 Bit		CT---	DPT_Switch	0/1	[Ix] [Short Press] 0	Sending of 0
	1 Bit		CT---	DPT_Switch	0/1	[Ix] [Short Press] 1	Sending of 1
	1 Bit	I	CT-W-	DPT_Switch	0/1	[Ix] [Short Press] 0/1 Switching	Switching 0/1
	1 Bit		CT---	DPT_UpDown	0/1	[Ix] [Short Press] Move Up Shutter	Sending of 0 (Up)
	1 Bit		CT---	DPT_UpDown	0/1	[Ix] [Short Press] Move Down Shutter	Sending of 1 (Down)
	1 Bit		CT---	DPT_UpDown	0/1	[Ix] [Short Press] Move Up/Down Shutter	Switching 0/1 (Up/Down)
	1 Bit		CT---	DPT_Step	0/1	[Ix] [Short Press] Stop/Step Up Shutter	Sending of 0 (Stop/Step Up)
	1 Bit		CT---	DPT_Step	0/1	[Ix] [Short Press] Stop/Step Down Shutter	Sending of 1 (Stop/Step Down)
	1 Bit		CT---	DPT_Step	0/1	[Ix] [Short Press] Stop/Step Shutter (Switched)	Switching of 0/1 (Stop/Step Up/Down)
	4 Bit		CT---	DPT_Control_Dimming	0x0 (Stop) 0x1 (Dec. by 100%) ... 0x7 (Dec. by 1%) 0x8 (Stop) 0x9 (Inc. by 100%) ... 0xF (Inc. by 1%)	[Ix] [Short Press] Brighter	Increase Brightness
	4 Bit		CT---	DPT_Control_Dimming	0x0 (Stop) 0x1 (Dec. by 100%) ... 0x7 (Dec. by 1%) 0x8 (Stop) 0x9 (Inc. by 100%) ... 0xF (Inc. by 1%)	[Ix] [Short Press] Darker	Decrease Brightness
	4 Bit		CT---	DPT_Control_Dimming	0x0 (Stop) 0x1 (Dec. by 100%) ... 0x7 (Dec. by 1%) 0x8 (Stop) 0x9 (Inc. by 100%) ... 0xF (Inc. by 1%)	[Ix] [Short Press] Brighter/Darker	Switch Bright/Dark
	1 Bit		CT---	DPT_Switch	0/1	[Ix] [Short Press] Light On	Sending of 1 (On)
	1 Bit		CT---	DPT_Switch	0/1	[Ix] [Short Press] Light Off	Sending of 0 (Off)
1 Bit	I	CT-W-	DPT_Switch	0/1	[Ix] [Short Press] Light On/Off	Switching 0/1	
1 Byte		CT---	DPT_SceneControl	0-63; 128-191	[Ix] [Short Press] Run Scene	Sending of 0 - 63	

	1 Byte		CT---	DPT_SceneControl	0-63; 128-191	[Ix] [Short Press] Save Scene	Sending of 128 - 191
	1 Bit	I/O	CTRW-	DPT_Switch	0/1	[Ix] [Switch/Sensor] Edge	Sending of 0 or 1
	1 Byte		CT---	DPT_Value_1_Ucount	0 - 255	[Ix] [Short Press] Constant Value (Integer)	0 - 255
	1 Byte		CT---	DPT_Scaling	0% - 100%	[Ix] [Short Press] Constant Value (Percentage)	0% - 100%
	2 Bytes		CT---	DPT_Value_2_Ucount	0 - 65535	[Ix] [Short Press] Constant Value (Integer)	0 - 65535
	2 Bytes		CT---	9.xxx	-671088.64 - 670760.96	[Ix] [Short Press] Constant Value (Float)	Float Value
796, 797, 802, 803	2 Bytes	O	CTR--	DPT_Value_2_Ucount	0 - 65535	[Ix] [Pulse Counter] Counter	Number of Pulses
797, 803	1 Byte	I	C--W-	DPT_Scaling	0% - 100%	[Ix] [Short Press] Shutter Status (Input)	0% = Top; 100% = Bottom
	1 Byte	I	C--W-	DPT_Scaling	0% - 100%	[Ix] [Short Press] Dimming Status (Input)	0% - 100%
798, 804	1 Bit		CT---	DPT_Switch	0/1	[Ix] [Long Press] 0	Sending of 0
	1 Bit		CT---	DPT_Switch	0/1	[Ix] [Long Press] 1	Sending of 1
	1 Bit	I	CT-W-	DPT_Switch	0/1	[Ix] [Long Press] 0/1 Switching	Switching 0/1
	1 Bit		CT---	DPT_UpDown	0/1	[Ix] [Long Press] Move Up Shutter	Sending of 0 (Up)
	1 Bit		CT---	DPT_UpDown	0/1	[Ix] [Long Press] Move Down Shutter	Sending of 1 (Down)
	1 Bit		CT---	DPT_UpDown	0/1	[Ix] [Long Press] Move Up/Down Shutter	Switching 0/1 (Up/Down)
	1 Bit		CT---	DPT_Step	0/1	[Ix] [Long Press] Stop/Step Up Shutter	Sending of 0 (Stop/Step Up)
	1 Bit		CT---	DPT_Step	0/1	[Ix] [Long Press] Stop/Step Down Shutter	Sending of 1 (Stop/Step Down)
	1 Bit		CT---	DPT_Step	0/1	[Ix] [Long Press] Stop/Step Shutter (Switched)	Switching of 0/1 (Stop/Step Up/Down)
	4 Bit		CT---	DPT_Control_Dimming	0x0 (Stop) 0x1 (Dec. by 100%) ... 0x7 (Dec. by 1%) 0x8 (Stop) 0x9 (Inc. by 100%) ... 0xF (Inc. by 1%)	[Ix] [Long Press] Brighter	Long Pr. -> Brighter; Release -> Stop
	4 Bit		CT---	DPT_Control_Dimming	0x0 (Stop) 0x1 (Dec. by 100%) ... 0x7 (Dec. by 1%) 0x8 (Stop) 0x9 (Inc. by 100%) ... 0xF (Inc. by 1%)	[Ix] [Long Press] Darker	Long Pr. -> Darker; Release -> Stop
	4 Bit		CT---	DPT_Control_Dimming	0x0 (Stop)	[Ix] [Long Press] Brighter/Darker	Long Pr. -> Brighter/Darker;

					0x1 (Dec. by 100%) ... 0x7 (Dec. by 1%) 0x8 (Stop) 0x9 (Inc. by 100%) ... 0xF (Inc. by 1%)		Release -> Stop
	1 Bit		CT----	DPT_Switch	0/1	[Ix] [Long Press] Light On	Sending of 1 (On)
	1 Bit		CT----	DPT_Switch	0/1	[Ix] [Long Press] Light Off	Sending of 0 (Off)
	1 Bit	I	CT-W-	DPT_Switch	0/1	[Ix] [Long Press] Light On/Off	Switching 0/1
	1 Byte		CT----	DPT_SceneControl	0-63; 128-191	[Ix] [Long Press] Run Scene	Sending of 0 - 63
	1 Byte		CT----	DPT_SceneControl	0-63; 128-191	[Ix] [Long Press] Save Scene	Sending of 128 - 191
	1 Bit	O	CTR--	DPT_Alarm	0/1	[Ix] [Switch/Sensor] Alarm: Breakdown or Sabotage	1 = Alarm; 0 = No Alarm
	2 Bytes		CT----	9.xxx	-671088.64 - 670760.96	[Ix] [Long Press] Constant Value (Float)	Float Value
	2 Bytes		CT----	DPT_Value_2_Ucount	0 - 65535	[Ix] [Long Press] Constant Value (Integer)	0 - 65535
	1 Byte		CT----	DPT_Scaling	0% - 100%	[Ix] [Long Press] Constant Value (Percentage)	0% - 100%
	1 Byte		CT----	DPT_Value_1_Ucount	0 - 255	[Ix] [Long Press] Constant Value (Integer)	0 - 255
	1 Bit		CT----	DPT_Switch	0/1	[Ix] [Double Press] 0	Sending of 0
	1 Bit		CT----	DPT_Switch	0/1	[Ix] [Double Press] 1	Sending of 1
	1 Bit	I	CT-W-	DPT_Switch	0/1	[Ix] [Double Press] 0/1 Switching	Switching 0/1
	1 Byte		CT----	DPT_SceneControl	0-63; 128-191	[Ix] [Double Press] Save Scene	Sending of 128 - 191
	1 Byte		CT----	DPT_SceneControl	0-63; 128-191	[Ix] [Double Press] Run Scene	Sending of 0 - 63
799, 805	1 Bit		CT----	DPT_Trigger	0/1	[Ix] [Long Press/Release] Stop Shutter	Release -> Stop Shutter
	1 Bit	I	C--W-	DPT_Reset	0/1	[Ix] [Pulse Counter] Reset	0 = No Action; 1 = Reset
800, 806	1 Byte	I	C--W-	DPT_Scaling	0% - 100%	[Ix] [Long Press] Dimming Status (Input)	0% - 100%
	1 Byte	I	C--W-	DPT_Scaling	0% - 100%	[Ix] [Long Press] Shutter Status (Input)	0% = Top; 100% = Bottom
807	1 Byte	I	C--W-	DPT_SceneControl	0-63; 128-191	[Motion Detector] Scene Input	Scene Value
808	1 Byte		CT----	DPT_SceneControl	0-63; 128-191	[Motion Detector] Scene Output	Scene Value
809, 838	1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Ix] Luminosity	0-100%
810, 839	1 Bit	O	CTR--	DPT_Alarm	0/1	[Ix] Open Circuit Error	0 = No Error; 1 = Open Circuit Error
811, 840	1 Bit	O	CTR--	DPT_Alarm	0/1	[Ix] Short Circuit Error	0 = No Error; 1 = Short Circuit Error
812, 841	1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Ix] Presence State (Scaling)	0-100%
813, 842	1 Byte	O	CTR--	DPT_HVACMode	1=Comfort 2=Standby 3=Economy 4=Building Protection	[Ix] Presence State (HVAC)	Auto, Comfort, Standby, Economy, Building Protection

814, 843	1 Bit	O	CTR--	DPT_Occupancy	0/1	[Ix] Presence State (Binary)	Binary Value
	1 Bit	O	CTR--	DPT_Ack	0/1	[Ix] Presence: Slave Output	1 = Motion Detected
815, 844	1 Bit	I	C--W-	DPT_Window_Door	0/1	[Ix] Presence Trigger	Binary Value to Trigger the Presence Detection
816, 845	1 Bit	I	C--W-	DPT_Ack	0/1	[Ix] Presence: Slave Input	0 = Nothing; 1 = Detection from slave device
817, 846	2 Bytes	I	C--W-	DPT_TimePeriodSec	0-65535	[Ix] Presence: Waiting Time	0-65535 s.
818, 847	2 Bytes	I	C--W-	DPT_TimePeriodSec	1-65535	[Ix] Presence: Listening Time	1-65535 s.
819, 848	1 Bit	I	C--W-	DPT_Enable	0/1	[Ix] Presence: Enable	According to parameters
820, 849	1 Bit	I	C--W-	DPT_Switch	0/1	[Ix] Presence: Day/Night	According to parameters
821, 850	1 Bit	O	CTR--	DPT_Occupancy	0/1	[Ix] Presence: Occupancy State	0 = Not Occupied; 1 = Occupied
822, 851	1 Bit	I	C--W-	DPT_Ack	0/1	[Ix] External Motion Detection	0 = Nothing; 1 = Motion detected by an external sensor
823, 828, 833, 852, 857, 862	1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Ix] [Cx] Detection State (Scaling)	0-100%
824, 829, 834, 853, 858, 863	1 Byte	O	CTR--	DPT_HVACMode	1=Comfort 2=Standby 3=Economy 4=Building Protection	[Ix] [Cx] Detection State (HVAC)	Auto, Comfort, Standby, Economy, Building Protection
825, 830, 835, 854, 859, 864	1 Bit	O	CTR--	DPT_Switch	0/1	[Ix] [Cx] Detection State (Binary)	Binary Value
826, 831, 836, 855, 860, 865	1 Bit	I	C--W-	DPT_Enable	0/1	[Ix] [Cx] Enable Channel	According to parameters
827, 832, 837, 856, 861, 866	1 Bit	I	C--W-	DPT_Switch	0/1	[Ix] [Cx] Force State	0 = No Detection; 1 = Detection
867, 871	2 Bytes	O	CTR--	DPT_Value_Temp	-273.00 - 670760.00	[Ix] Current Temperature	Temperature Sensor Value
868, 872	1 Bit	O	CTR--	DPT_Alarm	0/1	[Ix] Overcooling	0 = No Alarm; 1 = Alarm
869, 873	1 Bit	O	CTR--	DPT_Alarm	0/1	[Ix] Overheating	0 = No Alarm; 1 = Alarm
870, 874	1 Bit	O	CTR--	DPT_Alarm	0/1	[Ix] Probe Error	0 = No Alarm; 1 = Alarm
875	1 Byte	I	C--W-	DPT_SceneControl	0-63; 128-191	[Thermostat] Scene Input	Scene Value
876, 906	2 Bytes	I	C--W-	DPT_Value_Temp	-273.00 - 670760.00	[Tx] Temperature Source 1	External Sensor Temperature
877, 907	2 Bytes	I	C--W-	DPT_Value_Temp	-273.00 - 670760.00	[Tx] Temperature Source 2	External Sensor Temperature
878, 908	2 Bytes	O	CTR--	DPT_Value_Temp	-273.00 - 670760.00	[Tx] Effective Temperature	Effective Control Temperature
879, 909	1 Byte	I	C--W-	DPT_HVACMode	1=Comfort 2=Standby 3=Economy 4=Building Protection	[Tx] Special Mode	1-byte HVAC Mode
880, 910	1 Bit	I	C--W-	DPT_Ack	0/1	[Tx] Special Mode: Comfort	0 = Nothing; 1 = Trigger
	1 Bit	I	C--W-	DPT_Switch	0/1	[Tx] Special Mode: Comfort	0 = Off; 1 = On
881, 911	1 Bit	I	C--W-	DPT_Ack	0/1	[Tx] Special Mode: Standby	0 = Nothing; 1 = Trigger
	1 Bit	I	C--W-	DPT_Switch	0/1	[Tx] Special Mode: Standby	0 = Off; 1 = On

882, 912	1 Bit	I	C--W-	DPT_Ack	0/1	[Tx] Special Mode: Economy	0 = Nothing; 1 = Trigger
	1 Bit	I	C--W-	DPT_Switch	0/1	[Tx] Special Mode: Economy	0 = Off; 1 = On
883, 913	1 Bit	I	C--W-	DPT_Ack	0/1	[Tx] Special Mode: Protection	0 = Nothing; 1 = Trigger
	1 Bit	I	C--W-	DPT_Switch	0/1	[Tx] Special Mode: Protection	0 = Off; 1 = On
884, 914	1 Bit	I	C--W-	DPT_Window_Door	0/1	[Tx] Window Status (Input)	0 = Closed; 1 = Open
885, 915	1 Bit	I	C--W-	DPT_Ack	0/1	[Tx] Comfort Prolongation	0 = Nothing; 1 = Timed Comfort
886, 916	1 Byte	O	CTR--	DPT_HVACMode	1=Comfort 2=Standby 3=Economy 4=Building Protection	[Tx] Special Mode Status	1-byte HVAC Mode
887, 917	2 Bytes	I	C--W-	DPT_Value_Temp	-273.00 - 670760.00	[Tx] Setpoint	Thermostat Setpoint Input
	2 Bytes	I	C--W-	DPT_Value_Temp	-273.00 - 670760.00	[Tx] Basic Setpoint	Reference Setpoint
888, 918	1 Bit	I	C--W-	DPT_Step	0/1	[Tx] Setpoint Step	0 = -0.5°C; 1 = +0.5°C
889, 919	2 Bytes	I	C--W-	DPT_Value_Tempd	-670760.00 - 670760.00	[Tx] Setpoint Offset	Float Offset Value
890, 920	2 Bytes	O	CTR--	DPT_Value_Temp	-273.00 - 670760.00	[Tx] Setpoint Status	Current Setpoint
891, 921	2 Bytes	O	CTR--	DPT_Value_Temp	-273.00 - 670760.00	[Tx] Basic Setpoint Status	Current Basic Setpoint
892, 922	2 Bytes	O	CTR--	DPT_Value_Tempd	-670760.00 - 670760.00	[Tx] Setpoint Offset Status	Current Setpoint Offset
893, 923	1 Bit	I	C--W-	DPT_Reset	0/1	[Tx] Setpoint Reset	Reset Setpoint to Default
	1 Bit	I	C--W-	DPT_Reset	0/1	[Tx] Offset Reset	Reset offset
894, 924	1 Bit	I	C--W-	DPT_Heat_Cool	0/1	[Tx] Mode	0 = Cool; 1 = Heat
895, 925	1 Bit	O	CTR--	DPT_Heat_Cool	0/1	[Tx] Mode Status	0 = Cool; 1 = Heat
896, 926	1 Bit	I	C--W-	DPT_Switch	0/1	[Tx] On/Off	0 = Off; 1 = On
897, 927	1 Bit	O	CTR--	DPT_Switch	0/1	[Tx] On/Off Status	0 = Off; 1 = On
898, 928	1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Tx] Control Variable (Cool)	PI Control (Continuous)
899, 929	1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Tx] Control Variable (Heat)	PI Control (Continuous)
900, 930	1 Bit	O	CTR--	DPT_Switch	0/1	[Tx] Control Variable (Cool)	2-Point Control
	1 Bit	O	CTR--	DPT_Switch	0/1	[Tx] Control Variable (Cool)	PI Control (PWM)
901, 931	1 Bit	O	CTR--	DPT_Switch	0/1	[Tx] Control Variable (Heat)	2-Point Control
	1 Bit	O	CTR--	DPT_Switch	0/1	[Tx] Control Variable (Heat)	PI Control (PWM)
902, 932	1 Bit	O	CTR--	DPT_Switch	0/1	[Tx] Additional Cool	Temp >= (Setpoint+Band) => "1"
903, 933	1 Bit	O	CTR--	DPT_Switch	0/1	[Tx] Additional Heat	Temp <= (Setpoint-Band) => "1"
904, 934	1 Bit	O	CTR--	DPT_Switch	0/1	[Tx] PI State (Cool)	0 = PI signal 0%; 1 = PI signal greater than 0%
905, 935	1 Bit	O	CTR--	DPT_Switch	0/1	[Tx] PI State (Heat)	0 = PI signal 0%; 1 = PI signal greater than 0%

ANNEX III. COMMUNICATION OBJECTS OF Z41 COM

- "Functional range" shows the values that, with independence of any other values permitted by the bus according to the object size, may be of any use or have a particular meaning because of the specifications or restrictions from both the KNX standard or the application program itself.

Number	Size	I/O	Flags	Data type (DPT)	Functional Range	Name	Function
1	3 Bytes	I/O	CTRWU	DPT_TimeOfDay	00:00:00 - 23:59:59	[General] Time	Current Time
2	3 Bytes	I/O	CTRWU	DPT_Date	01/01/1990 - 31/12/2089	[General] Date	Current Date
3	1 Byte		CT---	DPT_SceneControl	0-63; 128-191	[General] Scenes: Send	Scene Value
4	1 Byte	I	C--W-	DPT_SceneNumber		[General] Scenes: Receive	Scene Value
5	2 Bytes	O	CTR--	DPT_Value_Temp	-273.00 - 670760.00	[General] Internal Temperature	Current Temperature (Built-in Sensor)
6	2 Bytes	I	C--WU	DPT_Value_Temp	-273.00 - 670760.00	[General] External Temperature	Temperature to Show in the Display
7	1 Byte	I	C--W-		0-5	[General] Select Language	0 = Main; 1 = Lang. 2; ... ; 4 = Lang. 5
8	2 Bytes	I	C--W-	DPT_LanguageCodeAlpha2_ASCII		[General] Select Language	Language Selection Through ISO 639_1 Two Letters Code
9	1 Bit	I	C--W-	DPT_Ack	0/1	[General] Illumination	0 = No Action; 1 = Light Display
10	1 Bit	I	C--W-	DPT_Switch	0/1	[General] Backlight Mode	0 = Normal Mode; 1 = Night Mode
	1 Bit	I	C--W-	DPT_Switch	0/1	[General] Backlight Mode	0 = Night Mode; 1 = Normal Mode
11	1 Bit	I	C--W-	DPT_Enable	0/1	[General] Touch Lock	0 = Unlocked; 1 = Locked
	1 Bit	I	C--W-	DPT_Enable	0/1	[General] Touch Lock	0 = Locked; 1 = Unlocked
12	1 Bit	O	CTR--	DPT_Switch	0/1	[General] Welcome Object	1-Bit Generic Control
13	1 Bit	I	C--W-	DPT_Switch	0/1	[General] Welcome Object - Additional Condition	Additional Condition Object 1
14	1 Bit	I	C--W-	DPT_Switch	0/1	[General] Welcome Object - Additional Condition	Additional Condition Object 2
15	1 Bit	I	C--W-	DPT_Switch	0/1	[General] Welcome Object - Additional Condition	Additional Condition Object 3
16	1 Bit	I	C--W-	DPT_Switch	0/1	[General] Welcome Object - Additional Condition	Additional Condition Object 4
17	1 Bit	I	C--W-	DPT_Switch	0/1	[General] Welcome Object - Additional Condition	Additional Condition Object 5
18	1 Bit	I	C--W-	DPT_Ack	0/1	[General] Welcome Greeting	1 = Welcome; 0 = Nothing
19-22	14 Bytes	I	C--W-			[General] Welcome Greeting - Line X	Text to show on the display at

							Line X
23	1 Byte	I	C - - W -	DPT_Scaling	0% - 100%	[Profile] Brightness	0-100%
24	1 Byte	I	C - - W -	DPT_Scaling	0% - 100%	[Profile] Contrast	0-100%
25	1 Byte	I	C - - W -	DPT_Scaling	0% - 100%	[Profile] Volume	0-100%
	1 Byte	I	C - - W -		0-3	[Profile] Melody	0 = Mute; 1 = Melody 1; 2 = Melody 2; 3 = Melody 3
26	1 Byte	I	C - - W -		0-7	[Profile] Theme	0 = Ocean; 1 = Sky; 2 = Night; 3 = Twilight; 4 = Egg Shell; 5 = Seaside; 6 = Rioja; 7 = Forest
27, 35, 43, 51, 59, 67, 75, 83, 91, 99, 107, 115, 123, 131, 139, 147, 155, 163, 171, 179, 187, 195, 203, 211, 219, 227, 235, 243, 251, 259, 267, 275, 283, 291, 299, 307, 315, 323, 331, 339, 347, 355, 363, 371, 379, 387, 395, 403, 411, 419, 427, 435, 443, 451, 459, 467, 475, 483, 491, 499, 507, 515, 523, 531, 539, 547, 555, 563, 571, 579, 587, 595, 603, 611, 619, 627, 635, 643, 651, 659, 667, 675, 683, 691, 699, 707, 715, 723, 731, 739, 747, 755, 763, 771, 779, 787	1 Bit	I	CT - W U	DPT_Switch	0/1	[Px][Bx] Binary Indicator	1-Bit Indicator
	1 Byte	I	CT - W U	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Enumerated Indicator	0...255
	1 Byte	I	CT - W U	DPT_Value_1_Ucount	0 - 255	[Px][Bx] 1-Byte Unsigned Int Indicator	0...255
	1 Byte	I	CT - W U	DPT_Value_1_Count	-128 - 127	[Px][Bx] 1-Byte Signed Int Indicator	-128...127
	1 Byte	I	CT - W U	DPT_Scaling	0% - 100%	[Px][Bx] Percentage Indicator	0-100%
	2 Bytes	I	CT - W U	DPT_Value_2_Ucount	0 - 65535	[Px][Bx] 2-Byte Unsigned Int Indicator	0...65535
	2 Bytes	I	CT - W U	DPT_Value_2_Count	-32768 - 32767	[Px][Bx] 2-Byte Signed Int Indicator	-32768...32767
	2 Bytes	I	CT - W U	9.xxx	-671088.64 - 670760.96	[Px][Bx] 2-Byte Float Indicator	-671088.64...670760.96
	1 Byte	I	CT - W U	DPT_Scaling	0% - 100%	[Px][Bx] Shutter Position	0% = Top; 100% = Bottom
	1 Byte	I	CT - W U	DPT_Scaling	0% - 100%	[Px][Bx] Light Indicator	0% = Off; 100% = On
	2 Bytes	I	CT - W U	DPT_Value_Temp	-273.00 - 670760.00	[Px][Bx] Temperature Indicator	Absolute Float Value
	1 Bit	I	CT - W U	DPT_Heat_Cool	0/1	[Px][Bx] Mode Indicator	0 = Cool; 1 = Heat
	1 Byte	I	CT - W U	DPT_HVACContrMode	0 = Auto 1 = Heat 3 = Cool 9 = Fan 14 = Dry	[Px][Bx] Mode Indicator	Heat, Cool, Auto, Fan and Dry
	1 Byte	I	CT - W U	DPT_HVACMode	1=Comfort 2=Standby 3=Economy 4=Building Protection	[Px][Bx] Special Mode Indicator	Comfort, Standby, Economy, Building Protection and Auto
	1 Byte	I/O	CTR W U	DPT_Scaling	0% - 100%	[Px][Bx] Red Channel	0-100%
	1 Bit	I	C - - W U	DPT_Alarm	0/1	[Px][Bx] Alarm Trigger	Trigger
	1 Bit	I	CT - W U	DPT_Enable	0/1	[Px][Bx] Weekly Timer Enabling	0 = Disabled; 1 = Enabled
	1 Bit	I	CT - W U	DPT_Enable	0/1	[Px][Bx] Daily Timer Enabling	0 = Disabled; 1 = Enabled
	3 Bytes	I/O	CTR W U	DPT_Colour_RGB	[0 - 255] * 3	[Px][Bx] RGB Color	Red, Green and Blue Components
	1 Bit	I	CT - W U	DPT_Enable	0/1	[Px][Bx] Chrono-thermostat: Enabling	0 = Disabled; 1 = Enabled
	4 Bytes	I	CT - W U	DPT_Value_Power	-3.403E+38...3.403E+38	[Px][Bx] Consumption Monitor: Power	W
	2 Bytes	I	CT - W U	DPT_Power	-670760 - 670760 kW	[Px][Bx] Consumption Monitor: Power	kW
	4 Bytes	I	CT - W U	DPT_Value_Volume_Flux	-3.403E+38...3.403E+38	[Px][Bx] Consumption Monitor: Flow	m ³ /s
2 Bytes	I	CT - W U	DPT_Value_Volume_Flow	-671088.64 - 670760.96	[Px][Bx] Consumption Monitor: Flow	l/h	
4 Bytes	I	CT - W U	14.xxx	-3.403E+38 - 3.403E+38	[Px][Bx] 4-Byte Float Indicator	-3.403E+38...3.403E+38	

	4 Bytes	I	CT-WU	DPT_Value_4_Count	-2147483648 - 2147483647	[Px][Bx] 4-Byte Signed Int Indicator	-2147483648...2147483647
	1 Byte	I	CT-WU	DPT_Scaling	0% - 100%	[Px][Bx] Fan Indicator	0 - 100%
	1 Byte	I	CT-WU	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Indicator	Enumerated Value
	1 Bit	I	C--WU	DPT_Switch	0/1	[Px][Bx] Macro: Trigger	0 = Start; 1 = Stop
	1 Bit	I	C--WU	DPT_Switch	0/1	[Px][Bx] Macro: Trigger	0 = Stop; 1 = Start
	1 Bit	I	CT-WU	DPT_Enable	0/1	[Px][Bx] Scheduler Enabling	0 = Disabled; 1 = Enabled
	1 Bit	I	C--WU	DPT_Switch	0/1	[Px][Bx] Logic Function: Trigger	0 = Nothing; 1 = Evaluate
	1 Bit	I	C--WU	DPT_Switch	0/1	[Px][Bx] Logic Function: Trigger	0 = Evaluate; 1 = Nothing
	1 Bit	I	CT-WU	DPT_Enable	0/1	[Px][Bx] Daily Timer Enabling	0 = Enabled; 1 = Disabled
	1 Bit	I	CT-WU	DPT_Enable	0/1	[Px][Bx] Chrono-thermostat: Enabling	0 = Enabled; 1 = Disabled
	1 Bit	I	CT-WU	DPT_Enable	0/1	[Px][Bx] Weekly Timer Enabling	0 = Enabled; 1 = Disabled
	1 Bit	I	CT-WU	DPT_Enable	0/1	[Px][Bx] Scheduler Enabling	0 = Enabled; 1 = Disabled
28, 36, 44, 52, 60, 68, 76, 84, 92, 100, 108, 116, 124, 132, 140, 148, 156, 164, 172, 180, 188, 196, 204, 212, 220, 228, 236, 244, 252, 260, 268, 276, 284, 292, 300, 308, 316, 324, 332, 340, 348, 356, 364, 372, 380, 388, 396, 404, 412, 420, 428, 436, 444, 452, 460, 468, 476, 484, 492, 500, 508, 516, 524, 532, 540, 548, 556, 564, 572, 580, 588, 596, 604, 612, 620, 628, 636, 644, 652, 660, 668, 676, 684, 692, 700, 708, 716, 724, 732, 740, 748, 756, 764, 772, 780, 788	1 Bit	O	CTR--	DPT_Switch	0/1	[Px][Bx] Binary Control	1-Bit Control
	1 Byte	O	CTR--	DPT_Value_1_Ucount	0 - 255	[Px][Bx] 1-Byte Unsigned Int Control	0...255
	1 Byte	O	CTR--	DPT_Value_1_Count	-128 - 127	[Px][Bx] 1-Byte Signed Int Control	-128...127
	1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Px][Bx] Percentage Control	0-100%
	2 Bytes	O	CTR--	DPT_Value_2_Ucount	0 - 65535	[Px][Bx] 2-Byte Unsigned Int Control	0...65535
	2 Bytes	O	CTR--	DPT_Value_2_Count	-32768 - 32767	[Px][Bx] 2-Byte Signed Int Control	-32768...32767
	2 Bytes	O	CTR--	9.xxx	-671088.64 - 670760.96	[Px][Bx] 2-Byte Float Control	-671088.64...670760.96
	1 Byte	O	CTR--	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Enumerated Control	0...255
	1 Bit	O	CTR--	DPT_UpDown	0/1	[Px][Bx] Move Shutter	0 = Up; 1 = Down
	1 Bit	O	CTR--	DPT_Switch	0/1	[Px][Bx] Light On/Off	0 = Off; 1 = On
	2 Bytes	O	CTR--	DPT_Value_Temp	-273.00 - 670760.00	[Px][Bx] Temperature Control	Absolute Float Value
	2 Bytes	I/O	CTRW-	DPT_Value_Tempd	-670760.00 - 670760.00	[Px][Bx] Temperature Offset Control	Relative Float Value
	1 Bit	O	CTR--	DPT_Step	0/1	[Px][Bx] Temperature Offset Control	0 = Decrease; 1 = Increase
	1 Bit	O	CTR--	DPT_Heat_Cool	0/1	[Px][Bx] Mode Control	0 = Cool; 1 = Heat
	1 Byte	O	CTR--	DPT_HVACContrMode	0 = Auto 1 = Heat 3 = Cool 9 = Fan 14 = Dry	[Px][Bx] Mode Control	Heat, Cool, Auto, Fan and Dry
	1 Byte	O	CTR--	DPT_HVACMode	1=Comfort 2=Standby 3=Economy 4=Building Protection	[Px][Bx] Special Mode Control	Comfort, Standby, Economy, Building Protection and Auto
	1 Byte	I/O	CTRWU	DPT_Scaling	0% - 100%	[Px][Bx] Green Channel	0-100%
	1 Bit	O	CTR--	DPT_Switch	0/1	[Px][Bx] Daily Timer Control	1-Bit Control
	1 Bit	O	CTR--	DPT_Switch	0/1	[Px][Bx] Weekly Timer Control	1-Bit Control
	1 Bit	I	CT-WU	DPT_Ack	0/1	[Px][Bx] Alarm Confirmation	0 = No Action; 1 = Confirm
2 Bytes	O	CTR--	DPT_Value_Temp	-273.00 - 670760.00	[Px][Bx] Chrono-thermostat:	Absolute Float Value	

						Temperature Setpoint	
1 Bit	O	CTR--	DPT_Bool	0/1	[Px][Bx] Holiday (1-Bit)	0 = Holiday; 1 = Workday	
1 Bit	O	CTR--	DPT_Bool	0/1	[Px][Bx] Holiday (1-Bit)	0 = Workday; 1 = Holiday	
1 Bit	O	CTR--	DPT_Step	0/1	[Px][Bx] Fan Control (1-Bit)	0 = Decrease; 1 = Increase	
1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	Auto, 20%, 40%, 60%, 80%, 100%	
1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	Auto, 25%, 50%, 75%, 100%	
1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	Auto, 33%, 67%, 100%	
1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	Auto, 50%, 100%	
1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	Auto, 100%	
1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	0%, 25%, 50%, 75%, 100%	
1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	0%, 33%, 67%, 100%	
1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	0%, 50%, 100%	
1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	0%, 100%	
1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	0%, 20%, 40%, 60%, 80%, 100%	
1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	20%, 40%, 60%, 80%, 100%	
1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	25%, 50%, 75%, 100%	
1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	33%, 67%, 100%	
1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	50%, 100%	
1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Px][Bx] Fan Control (Scaling)	100%	
1 Byte	O	CTR--	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	Auto, 1, 2, 3, 4, 5	
1 Byte	O	CTR--	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	Auto, 1, 2, 3, 4	
1 Byte	O	CTR--	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	Auto, 1, 2, 3	
1 Byte	O	CTR--	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	Auto, 1, 2	
1 Byte	O	CTR--	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	Auto, 1	
1 Byte	O	CTR--	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	0, 1, 2, 3, 4, 5	
1 Byte	O	CTR--	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	0, 1, 2, 3, 4	
1 Byte	O	CTR--	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	0, 1, 2, 3	
1 Byte	O	CTR--	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	0, 1, 2	
1 Byte	O	CTR--	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	0, 1	
1 Byte	O	CTR--	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	1, 2, 3, 4, 5	
1 Byte	O	CTR--	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	1, 2, 3, 4	
1 Byte	O	CTR--	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	1, 2, 3	
1 Byte	O	CTR--	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	1, 2	
1 Byte	O	CTR--	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Fan Control (Enumerated)	1	
1 Bit	O	CTR--	DPT_Switch	0/1	[Px][Bx] Macro: Started	0 = Macro Started; 1 = Nothing	
1 Bit	O	CTR--	DPT_Switch	0/1	[Px][Bx] Macro: Started	0 = Nothing; 1 = Macro Started	
29, 37, 45, 53, 61, 69, 77, 85, 93, 101,	1 Bit	O	CTR--	DPT_Step	0/1	[Px][Bx] Stop Shutter	0 = Stop/Step Up; 1 = Stop/Step Down

109, 117, 125, 133, 141, 149, 157, 165, 173, 181, 189, 197, 205, 213, 221, 229, 237, 245, 253, 261, 269, 277, 285, 293, 301, 309, 317, 325, 333, 341, 349, 357, 365, 373, 381, 389, 397, 405, 413, 421, 429, 437, 445, 453, 461, 469, 477, 485, 493, 501, 509, 517, 525, 533, 541, 549, 557, 565, 573, 581, 589, 597, 605, 613, 621, 629, 637, 645, 653, 661, 669, 677, 685, 693, 701, 709, 717, 725, 733, 741, 749, 757, 765, 773, 781, 789	4 Bit	O	CTR--	DPT_Control_Dimming	0x0 (Stop) 0x1 (Dec. by 100%) 0x2 (Dec. by 50%) 0x3 (Dec. by 25%) 0x4 (Dec. by 12%) 0x5 (Dec. by 6%) 0x6 (Dec. by 3%) 0x7 (Dec. by 1%) 0x8 (Stop) 0x9 (Inc. by 100%) 0xA (Inc. by 50%) 0xB (Inc. by 25%) 0xC (Inc. by 12%) 0xD (Inc. by 6%) 0xE (Inc. by 3%) 0xF (Inc. by 1%)	[Px][Bx] Light Dimming	4-Bit Dimming Control
	1 Byte	I/O	CTRWU	DPT_Scaling	0% - 100%	[Px][Bx] Blue Channel	0-100%
	2 Bytes	I	CT-WU	9.xxx	-671088.64 - 670760.96	[Px][Bx] Consumption Monitor: Cost	Local Currency
	1 Bit	O	CTR--	DPT_Switch	0/1	[Px][Bx] Chrono-thermostat: On/Off	0 = Off; 1 = On
	1 Byte	I/O	CTRWU	DPT_Scaling	0% - 100%	[Px][Bx] White Channel	0-100%
	1 Byte	O	CTR--	DPT_Value_1_Ucount	0 - 255	[Px][Bx] Holiday (1-Byte)	0...255
	1 Bit	I/O	CTRWU	DPT_Switch	0/1	[Px][Bx] Fan Control - Auto Mode	Switch Auto Mode on Short Press
	1 Bit	I/O	CTRWU	DPT_Switch	0/1	[Px][Bx] Fan Control - Auto Mode	Switch Auto Mode on Long Press
30, 38, 46, 54, 62, 70, 78, 86, 94, 102, 110, 118, 126, 134, 142, 150, 158, 166, 174, 182, 190, 198, 206, 214, 222, 230, 238, 246, 254, 262, 270, 278, 286, 294, 302, 310, 318, 326, 334, 342, 350, 358, 366, 374, 382, 390, 398, 406, 414, 422, 430, 438, 446, 454, 462, 470, 478, 486, 494, 502, 510, 518, 526, 534, 542, 550, 558, 566, 574, 582, 590, 598, 606, 614, 622, 630, 638, 646, 654, 662, 670, 678, 686, 694, 702, 710, 718, 726, 734, 742, 750, 758, 766, 774,	4 Bit	O	CTR--	DPT_Control_Dimming	0x0 (Stop) 0x1 (Dec. by 100%) ... 0x7 (Dec. by 1%) 0x8 (Stop) 0x9 (Inc. by 100%) ... 0xF (Inc. by 1%)	[Px][Bx] Light Dimming	4-bit Dimming Control
	1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Px][Bx] Shutter Positioning (Only Macros)	0% = Top; 100% = Bottom
	1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Px][Bx] Precise Dimming (Only Macros)	1-Byte Dimmer Control

782, 790							
31, 39, 47, 55, 63, 71, 79, 87, 95, 103, 111, 119, 127, 135, 143, 151, 159, 167, 175, 183, 191, 199, 207, 215, 223, 231, 239, 247, 255, 263, 271, 279, 287, 295, 303, 311, 319, 327, 335, 343, 351, 359, 367, 375, 383, 391, 399, 407, 415, 423, 431, 439, 447, 455, 463, 471, 479, 487, 495, 503, 511, 519, 527, 535, 543, 551, 559, 567, 575, 583, 591, 599, 607, 615, 623, 631, 639, 647, 655, 663, 671, 679, 687, 695, 703, 711, 719, 727, 735, 743, 751, 759, 767, 775, 783, 791	4 Bytes	I	CT - W U	DPT_Value_Volume	-3.403E+38 - 3.403E+38	[Px][Bx] Consumption Monitor: Volume	m ³
	4 Bytes	I	CT - W U	DPT_ActiveEnergy	-3.403E+38 - 3.403E+38	[Px][Bx] Consumption Monitor: Energy	Wh
	4 Bytes	I	CT - W U	DPT_ActiveEnergy_kWh	-2147483648 - 2147483647	[Px][Bx] Consumption Monitor: Energy	kWh
	14 Bytes	I	CT - W U			[Px][Bx] 14-Byte Text Indicator	UTF-8 Text String
32, 40, 48, 56, 64, 72, 80, 88, 96, 104, 112, 120, 128, 136, 144, 152, 160, 168, 176, 184, 192, 200, 208, 216, 224, 232, 240, 248, 256, 264, 272, 280, 288, 296, 304, 312, 320, 328, 336, 344, 352, 360, 368, 376, 384, 392, 400, 408, 416, 424, 432, 440, 448, 456, 464, 472, 480, 488, 496, 504, 512, 520, 528, 536, 544, 552, 560, 568, 576, 584, 592, 600, 608, 616, 624, 632, 640, 648, 656, 664, 672, 680, 688, 696, 704, 712, 720, 728, 736, 744, 752, 760, 768, 776,	2 Bytes	I	CT - W U	9.xxx	-671088.64 - 670760.96	[Px][Bx] Consumption Monitor: CO ₂	kg CO ₂

784, 792						
33, 41, 49, 57, 65, 73, 81, 89, 97, 105, 113, 121, 129, 137, 145, 153, 161, 169, 177, 185, 193, 201, 209, 217, 225, 233, 241, 249, 257, 265, 273, 281, 289, 297, 305, 313, 321, 329, 337, 345, 353, 361, 369, 377, 385, 393, 401, 409, 417, 425, 433, 441, 449, 457, 465, 473, 481, 489, 497, 505, 513, 521, 529, 537, 545, 553, 561, 569, 577, 585, 593, 601, 609, 617, 625, 633, 641, 649, 657, 665, 673, 681, 689, 697, 705, 713, 721, 729, 737, 745, 753, 761, 769, 777, 785, 793	1 Bit	O	CTR--	DPT_Switch	0/1	[Px][Bx] Consumption Monitor: Request 0 = No Action; 1 = Request
34, 42, 50, 58, 66, 74, 82, 90, 98, 106, 114, 122, 130, 138, 146, 154, 162, 170, 178, 186, 194, 202, 210, 218, 226, 234, 242, 250, 258, 266, 274, 282, 290, 298, 306, 314, 322, 330, 338, 346, 354, 362, 370, 378, 386, 394, 402, 410, 418, 426, 434, 442, 450, 458, 466, 474, 482, 490, 498, 506, 514, 522, 530, 538, 546, 554, 562, 570, 578, 586, 594, 602, 610, 618, 626, 634, 642, 650, 658, 666, 674, 682, 690, 698, 706, 714, 722, 730, 738, 746, 754, 762, 770, 778,	1 Bit	O	CTR--	DPT_Reset	0/1	[Px][Bx] Consumption Monitor: Reset 0 = No Action; 1 = Reset

786, 794							
795	14 Bytes	I/O	CTR W -			[Video Intercom] Synchronization	Video Intercom Synchronization
796	1 Bit	I/O	CTR W -	DPT_Enable	0/1	[Video Intercom] "Do Not Disturb" Mode	0 = Normal; 1 = Do Not Disturb
797	1 Byte	I	C - - W -	DPT_Value_1_Ucount	0 - 255	[Video Intercom] Ringtone	0 = Ringtone 1; 1 = Ringtone 2; 2 = Ringtone 3
798	1 Byte	I	C - - W -	DPT_Scaling	0% - 100%	[Video Intercom] Ringtone Volume	0-100%
799	1 Bit		CT - - -	DPT_Ack	0/1	[Video Intercom] Incoming Call	0 = Nothing; 1 = Incoming Call
800	1 Bit	I	C - - W -	DPT_Ack	0/1	[Video Intercom] Play Ringtone	0 = Nothing; 1 = Play Ringtone
801, 805, 809, 813	1 Bit	O	CTR - -	DPT_Switch	0/1	[VI x] Switch 1	1 = Open
	1 Bit	O	CTR - -	DPT_Switch	0/1	[VI x] Switch 1	0 = Open
802, 806, 810, 814	1 Bit	O	CTR - -	DPT_Switch	0/1	[VI x] Switch 2	1 = Open
	1 Bit	O	CTR - -	DPT_Switch	0/1	[VI x] Switch 2	0 = Open
803, 807, 811, 815	1 Bit	O	CTR - -	DPT_Switch	0/1	[VI x] Switch 3	1 = Open
	1 Bit	O	CTR - -	DPT_Switch	0/1	[VI x] Switch 3	0 = Open
804, 808, 812, 816	1 Bit	I/O	CTR W -	DPT_Enable	0/1	[VI x] Enable Automatic Door Opening	0 = Disable; 1 = Enable
817	1 Byte	I	C - - W -	DPT_SceneControl	0-63; 128-191	[Thermostat] Scene Input	Scene Value
818, 848	2 Bytes	I	C - - W -	DPT_Value_Temp	-273.00 - 670760.00	[Tx] Temperature Source 1	External Sensor Temperature
819, 849	2 Bytes	I	C - - W -	DPT_Value_Temp	-273.00 - 670760.00	[Tx] Temperature Source 2	External Sensor Temperature
820, 850	2 Bytes	O	CTR - -	DPT_Value_Temp	-273.00 - 670760.00	[Tx] Effective Temperature	Effective Control Temperature
821, 851	1 Byte	I	C - - W -	DPT_HVACMode	1=Comfort 2=Standby 3=Economy 4=Building Protection	[Tx] Special Mode	1-byte HVAC Mode
822, 852	1 Bit	I	C - - W -	DPT_Ack	0/1	[Tx] Special Mode: Comfort	0 = Nothing; 1 = Trigger
	1 Bit	I	C - - W -	DPT_Switch	0/1	[Tx] Special Mode: Comfort	0 = Off; 1 = On
823, 853	1 Bit	I	C - - W -	DPT_Ack	0/1	[Tx] Special Mode: Standby	0 = Nothing; 1 = Trigger
	1 Bit	I	C - - W -	DPT_Switch	0/1	[Tx] Special Mode: Standby	0 = Off; 1 = On
824, 854	1 Bit	I	C - - W -	DPT_Ack	0/1	[Tx] Special Mode: Economy	0 = Nothing; 1 = Trigger
	1 Bit	I	C - - W -	DPT_Switch	0/1	[Tx] Special Mode: Economy	0 = Off; 1 = On
825, 855	1 Bit	I	C - - W -	DPT_Ack	0/1	[Tx] Special Mode: Protection	0 = Nothing; 1 = Trigger
	1 Bit	I	C - - W -	DPT_Switch	0/1	[Tx] Special Mode: Protection	0 = Off; 1 = On
826, 856	1 Bit	I	C - - W -	DPT_Window_Door	0/1	[Tx] Window Status (Input)	0 = Closed; 1 = Open
827, 857	1 Bit	I	C - - W -	DPT_Ack	0/1	[Tx] Comfort Prolongation	0 = Nothing; 1 = Timed Comfort
828, 858	1 Byte	O	CTR - -	DPT_HVACMode	1=Comfort 2=Standby 3=Economy 4=Building Protection	[Tx] Special Mode Status	1-byte HVAC Mode
829, 859	2 Bytes	I	C - - W -	DPT_Value_Temp	-273.00 - 670760.00	[Tx] Setpoint	Thermostat Setpoint Input
	2 Bytes	I	C - - W -	DPT_Value_Temp	-273.00 - 670760.00	[Tx] Basic Setpoint	Reference Setpoint
830, 860	1 Bit	I	C - - W -	DPT_Step	0/1	[Tx] Setpoint Step	0 = -0.5°C; 1 = +0.5°C
831, 861	2 Bytes	I	C - - W -	DPT_Value_Tempd	-670760.00 - 670760.00	[Tx] Setpoint Offset	Float Offset Value

832, 862	2 Bytes	O	CTR--	DPT_Value_Temp	-273.00 - 670760.00	[Tx] Setpoint Status	Current Setpoint
833, 863	2 Bytes	O	CTR--	DPT_Value_Temp	-273.00 - 670760.00	[Tx] Basic Setpoint Status	Current Basic Setpoint
834, 864	2 Bytes	O	CTR--	DPT_Value_Tempd	-670760.00 - 670760.00	[Tx] Setpoint Offset Status	Current Setpoint Offset
835, 865	1 Bit	I	C--W-	DPT_Reset	0/1	[Tx] Setpoint Reset	Reset Setpoint to Default
	1 Bit	I	C--W-	DPT_Reset	0/1	[Tx] Offset Reset	Reset offset
836, 866	1 Bit	I	C--W-	DPT_Heat_Cool	0/1	[Tx] Mode	0 = Cool; 1 = Heat
837, 867	1 Bit	O	CTR--	DPT_Heat_Cool	0/1	[Tx] Mode Status	0 = Cool; 1 = Heat
838, 868	1 Bit	I	C--W-	DPT_Switch	0/1	[Tx] On/Off	0 = Off; 1 = On
839, 869	1 Bit	O	CTR--	DPT_Switch	0/1	[Tx] On/Off Status	0 = Off; 1 = On
840, 870	1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Tx] Control Variable (Cool)	PI Control (Continuous)
841, 871	1 Byte	O	CTR--	DPT_Scaling	0% - 100%	[Tx] Control Variable (Heat)	PI Control (Continuous)
842, 872	1 Bit	O	CTR--	DPT_Switch	0/1	[Tx] Control Variable (Cool)	2-Point Control
	1 Bit	O	CTR--	DPT_Switch	0/1	[Tx] Control Variable (Cool)	PI Control (PWM)
843, 873	1 Bit	O	CTR--	DPT_Switch	0/1	[Tx] Control Variable (Heat)	2-Point Control
	1 Bit	O	CTR--	DPT_Switch	0/1	[Tx] Control Variable (Heat)	PI Control (PWM)
844, 874	1 Bit	O	CTR--	DPT_Switch	0/1	[Tx] Additional Cool	Temp >= (Setpoint+Band) => "1"
845, 875	1 Bit	O	CTR--	DPT_Switch	0/1	[Tx] Additional Heat	Temp <= (Setpoint-Band) => "1"
846, 876	1 Bit	O	CTR--	DPT_Switch	0/1	[Tx] PI State (Cool)	0 = PI signal 0%; 1 = PI signal greater than 0%
847, 877	1 Bit	O	CTR--	DPT_Switch	0/1	[Tx] PI State (Heat)	0 = PI signal 0%; 1 = PI signal greater than 0%

Join and send us your inquiries
about Zennio devices:

<http://support.zennio.com>

Zennio Avance y Tecnología S.L.
C/ Río Jarama, 132. Nave P-8.11
45007 Toledo (Spain).

Tel. +34 925 232 002.

www.zennio.com
info@zennio.com



RoHS