

Iddero Verso Icon List

Version: 1.0



	Icon	Description		Icon	Description
1		Home	23		None
2		Back	24		Save
3		Arrow right	25		Options
4		Arrow left	26		Reset
5		Arrow up	27		Favorites
6		Arrow down	28		Pencil
7		Double arrow left	29		Communications
8		Double arrow right	30		Misc.
9		Double arrow up	31	0	Digit 0
10		Double arrow down	32	1	Digit 1
11		Arrow right 2	33	2	Digit 2
12		Arrow left 2	34	3	Digit 3
13		Arrow up 2	35	4	Digit 4
14		Arrow down 2	36	5	Digit 5
15		Accept	37	6	Digit 6
16		Accept all	38	7	Digit 7
17		Cancel	39	8	Digit 8
18		Close	40	9	Digit 9
19		Restore	41		Lamp on
20		Close 2	42		Lamp off
21		Plus	43		Lamp on/off
22		Minus	44		Darker

Iddero Verso Icon List

Version: 1.0



Icon	Description	Icon	Description
45	Brighter	67	Sunblind down
46	Dimmer	68	Sunblind up
47	Contrast	69	Sunblind
48	Contrast 2	70	Roller blind up
49	Table lamp	71	Roller blind down
50	Wall lamp	72	Roller blind
51	Ceiling lamp	73	Off
52	Shutter step down	74	On
53	Shutter step up	75	On/off
54	Shutter up	76	On/off 2
55	Shutter down	77	Plug
56	Shutter open	78	Plug Ok
57	Shutter closed	79	Plug not Ok
58	Shutter mid pos	80	Socket
59	Shutter horiz. open	81	Cool
60	Shutter horiz. close	82	Heat
61	Shutter horiz. right	83	Cool/heat
62	Shutter horiz. left	84	Cool+
63	Slats down	85	Heat+
64	Slats up	86	Dry
65	Slats horiz.	87	Comfort
66	Slats	88	Standby

Iddero Verso Icon List

Version: 1.0



	Icon	Description		Icon	Description
89		Economy	111		Fan auto
90		Protect	112		Fan stop
91		Auto	113		Fan off
92		Manual	114		Temperature decrease
93		Vanes horizontal	115		Temperature increase
94		Vanes vertical	116		Temperature
95		Vanes 1	117		Temperature settings
96		Vanes 2	118		A/C split
97		Vanes 3	119		Radiator
98		Vanes 4	120		Summer
99		Vanes 5	121		Summer/winter
100		Vanes swing	122		Day/night
101		Vanes stop	123		Clouds
102		Vanes auto	124		Cloud
103		Fan	125		Cloud + rain
104		Fan lower	126		Cloud + snow
105		Fan higher	127		Cloud + snow 2
106		Fan 1	128		Cloud + storm
107		Fan 2	129		Wind
108		Fan 3	130		CO2
109		Fan 4	131		Lightning
110		Fan 5	132		Scene

Iddero Verso Icon List

Version: 1.0



	Icon	Description		Icon	Description
133		Scene edit	155		iPod
134		Enter home	156		CD / DVD
135		Exit home	157		Projector
136		Party	158		TV
137		Sandclock	159		Unlocked
138		Clock	160		Locked
139		Play	161		Locked off
140		Stop	162		Locked on
141		Pause	163		Security
142		Prev	164		Presence simulation
143		Next	165		House settings
144		Fast forward	166		Warning
145		Rewind	167		Info
146		Record	168		Alarm
147		Eject	169		Alarm 2
148		Volume off	170		Alarm 3
149		Volume up	171		Alarm 4
150		Volume down	172		Intrusion
151		Volume	173		Fire
152		Sound	174		Gas
153		Equalizer	175		Water
154		Music	176		Sprinkler

Iddero Verso Icon List

Version: 1.0












Icon	Description	Icon	Description
177	Valve	199	Toilet
178	Window open	200	Bath
179	Window closed	201	Wardrobe
180	Door open	202	Couch
181	Garage door open	203	Dishes
182	Garage door closed	204	Staircase
183	Key	205	Gym
184	Door open 2	206	Swimmingpool
185	Phone pick up	207	Car
186	Phone hang up	208	Car 2
187	Microphone	209	Plant
188	Camera	210	Fountain
189	Mobile phone	211	Mountains
190	Water heater	212	Solar cells
191	Coffee machine	213	First aids
192	Oven	214	Disabled people
193	Iron	215	Do not disturb
194	Washing machine	216	Food service
195	Cooking pot	217	Clean room
196	Water deposit	218	Do not clean room
197	Double bed	219	Log
198	Single bed	220	Date

Iddero Verso Icon List

Version: 1.0



	Icon	Description		Icon	Description
221		Settings	226		Eco settings
222		Settings 2	227		Clean screen
223		Settings 3	228		User interface
224		Settings 4	229		Globe
225		Edit			